

UNI-T®

Instruments.uni-trend.com



MSO5000HD Series High-Resolution Oscilloscopes

User Manual

The manual applies to:

MSO5000HD series

V2.0

May. 2025

Foreword













Thank you for choosing this UNI-T instrument. For safe and proper use this instrument, please read this manual carefully, especially the safety instructions section.





After reading this manual, it is recommended to keep the manual in a convenient location, preferably near the device, for future reference.

1. Safety Instructions

This chapter contains information and warnings that must be observed. Ensure that the instrument is operated under the safe conditions. In addition to the safety precautions indicated in this chapter, you must also follow accepted safety procedures.

Safety Precautions	
Warning	Please follow these guidelines to avoid possible electric shock and risk to personal safety.
	Users must adhere to standard safety precautions during the operation, servicing, and maintenance of this device. UNI-T will not be liable for any personal safety and property loss caused by the user's failure following the safety precautions. This device is designed for professional users and responsible organizations for measurement purposes.
	Do not use this device in any manner not specified by the manufacturer. This device is intended for indoor use only, unless otherwise stated in the product manual.
Safety Statements	
Warning	“Warning” indicates the presence of a hazard. It warns users to pay attention to a certain operation process, operation method or similar. Personal injury or death may occur if the rules in the “Warning” statement are not properly performed or observed. Do not proceed to the next step until you fully understand and meet the conditions stated in the “Warning” statement.
Caution	“Caution” indicates the presence of a hazard. It warns users to pay attention to a certain operation process, operation method or similar. Product damage or loss of important data may occur if the rules in the “Caution” statement are not properly performed or observed. Do not proceed to the next step until you fully understand and meet the conditions stated in the “Caution” statement.
Note	“Note” indicates important information. It reminds users to pay attention to procedures, methods, and conditions, etc. The contents of “Note” should be highlighted if necessary.

Safety Sign		
	Danger	It indicates danger of electric shock, which may cause personal injury or death.
	Warning	It indicates that there are factors you should be cautious of to prevent personal injury or product damage.
	Caution	It indicates danger, which may cause damage to this device or other equipment if you fail to follow a certain procedure or condition. If the “Caution” sign is present, all conditions must be met before you proceed to operation.
	Note	It indicates potential problems, which may cause failure of this device if you fail to follow a certain procedure or condition. If the “Note” sign is present, all conditions must be met before this device will function properly.
	AC	Alternating current of device. Please check the region's voltage range.
	DC	Direct current device. Please check the region's voltage range.
	Grounding	Frame and chassis grounding terminal
	Grounding	Protective grounding terminal
	Grounding	Measurement grounding terminal
	OFF	Main power off
	ON	Main power on
	Power	Standby power supply: When the power switch is turned off, this device is not completely disconnected from the AC power supply.
CAT I		Secondary electrical circuit connected to wall sockets through transformers or similar equipment, such as electronic instruments and electronic equipment with protective measures, and any high-voltage and low-voltage circuits, such as the copier in the office.
CAT II		Primary electrical circuit of the electrical equipment connected to the indoor socket via the power cord, such as mobile tools, home appliances, etc. Household appliances, portable tools (e.g., electric drill), household sockets, sockets more than 10 meters away from CAT III circuit or sockets more than 20 meters away from CAT IV circuit.
CAT III		Primary circuit of large equipment directly connected to the distribution board and circuit between the distribution board and the socket (three-phase distributor circuit includes a single

		commercial lighting circuit). Fixed equipment, such as multi-phase motor and multi-phase fuse box; lighting equipment and lines inside large buildings; machine tools and power distribution boards at industrial sites (workshops).
CAT IV		Three-phase public power unit and outdoor power supply line equipment. Equipment designed to “initial connection”, such as power distribution system of power station, power instrument, front-end overload protection, and any outdoor transmission line.
	Certification	CE indicates a registered trademark of EU
	Certification	Conforms to UL STD 61010-1 and 61010-2-030. Certified to CSA STD C22.2 No.61010-1 and 61010-2-030.
	Waste	Do not place equipment and accessories in the trash. Items must be properly disposed of in accordance with local regulations.
	EFUP	This environment-friendly use period (EFUP) mark indicates that dangerous or toxic substances will not leak or cause damage within this indicated time period. The environmentally friendly use period of this product is 40 years, during which it can be used safely. Upon expiration of this period, it should enter the recycling system.

Warning

Any changes or modifications to this unit not expressly approved by the party responsible for compliance may void the user's authority to operate the equipment.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to the radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is

connected.

- Consult the dealer or an experienced radio/TV technician for help.

Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Safety Requirements	
Warning	
Preparation before use	<p>Please connect this device to AC power supply with the power cable provided.</p> <p>The AC input voltage of the line reaches the rated value of this device. See the product manual for specific rated value.</p> <p>The line voltage switch of this device matches the line voltage.</p> <p>The line voltage of the line fuse of this device is correct.</p> <p>It is not used to measure the main circuit.</p>
Check all terminal rated values	<p>Please check all rated values and marking instructions on the product to avoid fire and impact of excessive current. Please consult the product manual for detailed rated values before connection.</p>
Use the power cord properly	<p>The user can only use the special power cord for the instrument approved by the local and state standards. Please check whether the insulation layer of the cord is damaged, or the cord is exposed, and test whether the cord is conductive. If the cord is damaged, please replace it before using the instrument.</p>
Instrument Grounding	<p>To avoid electric shock, the grounding conductor must be connected to the ground. This product is grounded through the grounding conductor of the power supply. Please be sure to ground this product before it is powered on.</p>
AC power supply	<p>Please use the AC power supply specified for this device. Please use the power cord approved by your country and confirm that the insulation layer is not damaged.</p>
Electrostatic prevention	<p>This device may be damaged by static electricity, so it should be tested in the anti-static area if possible. Before the power cable is connected to this device, the internal and external conductors should be grounded briefly to release static electricity. The protection grade of this device is 4 kV for contact discharge and 8 kV for air discharge.</p>

Measurement accessories	Measurement accessories are of lower class, which are definitely not applicable to main power supply measurement, CAT II, CAT III or CAT IV circuit measurement. Probe subassemblies and accessories within the range of IEC 61010-031 and current sensor within the range of IEC 61010-2-032 can meet its requirements.
Use the input / output port of this device properly	Please use the input / output ports provided by this device in a proper manner. Do not load any input signal at the output port of this device. Do not load any signal that does not reach the rated value at the input port of this device. The probe or other connection accessories should be effectively grounded to avoid product damage or abnormal function. Please refer to the product manual for the rated value of the input / output port of this device.
Power fuse	Please use power fuse of specified specification. If the fuse needs to be replaced, it must be replaced with another one that meets the specified specifications by the maintenance personnel authorized by UNI-T.
Disassembly and cleaning	There are no components available to operators inside. Do not remove the protective cover. Maintenance must be carried out by qualified personnel.
Service environment	This device should be used indoors in a clean and dry environment with ambient temperature from 0 °C to +40 °C. Do not use this device in explosive, dusty, or high humidity conditions.
Do not operate in humid environment	Do not use this device in a humid environment to avoid the risk of internal short circuit or electric shock.
Do not operate in flammable and explosive environment	Do not use this device in a flammable and explosive environment to avoid product damage or personal injury.
Caution	
Abnormality	If this device may be faulty, please contact the authorized maintenance personnel of UNI-T for testing. Any maintenance, adjustment or parts replacement must be done by the relevant personnel of UNI-T.
Cooling	Do not block the ventilation holes at the side and back of this device. Do not allow any external objects to enter this device via ventilation holes. Please ensure adequate ventilation and leave a gap of at least 15 cm on both sides, front and back of this device.

Safe transportation	Please transport this device safely to prevent it from sliding, which may damage the buttons, knobs or interfaces on the instrument panel.
Proper ventilation	Poor ventilation will cause the device temperature to rise, thus causing damage to this device. Please keep proper ventilation during use, and regularly check the vents and fans.
Keep clean and dry	Please take actions to avoid dust or moisture in the air affecting the performance of this device. Please keep the product surface clean and dry.
Note	
Calibration	The recommended calibration period is one year. Calibration should only be carried out by qualified personnel.

1.1. Environmental Requirements

This instrument is suitable for the following environment.

- Indoor use
- Pollution degree: Class 2
- Overvoltage category: This product should be powered from a mains supply that complies with Overvoltage Category II, which is a typical requirement for connecting equipment via power cords and plugs.
- Operating: Altitude below 3,000 meters; non-operating: Altitude below 15,000 meters.
- Unless otherwise specified, the operating temperature range is from 0°C to +40°C, and the storage temperature range is from -20°C to +70°C.
- Operating: Humidity at temperature below +35°C, ≤ 90% RH. (Relative humidity);
non-operating: Humidity at temperatures from +35°C to +40°C, ≤ 60% RH.

There are ventilation outlets on the rear and side panels of the instrument, please keep the air ventilation in the outlet of housing. To prevent excessive dust from blocking the vents, clean the instrument housing regularly. The housing is not waterproof; please cut off the power supply first and then wipe the housing with a dry cloth or a slightly moistened soft cloth.

1.2. Connecting Power Supply

The specification of the AC power supply is as shown in the following table.

Voltage Range	Frequency
100-240 VAC (Fluctuations $\pm 10\%$)	50/60 Hz
100-120 VAC (Fluctuations $\pm 10\%$)	400 Hz

Please use the attached power cord to connect to the power port.

Connecting to the service cable:

This instrument is a Class I safety product. The supplied power cables have reliable performance in terms of case grounding. This instrument is equipped with a three-prong power cable that meets international safety standards. It provides good case grounding performance for the specifications of your country or region.

Please install the AC power cable as follows:

- Ensure the power cable is in good condition.
- Leave enough space to connect the power cord.
- Plug the attached three-prong power cable into a well-grounded power socket.

1.3. Electrostatic Protection

Electrostatic discharge may cause damage to components. Components can be invisibly damaged by electrostatic discharge during transportation, storage, and use.

The following measures can reduce the damage caused by electrostatic discharge:

- Test in an antistatic area as far as possible.
- Before connecting the power cable to the instrument, briefly ground the inner and outer conductors of the instrument to discharge static electricity.
- Ensure all instruments are properly grounded to prevent the accumulation of static.

2. Introduction

This manual introduces the safety requirements, installation, and operation of the MSO5000HD series high-resolution oscilloscopes.

3. MSO5000HD Series Oscilloscopes

MSO5000HD is a high-resolution oscilloscope that integrates four signal channels, a 16-channel logic analyzer, and a two-channel arbitrary waveform generator. With bandwidths of up to 1 GHz, a maximum sampling rate of 5 GSa/s, and 12-bit ADC resolution, it offers industry-leading high-speed signal acquisition and storage capabilities. The oscilloscope features a maximum memory depth of 500 Mpts, making it ideal for long-term recording and analysis of high-speed signals. Designed for general-purpose design, debugging, and testing, it serves a wide range of digital oscilloscope markets, including communications, semiconductors, computing, instrumentation, industrial electronics, consumer electronics, automotive electronics, field maintenance, R&D, education, and more.

MSO5000HD series high-resolution oscilloscopes includes three models.

Model	Analog channel number	Analog bandwidth	Digital	Gen
MSO5104HD	4	1 GHz	●	○
MSO5054HD	4	500 MHz	●	○
MSO5034HD	4	350 MHz	●	○

○: Option ●: Standard ×: Not support

4. Document Overview

This user manual is designed to help users quickly understand the front panel, rear panel, user interface, and basic operations of the MSO5000HD series high-resolution oscilloscopes.

Note: The latest edition of the user manual can be downloaded from the UNI-T website:

<https://www.uni-trend.com>

(1) Software Version

The software update may change or add new functions. Please visit the UNI-T website for the latest version or contact UNI-T to upgrade the software.

(2) Document Format

a. Key

A key with a character frame represents a key on the front panel. For example, Default represents the “Default” key.

b. Menu

Double quotation marks represent a menu or a pop-up menu. For example, “Channel Setting” pop-up menu on the operation interface allows you to click on “Vertical Scale” to operate and set the vertical scale settings.

c. Operation Step

Use an arrow “>” to represent the next step. For example, “Storage > Save” represents that in the Storage Menu, you should first click on “Storage” and then click on “Save” to save the waveform, setting, or picture file.

d. Connector

“Square brackets + Word” represents a connector on the front or rear panel. For example, [AUX OUT].

e. Hyperlink

“Underline + Blue text” represents a hyperlink. For example, [Connecting Power Supply](#).

f. Rotary knob

A key with an underline represents a rotary knob. For example, Position represents the vertical rotary knob.

5. Getting Started Guide

- [General Inspection](#)
- [Before Use](#)
- [Front Panel](#)
- [Rear Panel](#)
- [Operation Panel](#)
- [User Interface](#)
- [Touch Screen](#)
- [Parameter Setting](#)
- [Remote Control](#)

This chapter is to introduce on using the oscilloscope for the first time, the front and rear panels, the user interface, as well as touch screen function.

5.1. General Inspection

It is recommended to inspect the instrument follow the steps below before using the MSO5000HD series oscilloscopes for the first time.

(1) Check for Damages caused by Transport

If the packaging carton or the foam plastic cushions are severely damaged, please contact the UNI-T distributor of this product immediately.

(2) Check Accessories

The details of the supplied accessories are described in the MSO5000HD series high-resolution oscilloscopes accessories section in this manual. Please refer to this section for the list of accessories. If any accessories are missing or damaged, contact UNI-T or the local distributors of this product.

(3) Machine Inspection

If the instrument appears to be damaged, not working properly, or has failed the functionality test, please contact UNI-T or local distributors of this product.



If the equipment is damaged due to shipping, please keep the packaging and notify both the

transportation department and UNI-T distributors, UNI-T will arrange maintenance or replacement.


5.2. Before Use

To perform a quick verification of the instrument's normal operations, please follow the steps below.

(1) Connecting to the Power Supply


Refer to Connecting Power Supply, use the assembled power line or other power line that meets the local country standards to connect the oscilloscope. When the power switch on the rear panel is not opened, the power soft key indicator  at the left bottom on the rear panel is extinguished, which indicates this soft switch key is no-effect. When the power switch on the rear panel is opened, the power soft key indicator  at the left bottom on the rear panel is illuminated with red, and then press the soft switch key to enable the oscilloscope.

(2) Boot Check

Press the power soft key and the indicator  should change from red to green. The oscilloscope will show a boot animation, and then enter the normal interface.


(3) Connecting Probe

This oscilloscope provides 2 pieces of compensating signal probe. Connect the BNC of the probe to the BNC of oscilloscope's CH1 and connect the probe to the "Probe Compensating Signal Connection Clip" and then connect the ground alligator clip of the probe with the ground terminal of compensating signal connection clip. The output of compensating signal connection clip: amplitude is approximately 3 Vpp, with a default frequency of 1 kHz.



Probe Compensating Signal Connection Clip and Ground Terminal

(4) Function Check


Press the  key, a square wave (amplitude 3 Vpp, frequency 1 kHz) should appear on the screen. Repeat step 3 to check all channels.

(5) Probe Compensation

When the probe is connected to any input channel for the first time, this step might be adjusted to match the probe and the input channel. Probes that are not compensated may lead to measurement errors or mistakes. Please follow the following steps to adjust the probe

compensation.

- Set the attenuation coefficient in the probe menu to 10x and set the probe switch to 10x. Connect the oscilloscope probe to CH1. If using the probe's hook tip, ensure it makes stable contact. Connecting the probe to the “Probe Compensation Signal Connection Clip” of the oscilloscope and connect the ground alligator clip to the ground terminal of probe compensating signal connection clip. Open CH1 and press the **Autoset** key.
- View the displayed waveform, as shown in the following figure.




- If the displayed waveform resembles the above “Insufficient Compensation” or “Excessive Compensation”, use a non-metallic screwdriver to adjust the probe's variable capacitance until the display matches the “Correct compensation” waveform.

Note: The probe type is UT-P07A and UT-P08A. When connected to the oscilloscope, the probe ratio will be automatically identified as X10.

Warning: To avoid electric shock when using the probe to measure high voltage, please ensure that the probe insulation is in good condition and avoid physical contact with any metallic part of the probe.

5.3. Front Panel




No.	Description	No.	Description
1	Display area	8	Probe compensating signal connection clip and ground terminal ①
2	Measurement analysis area	9	Vertical control area
3	Multi-function area	10	Analog channel input terminal ②
4	Control area	11	Digital channel input terminal ③
5	Horizontal control area	12	Gen output port ④
6	Trigger control area	13	USB HOST port
7	Signal output area	14	Power soft switch key

- ① Probe compensation signal connection terminal and ground terminal: Connect the BNC end of the probe to the BNC connector on Channel 1 of the oscilloscope. Attach the probe tip to the "Probe Compensation Signal Terminal", and connect the probe's ground alligator clip to the "Ground Terminal" beneath the probe compensation signal terminal. This setup will output the oscilloscope's internal signal. For more details, refer to the section [Before Use - Connecting the Probe](#).
- ② Analog channel input terminal: Connect the oscilloscope probe or BNC cable to these BNC connectors to input a signal into the oscilloscope.

- ③ Digital channel input port: Use the UT-M15 logic probe, provided as an accessory, to connect the oscilloscope to the device under test for digital channel usage. For more details, refer to the section [Digital Channel](#).
- ④ Signal Source Output Interface G1, G2: These BNC connections can output signals such as continuous wave, amplitude modulation, frequency modulation, amplitude-shift keying, frequency-shift keying, and sweep signals. For more details, refer to the section [Function/Arbitrary Waveform Generator \(Gen\)](#).

Note: The output terminal of the signal source is equipped with an OVP function. When the input voltage exceeds ± 9 V, OVP will be triggered.

5.4. Rear Panel



Rear Panel

1. EXT Trig: The input terminal of external trigger
2. AUX OUT: Output terminal for trigger output, Pass/Fail output, DVM output
3. 10MHz REF: 10 MHz REF IN&OUT, BNC. Use this port to import the external reference clock signal or export 10 MHz clock signal generated by the internal crystal oscillator of the instrument.
4. USB HOST: Supports USB device
5. HDMI: Supports to connect an external display with HDMI port

6. USB Device: USB Device for communication between the oscilloscope and a PC
7. LAN: Connects to LAN for remote control
8. Power switch: After the AC power socket is properly connected, turn on the power switch. Then, press the power soft key on the front panel to start the oscilloscope.
9. AC power input socket: Use the assembled power cable to connect the oscilloscope to AC power, refer [Before Use - Connecting the Probe](#) section.
10. Safety lock: Lock the oscilloscope at fixed position (sold separately).

5.5. Operation Panel

(1) Vertical Control



- **1**, **2**, **3**, **4**: Analog channel setting key respectively represents CH1, CH2, CH3 and CH4. The four channel tabs are identified by different colors, which correspond to the waveform colors on the screen and the channel input connectors. Press any keys to enter the related channel menu (activate or disable the channel). For more details, refer to the section of [Vertical System](#).
- **Math**: Press this key to open the mathematical operation menu to perform math operation (add, subtract, multiply, divide), digital filter and advanced operation. For more details, refer to the section of [Mathematical Operation](#).
- **Ref**: Loading the reference waveform from “local or USB”, so the measured waveform can compare with the reference waveform. For more details, refer to the section of [Reference Waveform](#).
- **Bus**: Press this key to enter protocol decoding setting, to set the decoding of RS232, I²C, SPI, CAN, CAN-FD, CAN-XL, LIN, FlexRay, Audio, 1553B, Manchester, SENT, ARINC429, I3C and 1-WIRE. For more details, refer to the section of [Protocol Decoding](#).
- **Digital**: Press this key to enter Digital setting, to set basics, grouping, threshold, bus and label. For more details, refer to the section of [Digital Channel](#).
- **Scale**: Vertical scale rotary knob is used to adjust the vertical scale in the current channel. Turn clockwise to decrease the scale, turn counterclockwise to increase the scale. The amplitude of waveform will increase or decrease with the adjustment and the scale at the



bottom of screen will change in real-time.

The vertical scale is step with 1-2-5, press this rotary knob to adjust the vertical scale between coarse tuning and fine tuning.


- **Position:** Vertical position rotary knob is used to move the vertical position of the waveform in the current channel. Press this rotary knob to move the channel position back to the vertical midpoint.

(2) Horizontal Control




- **Menu:** Horizontal menu key is used to display the horizontal scale, time base mode (XY/YT), horizontal, auto roll, quick roll time base, horizontal position, time base extension and time base selection. For more details, refer to the section of

[Horizontal System](#) for more details.


- **Scale:** Horizontal scale rotary knob is used to adjust all channel time base. During the adjustment, the waveform is compressed or extended in horizontal show on the screen and the horizontal scale value  will change in real-time. The time base is step with 1-2-5, press this rotary knob to adjust the horizontal scale between coarse tuning and fine tuning.

- **Position:** Horizontal position rotary knob is used to move the trigger point to the left or right relative to the center of the screen. During the adjustment, all channel waveforms move to left or right side and the horizontal shift value on the top of the screen




will change in real-time. Press this rotary knob to move the current position back to the horizontal midpoint.

(3) Trigger Control



- **Slope:** Press the Slope key to switch the trigger edge: rising edge, falling edge, or any edge. The corresponding edge's indicator light will illuminate when switching the edge.
- **Menu:** Press the Menu key to enter the trigger menu. For more details, refer to the section of [Triggering System](#).

- **Source:** Press the Source key to switch the trigger source. The panel numbers 1 to 4 correspond to channels C1 to C4. When switching the source, the corresponding number's indicator light will illuminate.


- **Position:** Trigger level rotary knob, turn clockwise to increase the level, turn counterclockwise to decrease the level. During the adjustment, the trigger level  in the top right will change in real-time. When the trigger is single level, press this rotary knob to turn the trigger level to the trigger signal and quickly turn to 50%.
- When the trigger status is READY or TRIGED, the corresponding Ready or Trig'd indicator light in the trigger control area will illuminate.

(4) Control Area



- **Auto/Normal:** Press the Auto/Normal key to switch the oscilloscope trigger mode between Auto and Normal.
- **Run/Stop:** This key is used to set the operating mode of the oscilloscope to "Run" or "Stop".
In the "RUN" state, the key is illuminated in green.
In the "STOP" state, the key is illuminated in red.
- **Force:** When the trigger mode is Normal or Single, press the force trigger key to generate a trigger.
- **Autoset:** After pressing the Autoset key, the oscilloscope automatically adjusts the vertical scale, time base, and trigger mode based on the input signal to display the optimal waveform.
- **Single:** Press the Single key to set the oscilloscope's trigger mode to "Single". The key will illuminate orange.


(5) Measurement Analysis Area



- **Measure:** Press the Measure key to enter the measurement menu, to set the counter, voltmeter, parameter snapshot, measurement statistics, add measurement, clear measurement, and global settings. For more details, refer to the section [Automatic Measurement](#).
- **Cursor:** Press the Cursor key to enter the cursor measurement menu, to set time, voltage, and screen measurement for each source. For more details, refer to the section of [Cursor Measurement](#).
- **Analyze:** Press the Analyze to open the analysis module menu, where the user can access functions such as the voltmeter, counter, power analysis, waveform recording, pass/fail test, and timing analysis.

(6) Multi-function Area



- **Quick:** The quick operation buttons enable the quick saving of pictures, waveform files, and setting files. The format and path for saving will follow the settings configured in the save and load section.
- : Press the Clear key to clear all recalled waveforms and parameter measurement statistics from the screen.
- **Touch/Lock:** Press the Touch/Lock key to disable the touchscreen function; the background light will illuminate. To enable the touchscreen again, press this key once more, and the background light will turn off.
- **Default:** Restore factory settings. Press the Default key to reset all oscilloscope settings to their default values.
- **Multipurpose A:** Multi-function knob A. When a numerical menu is selected in the function popup window, the LED on the multi-function knob will light up, allowing the user to adjust values using the knob.
- **Multipurpose B:** Multi-function knob B. When setting numerical parameters in a text box, the user can rotate this knob to shift the selected digit.


(7) Signal Output Area




- **G1:** Press the G1 key to open the signal source Gen settings menu and select G1. For more details, refer to the section [Function/Arbitrary Waveform Generator \(Gen\)](#).
- **G2:** Press the G2 key to open the signal source Gen settings menu and select G2. For more details, refer to the section [Function/Arbitrary Waveform Generator \(Gen\)](#).

(8) Home Menu



Press the Home icon at the top-right of the screen to open “Home” quick menu, including: measurement, cursor, voltmeter, counter, math, reference, signal source, Bode plot, regional histogram, search, decoding, navigation, recording, marker, FFT, power analysis, pass/fail test, timing analysis, save, display, auxiliary, help, and regional draw. The quick menu key allows the user to quickly enter the corresponding function menu.



5.6. User Interface



1. Display: C1 - C4 waveform measurement window, Ref waveform, and Math waveform.
2. Trigger state icon: TRIGED, AUTO, READY, STOP, ROLL, and SCAN.

3. Horizontal base label: Displays the current horizontal time base, click to enter the horizontal setting menu.
4. Sampling rate and memory depth label: Displays the current sampling rate and memory depth, click to enter the horizontal setting menu.
5. Trigger info label: Displays the trigger information, including the trigger type, source, level, and mode. Click the label to open the 'Trigger Setting' window and adjust the trigger parameters.
6. Function toolbar: Displays the currently added functions in toolbar. Touch an icon to enter the corresponding function menu. A maximum of 9 icons can be displayed.
7. Home menu: Open the function guide menu, click each function key to enter the corresponding menu.
8. Notification: Displays the USB, LAN connection icon, and time. Click this area to open the setting menu. Refer to the Notification section for more details.
 - USB: When the instrument detects a USB is connected, a USB icon is displayed in this area.
 - LAN: When the LAN is successfully connected, the LAN icon is displayed in this area.
 - Time: Displays the current time and allows you to set the system time.
9. Volts/div signal bar: When the volts/div has multiple info box at the bottom of the screen, press this key  ,  to move to left or right and reveal the hidden box.
10. Multi-window display area: If multiple functions are enabled simultaneously, such as XY, Math, and FFT, multiple function windows can be displayed at the same time.
11. Digital channel label: Displays the status of the digital channel switch. Open channels are highlighted. Click to access the digital settings menu.
12. Ref label: Displays the status of Ref1-Ref4 and vertical scale switch. Up to 4 Ref labels can be displayed.
13. FFT label: Displays the status of FFT1-FFT4 switch, vertical scale, sampling rate, and the frequency of each div. Up to 4 FFT labels can be displayed.
14. Math label: Displays the status of M1-M4 switch, vertical scale, and operation type. Up to 4 Math labels can be displayed.
15. Measured result display window: Displays counter, DVM measurement, parameter measurement, and statistical results. This window can be enabled or disabled.
16. Channel label: Displays the status of C1 - C4 switch, vertical scale, impedance, bandwidth limitation, inverse phase, channel coupling, probe attenuation ratio, and vertical bias.
17. Analog channel label: Displays the CH1-CH4 icons. Each channel icon matches the color of its corresponding waveform.

5.7. Touch Screen

MSO5000HD series provides 10.1-inch super capacitive touch screen, multiple point touch control and gesture control. MSO5000HD has an easy operating system with flexible and high-sensitive touch screen features for great waveform display and excellent user experience.

Touch control function includes tap, pinch, drag, and rectangle drawing.

Note: The menu displayed on the screen of the oscilloscope can all use the touch control function.

(1) Tap

Use one finger to slightly tap on an icon or a word on the screen as shown in the following figure.

Tap gestures can be used for:

- Tap the menu display on the screen and then to setup.
- Tap the function icon at the top-right of the screen to open the corresponding function.
- Tap the pop-up numeric keypad to set the parameter.
- Tap the virtual keyboard to set the label name and file name.
- Tap a message to open a close button at the top-right of the screen to close the pop-up window.
- Tap another window displayed on the screen, then proceed with the setup.
- Tap a message to open a help button at the top-right of the screen to open the corresponding function help menu.



Tap Gestures

(2) Pinch

Squeeze two fingers together or separate. Pinch gestures can zoom out or zoom in the waveform. To zoom out the waveform, pinch two fingers together and then slide them apart; to zoom in, spread two fingers apart and then pinch them together, as shown in the following figure.

Pinch gestures can be used for:

- Adjust the horizontal time base of waveform by squeezing in the horizontal direction.
- Adjust the vertical time base of waveform by squeezing in the horizontal direction.




Pinch Gestures

(3) Drag

Use one finger to press and drag the selected item to the aimed position as shown in the following figure.

Drag gestures can be used for:


- Drag the waveform to change the waveform position.
- Drag the window to change the window position.
- Drag the cursor to change the cursor position.




Drag Gestures

(4) Rectangle Drawing

Open the HOME menu and click the icon “Rectangle Drawing” to enable the function, drag your finger to draw a rectangle on the screen as shown in Figure (a), (b), move the finger, a menu will appear on the screen, at this point, “Zone A”, “Zone B”, “Intersection”, “Non-intersect” can be selected. Drag your finger from bottom right to the top left on the screen to draw the trigger area.



(a)



(b)



Rectangle Drawing Gestures

Select “Zone A”:

- Draw zone A
- Open zone A
- Open “Zone Trigger” menu

Select “Zone B”:

- Draw zone B
- Open zone B
- Open “Zone Trigger” menu

Note: Click on “Rectangle Drawing” to step through rectangle drawing and operating waveform mode. Click on “Rectangle Drawing”, if the icon shows , it indicates that “Rectangle Drawing” mode is enabled; if the icon shows , it indicates that “Operating Waveform” mode is enabled.

5.8. Parameter Setting

MSO5000HD series supports use the Multipurpose A (Multipurpose rotary knob) and touch screen to set the parameter. The setting steps are as follows.

(1) Multipurpose Rotary Knob


For the parameter of time and voltage, once the parameter is selected, rotate the Multipurpose A knob on the front panel to enter the parameter value.

(2) Touch Screen

Once the parameter or input field has been selected, double-click to open the virtual keyboard to enter the parameter value, label name, or file name.

a. Enter character string

When naming a file or folder, use the character keyboard to enter a string.



b. Input field

Enter text: input letters, numbers, and special characters, with a maximum length of 255 characters.

c. Clear key

Press the “Clear” key to delete all contents in the input field.

d. Caps key

Press the “Caps” key to switch between upper and lower case.



e. Tab key

Press the “Tab” key to enter 2 spaces at a time.

f. Shift key

Press the “Shift” key to switch among number, special character, upper and lower case.

g. Arrow keys (left, right)

If part of the content needs to be changed, press the “”, “” key to move the cursor to left or right and then to edit the content.

h. Space key

Press the “Space” key to enter one space in the input field.

i. Backspace key

Press the “Backspace” key to delete a single character. This key is used to delete a character when the input field contains a large amount of content.


j. Enter key

Once the content has been entered, press the “Enter” key to confirm the setting and close the virtual keyboard.

(3) Enter Numeric Value

When setting or editing a parameter, use the numeric keypad to enter the numeric value.

1. Click the number or unit to enter.




After entering all the values and selecting the desired units, the numeric keypad will automatically close, completing the parameter setting. Additionally, the user can manually close the numeric keypad by clicking the confirm key, in which case the unit will default to the preset unit. On the numeric keypad, the user can also perform the following operations:

- a. Delete the entered parameter value.
 - b. Set the parameter to the maximum or minimum value (sometimes specifically the maximum or minimum value for the current state).
 - c. Set the parameter to the default value.
 - d. Clear the parameter input field.
 - e. Move the cursor to modify the parameter value.
2. Enter binary, hexadecimal system value

During the decoding trigger, use the numeric keypad to enter binary or hexadecimal values for data and address settings.

Enter Method: Tap to select the number or input field to be edited, and then use the numeric keypad to enter the desired numeric or letter values



- (4) After entering all the values and pressing the Ok button, the numeric keypad will automatically close, completing the parameter setting. Additionally, on the numeric keypad, the user can perform the following operations:
- Move the cursor to modify the parameter value.
 - Set the parameter to the maximum or minimum value (sometimes specifically for the current state).
 - Set the parameter to the default value.
 - Clear the parameter input field.

5.9. Remote Control

MSO5000HD series high-resolution oscilloscopes can communicate with a PC via USB and LAN port for remote control. Remote control is implemented using SCPI (Standard Commands for Programmable Instruments.)

MSO5000HD series has three methods for remote control.

(1) Custom Programming

The user can perform the programming control on the oscilloscope through SCPI (Standard Commands for Programmable Instruments). For detailed descriptions on command and programming, please refer to *MSO5000HD Series High-Resolution Oscilloscopes-Programming Manual*.

(2) PC Software Control (Instrument manager)

The user can use a PC software to remotely control the oscilloscope. The instrument manager can display the oscilloscope screen in real time and control the operation with the mouse. It is recommended to use the PC software provided by UNI-T. It can be downloaded from UNI-T official website (<https://www.uni-trend.com>).

Operating steps:

- Set up the communication between the instrument and a PC.
- Open the instrument manager software and search the instrument source.
- Right-click to open the oscilloscope, operate the instrument manager to remotely control the oscilloscope. Refer to *Instrument Manager-User Manual* for more details. This device supports remote control through communication with a computer via USB, LAN interfaces. Remote control is implemented using the SCPI command set, allowing users to operate and configure the device remotely.

(3) Web Control

Once the network is connected, users can access a web page via the IP address. After logging in with the username and password, they can control the device. The Web Control feature displays the instrument's screen interface in real-time. It supports web access from PCs, smartphones, and iPads, and allows for both internal and external remote control of the device. For more details on logging into Web Control, refer to the "[Web Access](#)" section.


6. Vertical System

- [Open/Activate/Close Analog Channel](#)
- [Vertical Scale](#)
- [Offset](#)
- [Channel Coupling](#)
- [Bandwidth Limit](#)
- [Probe attenuation ratio](#)
- [Inverse Phase](#)
- [Impedance](#)
- [Unit](#)
- [Label](#)

MSO5000HD provides a separate vertical control system for each channel. The setup method of the vertical system for each channel is the same. This chapter introduces the vertical channel setting using C1 as an example.

Access the Channel Setting menu using the following method.

- When the channel is active, tap the Channel label to enter the Channel Setting menu.



6.1. Open/Activate/Close Analog Channel

C1 - C4 analog channels have three states: open, close, and activated.

(1) Open the analog channel

- When an analog channel is turned off, click on the channel key **1** on the front panel to turn on CH1 and the indicator will be illuminated.
- Tap on the channel label at the bottom of the screen to turn on CH1.
- In “Channel Setting” menu, select 'CH1' and set it to ON to turn on CH1, or set it to OFF to turn off CH1.


(2) Close the analog channel

- When CH1 is opened and in the activated state, press the channel key **1** on the front panel or tap on the channel label at the bottom of the screen to turn off CH1.
- When CH1 is opened but not in the activated state. CH1 should be activated at first, and then press the channel key **1** on the front panel or tap on the channel label at the bottom of the screen to turn off CH1.
- Open the “Channel Setting” menu and select “CH1”, set it to OFF to turn off CH1.


(3) Activate the analog channel

When multiple channels are open simultaneously, but only one channel is activated (a channel can only be activated in the open state), the vertical scale, vertical position, and channel settings of the activated channel can be adjusted.


- Press the channel key **1** on the front panel to activate CH1.
- Tap on the channel label at the bottom of the screen to activate CH1.
- Open the “Channel Setting” menu and select “CH1” to activate CH1.



Activated State




Open but not Activated



Off State



6.2. Vertical Scale


The vertical scale represents the voltage value per division in the vertical direction, typically expressed as V/div. When adjusting the vertical scale, the waveform's amplitude will increase or decrease, and the scale displayed in the channel label at the bottom of the screen will update in real-time (as shown in the figure below).



The vertical scale range depends on the currently selected probe and input impedance. The default probe ratio is 1X. When the input impedance is set to 1 MΩ, the vertical scale range is from 500 μV/div to 10 V/div. When the input impedance is set to 50 Ω, the vertical scale range is from 500 μV/div to 1 V/div.

When CH1 is active, adjust the vertical scale using the following steps.

- Use the vertical Scale rotary knob on the front panel to set the vertical scale.
Clockwise: turn clockwise to decrease the vertical scale.
Counterclockwise: turn counterclockwise to increase the vertical scale.
- Tap the screen, use a pinch gesture to adjust the vertical scale.
- Open the “Channel Setting” menu, select CH1, double-click on the “Vertical Scale” menu to open the numeric keypad to enter the vertical scale value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). The user can also adjust the vertical scale value by rotating the Multipurpose A rotary knob, or by clicking the icon ,  on the right.



MSO5000HD series supports vertical adjustment. In the “Channel Setting” menu, the adjustment method can set to “Coarse tuning” or “Fine tuning”. “ON” indicates coarse tuning, “OFF” indicates fine tuning. The default is coarse tuning. Press the vertical Scale rotary knob on the right side of the front panel to toggle between “Coarse tuning” and “Fine tuning”.

- **Coarse tuning:** Click the “Decrease Scale” or “Increase Scale” key on the right side of the vertical scale tab. The vertical time base for all channel waveforms will be adjusted within the allowable range using the 1-2-5 step sequence.
- **Fine tuning:** It adjusts in steps proportional to the difference within the target vertical range. For example, if the current range is 500 mV, when fine-tuning downwards within the range [500 mV, 200 mV], the adjustment step is calculated as: (500-200) mV/ 150; when fine-tuning upwards within the range [500 mV, 1V], the adjustment step is calculated as: (1000-500) mV/ 100.

Fine Tuning Step Calculation

Fine Tuning Range	Step (Take the first range as an example)
1 mV - 2mV, 10 mV - 20 mV, 100 mV - 200 mV, 1 V - 2 V	(2-1) mV / 100
2 mV - 5 mV, 20 mV - 50 mV, 200 mV - 500 mV, 2 V - 5 V	(5-2) mV / 150
5 mV - 10 mV, 50mV - 100 mV, 500 mV - 1 V, 5 V - 10 V	(10-5) mV / 100

Note: Fine adjustment is enabled by default when adjusting the vertical scale via the touch panel.

6.3. Offset

The vertical offset indicates that the offset of the channel signal zero position of a waveform relative to the center of the screen in the vertical direction. When adjusting the vertical offset, the waveform of a channel will move up and down, and the vertical offset in the channel label at the bottom of the screen will change in real time (as shown in the following figure). The range of the vertical offset is related to the current input impedance, probe ratio and the vertical scale.

vertical scale	Offset range
500 μ V/div - 100 mV/div	± 2 V (50 Ω or 1 M Ω)
101 mV/div - 1 V/div	± 5 V (50 Ω)
101 mV/div - 1 V/div	± 20 V (1 M Ω)
1.01 V/div - 10 V/div	± 200 V (1 M Ω)



When CH1 is in the activated state, the vertical offset can be set by the following steps.

- Open the “Channel Setting” menu, enter CH1 tab and Double-click on the “Offset” input field to open the numeric keypad to directly enter the offset value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).
- Click on the “Offset” input field, rotate the Multipurpose B to move the selected cursor, and use Multipurpose A rotary knob to adjust the offset value.

6.4. Channel Coupling


The channel coupling is used to filter out unwanted signals. For example, the measured signal is a

signal containing DC offset.

Click the channel label at the bottom of the screen to open the “Channel Setting” menu, and then click on “Coupling” to select the coupling mode.

- **DC:** When the coupling mode is “DC”, the measured signal containing DC component and AC component can all be passed through.
- **AC:** When the coupling mode is “AC”, the measured signal containing DC component will be blocked.
- **Ground:** When the coupling mode is “Ground”, the measured signal containing DC component and AC component will all be blocked.

Once the channel coupling is set, the channel coupling mode will display in the channel label at the bottom of the screen, as shown in the following figure.



6.5. Bandwidth Limit

The bandwidth limit is used to decrease the noise in the waveform. It is mainly used to reduce high-frequency noise in a signal when observing low-frequency signals. For example, the measured signal is a pulse signal containing high-frequency oscillation.

Click the channel label at the bottom of the screen to open the “Channel Setting” menu, and then click on “Bandwidth Limitation” to select the value of bandwidth limitation. When the bandwidth limitation is enabled, the value of bandwidth limitation will be displayed in the channel label at the bottom of the screen, as shown in the following figure.



MSO5000HD series can set the bandwidth limitation to 20 MHz, FULL and Digital bandwidth.


- **20 MHz:** When the measured signal contains a high-frequency that is greater than 20 MHz, it will be attenuated.
- **FULL:** The measured signal containing the high frequency can be passed through.
- **Digital bandwidth:** A finite impulse response (FIR) filter is used to achieve oscilloscope bandwidth tunability. It can ensure arbitrary amplitude-frequency characteristics while maintaining strictly linear phase-frequency characteristics; its unit sampling response is finite in

length. Digital bandwidth processing, at the back-end of digital signal processing, can filter signals for both UPO and DSO waveform displays. This filter can be widely used in automotive electronics, power supplies, motor testing, and other fields, effectively filtering out noise and interference. The digital bandwidth can be set in the range of 50 Hz to 1 GHz.

6.6. Probe Attenuation Ratio

(1) Probe Ratio

To match the probe's attenuation coefficient, set the probe attenuation ratio in the channel operation menu. For example, with a probe attenuation coefficient of 10:1, the probe attenuates the measured signal by a factor of 10 before it reaches the oscilloscope. Therefore, the probe coefficient in the oscilloscope's channel menu should be set to $\times 10$, meaning the incoming signal will be multiplied by 10 to ensure that the oscilloscope reads the correct voltage. Click the channel tab at the bottom of the screen to open the "Channel Settings" menu. Then, click the "Probe attenuation ratio" drop-down menu to select the appropriate probe attenuation ratio.



Probe attenuation ratio: 0.001X, 0.01X, 0.1X, 1X, 10X, 100X, 1000X, and a custom value.

When the channel unit is set to A, it indicates a current probe, and the probe attenuation ratio can be adjusted to 5 mV/A, 10 mV/A, 50 mV/A, 100 mV/A, 200 mV/A, 5000 mV/A, 1 V/A, or a custom value.

(2) Probe Setting


When the oscilloscope detects a probe with a probe attenuation ratio detection pin (different resistors represent different attenuation ratios), it automatically recognizes the probe's attenuation coefficient, sets the probe attenuation ratio to the matching value, and displays information such as the manufacturer, probe model, serial number, and probe magnification in the probe setup menu.

Click "Probe Setting" to enter the "Probe Setting" menu. In this menu, the user can configure the probe indicator, probe key function, and view the corresponding manufacturer, probe model, serial number, probe magnification, and other related information.

- a. Probe Indicator: Click the "Probe Indicator" to set it to ON or OFF.
- b. Probe Key Function: Click the "Probe Key" drop-down menu to set Run/Stop, Single, or screenshot.

- **Run/Stop:** When you press the active probe key, the oscilloscope status toggles between Run and Stop.
- **Single:** When you press the active probe key, the oscilloscope trigger mode switches to Single.
- **Screenshot:** When you press the active probe key, the oscilloscope automatically takes a screenshot.

6.7. Inverse Phase

Click the channel tab at the bottom of the screen to open the “Channel Setting” menu, and then click on “Inverse Phase” to switch it on or off. When the inverse phase is enabled, an icon  in the channel label will be illuminated.

Inverse phase: ON



When the inverse phase is disabled, the waveform is displayed normally. When the inverse phase is enabled, the waveform voltage will be reversed, and the results of math operation and waveform measurement will also be changed, as shown in the following figure.



Inverse Phase: ON

Inverse Phase: OFF


6.8. Impedance

To reduce the electric load caused by the interaction of the oscilloscope and the circuit to be measured, this oscilloscope provides two input impedance modes: 1 MΩ (default) and 50 Ω. In the “Channel Setting” menu, click on the “Impedance” key to select the input impedance to 1 MΩ or 50 Ω.

- **1 MΩ:** The input impedance of the oscilloscope is extremely high at this time, so the current flowing into the oscilloscope from the measured circuit can be ignored.

- **50 Ω :** Match the oscilloscope to a device with an output impedance of 50 Ω .

The circuit diagram in the “Channel Setting” menu will change with the input impedance, as shown in the following figure.




- The input impedance setting affects the range of the channel's vertical scale and vertical offset.

Note: After the oscilloscope automatically recognizes the probe, the impedance will also be automatically set to the appropriate mode, and the user does not need to set it manually.

6.9. Unit

Click the channel tab at the bottom of the screen to open the “Channel Setting” menu, and then click on the “Unit” to set the unit to “V”, “A”, “W”, or “U”. The default unit is V. When using the current probe, the unit switches to “A”. Once the unit is set, the unit in the channel label and the measurement unit will also be changed.



6.10. Channel Fold

Click the “Channel Fold” to set the channel's waveform state to hide (ON) or display (OFF).


ON: When the “Channel Fold” is set to ON, the channel's waveform is not displayed.

OFF: When the “Channel Fold” is set to OFF, the channel's waveform is not displayed normally.

6.11. Label

The instrument uses the channel number to identify the channel by default, but the user can set a different name for each channel to suit your preferences. For example, CH1.

Click the channel tab at the bottom of the screen to open the “Channel Setting” menu, and then click on “Label” to select display (ON) or not display (OFF) the channel label. The channel label can also be set by double-click on the input field to pop up the virtual keyboard to directly enter the character string. For details on the use of the virtual keyboard, refer to the section of [5.8 Parameter Setting](#).





7. Horizontal System

- [Horizontal Scale](#)
- [Horizontal Extension](#)
- [Auto Roll Mode](#)
- [Fastest Roll Time Base](#)
- [Horizontal Position](#)
- [Time Base Extension](#)
- [XY](#)

Access the Horizontal Control System menu using the following method.

- Press the Menu key to enter “Horizontal” menu.
- Tap the horizontal tab on the top to enter “Horizontal” menu.




7.1. Horizontal Scale



The horizontal scale is also known as the horizontal time base, i.e., the time value represented by each scale in the horizontal direction of the screen, usually expressed as s/div. The range of horizontal scales as shown in the following table. When adjusting the horizontal time base, it changes in step of 1-2-5, i.e. 500 ps/div, 2 ns/div, 5 ns/div...500 s/div, and 1 ks/div.


Model	Range
MSO5104HD	500 ps/div - 1 ks/div
MSO5054HD	500 ps/div - 1 ks/div
MSO5034HD	1 ns/div - 1 ks/div

When the horizontal time base is changed, the waveform of all channels will be horizontally extended or compressed with respect to the currently selected horizontal extension reference (see horizontal extension), and the horizontal time base on the top left will change in real time (as shown in the following figure).







Set the horizontal time base using the following steps.

- Use the horizontal Scale rotary knob on the front panel to set the horizontal scale.
Clockwise: turn clockwise to decrease the horizontal scale.
Counterclockwise: turn counterclockwise to increase the horizontal scale.
- Tap the screen, use a pinch gesture to adjust the horizontal scale.
- Tap the **H (Horizontal Scale)** tab on the top to enter the “Horizontal” menu, double-click on the “Horizontal Scale” input field to open the numeric keypad to directly enter the horizontal scale value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). The user can also adjust the horizontal scale value by rotating the Multipurpose A rotary knob, or by clicking the icon ,  on the right.



MSO5000HD series supports horizontal adjustment. In the “Channel Setting” menu, the adjustment method can set to “Coarse tuning” or “Fine tuning”. “ON” indicates coarse tuning, “OFF” indicates fine tuning. The default is coarse tuning. Press the horizontal Scale rotary knob on the right side of the front panel to toggle between “Coarse tuning” and “Fine tuning”.

- **Coarse tuning:** Click the “ Decrease Scale” or “ Increase Scale” key on the right side of the horizontal scale tab. The horizontal time base for all channel waveforms will be adjusted within the allowable range using the 1-2-5 step sequence.
- **Fine tuning:** Click the “ Decrease Scale” or “ Increase Scale” key on the right side of the horizontal scale tab. The horizontal time base can further adjust all channel waveforms within the allowable range using the 1-2-5 step sequence.

7.2. Horizontal Extension


The horizontal extension refers to the reference position for horizontal extension and horizontal compression when adjusting the horizontal time base. In “Horizontal” menu, select “Horizontal Extension” to set the reference position to “Center”, “Left”, “Right”, or “Trigger point”. The default is “Center”.

- **Center:** When adjusting the horizontal time base, the waveform is expanded or compressed horizontally around the center of the screen.
- **Left:** When adjusting the horizontal time base, the waveform is expanded or compressed horizontally around the far left.
- **Right:** When adjusting the horizontal time base, the waveform is expanded or compressed horizontally around the far right.
- **Trigger point:** When adjusting the horizontal time base, the waveform is expanded or compressed horizontally around the trigger point.


7.3. Auto Roll Mode

Click on the “Auto Roll Mode” menu, set whether to enter SCAN or ROLL when the current time base is slower than the fastest roll time base. It can toggle between “Yes” and “No”.

- **Yes:** When the time base is slower than the fastest roll time base, the oscilloscope will enter the ROLL mode. In this mode, the oscilloscope continuously draws the voltage-time tendency of the waveform on the screen. The waveform is refreshed from right to left and the latest waveform is drawn on the far right.



- **No:** When the time base is slower than the fastest roll time base, the oscilloscope will not enter the ROLL mode and will be in SCAN state. In the SCAN state, the oscilloscope enters the slow sweep mode. When using the slow sweep mode to observe the low-frequency signal, it is recommended that the channel coupling is set to DC. In this mode, the waveform starts from the trigger position, refreshing from left to right, with the latest waveform drawn on the far left.



7.4. Fastest Roll Time Base

The fastest scrolling time base enters the time base mode of ROLL or SCAN, with only a prompt function and does not support setting.

7.5. Horizontal Position


Tap on the “Horizontal Position” input field to change its value. Set the horizontal center as the zero point, the waveform will move to the left if the horizontal position is greater than 0; the waveform will move to the right if the horizontal position is less than 0.


Set the horizontal position using the following steps.

- Click on the “Horizontal Position” input field, rotate the Multipurpose B to move the selected cursor, and use Multipurpose A rotary knob to adjust the position.
Clockwise: turn clockwise to increase the value.
Counterclockwise: turn counterclockwise to decrease the value.
- Rotate the horizontal Position rotary knob to adjust the horizontal position.
Clockwise: turn clockwise to decrease the value.
Counterclockwise: turn counterclockwise to increase the value.
- Double-click on “Horizontal Position” input field to open the numeric keypad to directly enter the value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

7.6. Time Base Extension

The time base extension is used to horizontally enlarge a waveform for examining more details, helping users gain a better understanding of the signal. Follow these steps to enable the window extension.



- Tap the **H** (Horizontal Scale) tab on the top to enter the “Horizontal” menu, select the “Horizontal” menu, click on the “Time Base Extension” option and toggle it ON or OFF.
ON: turns on the time base extension.
OFF: turns off the time base extension.
- Tap the icon  in the top right of the screen to quickly open the time base extension, tap the


icon  to exit the time base extension.

(1) Enlarge Waveform

When the window is extended, the user can adjust the horizontal and vertical position magnification of the waveform in the main window.

Set the magnification using the following steps.

- Double-click on the “Horiz Zoom” and “Vert Zoom” input field on the screen to open the numeric keypad to directly enter the value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).
- Tap “+” or “-” next to “Horiz Zoom” and “Vert Zoom” input field on the screen to increase or decrease the numeric value.
- Click to select “Horiz Zoom” and “Vert Zoom” input field, use the [Multipurpose A](#) rotary knob to adjust the value.
- Drag the four borders of the magnified area in the main window to define the region of the waveform to be enlarged.



(2) Waveform before Enlarged

The enlarged waveform, displayed with a shadow in the upper part of the screen, can be moved using the horizontal [Position](#) rotary knob or zoomed in and out by adjusting the horizontal [Scale](#) rotary knob.

(3) Waveform after Enlarged

The horizontally enlarged waveform is displayed in the lower part of the screen, and the window extension improves the resolution relative to the main time base.

Note: The window extension is only available when the horizontal time base is set to the fastest roll time base. When the time base extension is enabled in ROLL mode, the main time base will default to the fastest roll time base.

7.7. XY

The waveform displayed in XY mode is also known as a Lissajous curve. XY mode supports cursor measurements, allowing for quick measurement of the phase difference between two signals.

- (1) Time Base Format
 - a. YT: Displays the voltage value on the time base (horizontal scale).
 - b. XY: Displays Lissajous curve, it can easily measure the phase difference between two signals with same frequency.
- (2) Display: When XY mode is enabled, the channel waveform and XY curve are displayed in a split screen by default.
- (3) Source X - Y:


Set the waveform to generate a Lissajous curve, which can be selected from C1-C2, C1-C3, C1 - C4, C2-C3, C2-C4, or C3-C4.

If "X-Y" is set to C1-C2, input the CH1 signal on the horizontal axis (X) and the CH2 signal on the vertical axis (Y).

If "X-Y" is set to C1-C2, input the CH1 signal on the horizontal axis (X) and the CH2 signal on the vertical axis (Y).

In XY mode, when CH1 or CH3 is active, use the vertical Position rotary knob to move the XY curve horizontally. When CH2 or CH4 is active, use the vertical Position rotary knob to move the XY curve vertically.

The amplitude of each channel can be adjusted using the vertical Scale rotary knob. The time base can be adjusted using the horizontal Scale rotary knob to improve the display of the Lissajous curve. The waveform in XY mode is shown in the following figure.



In this state, set the menu to display in split screen, and press the **Cursor** key, as shown in the following figure.



When XY mode is enabled, the cursor supports both time and voltage measurements. For time measurement, the cursor is displayed in the waveform window, and the user can move it only within the waveform window. For voltage measurement, the cursor is displayed in the XY window. Refer to the [Cursor Measurement](#) section for details on time and voltage cursor usage.


Cursor ①: Time, rectangular coordinates, polar coordinates, product, and ratio.

Cursor ②: Time, rectangular coordinate, polar coordinates, product, and proportion.

Δ : Delta (numerical difference between two cursors).


Application of XY mode

The phase difference between the two signals with the same frequency can be easily observed through Lissajous curve. The following figure explains a schematic diagram for observing the phase difference.



Based on $\sin\theta = A/B$ or C/D , where θ is the phase angle between the channels (with A, B, C, and D defined in the figure above), the phase angle can be calculated as $\theta = \pm \arcsin(A/B)$ or $\theta = \pm \arcsin(C/D)$. If the major axis of the ellipse is in the I or III quadrant, then the resulting phase angle should be in the I or IV quadrant, i.e., within $(0 - \pi/2)$ or $(3\pi/2 - 2\pi)$. If the major axis of the ellipse is in the II or IV quadrant, then the phase angle should be within $(\pi/2 - \pi)$ or $(\pi - 3\pi/2)$.

Additionally, if the frequency or phase difference between the two signals is an integer multiple, calculate the frequency and phase relationship between the two signals based on the following figure.



8. Triggering System

- [Noun Explanation of Triggering System](#)
- [Edge Triggering](#)
- [Pulse Width Triggering](#)
- [Video Triggering](#)
- [Slope Triggering](#)
- [Runt Pulse Triggering](#)
- [Over-amplitude Triggering](#)
- [Delay Triggering](#)
- [Timeout Triggering](#)
- [Duration Triggering](#)
- [Setup & Hold Triggering](#)
- [Nth Edge Triggering](#)
- [Code Pattern Triggering](#)
- [Extreme Value Triggering](#)
- [RS232 Triggering](#)
- [I²C Triggering](#)
- [SPI Triggering](#)
- [CAN Triggering](#)
- [CAN-FD Triggering](#)
- [CAN - XL Triggering](#)
- [LIN Triggering](#)
- [FlexRay Triggering](#)
- [Audio Triggering](#)

- [1553B Triggering](#)
- [Manchester Triggering](#)
- [SENT Triggering](#)
- [ARINC429 Triggering](#)
- [1 - WIRE Triggering](#)
- [I3C Triggering](#)
- [Zone Triggering](#)

Triggering refers to setting a condition that must be met for the oscilloscope to capture and display a waveform. When the waveform meets the specified trigger condition, the oscilloscope captures the waveform and its adjacent part, displaying it on the screen. While the oscilloscope continuously captures waveforms during operation, only those that meet stable trigger conditions will be displayed.

The trigger ensures that each time base sweep or acquisition starts from a defined condition, synchronizing each scan with the acquisition. This synchronization ensures that the acquired waveforms overlap and provide a stable display.

Trigger settings determine when the oscilloscope acquires and displays data based on the characteristics of the input signal. For example, setting the trigger to activate on the rising edge of the analog channel 1 input signal enables the user to capture the desired waveform more efficiently. Understanding the signal under test is crucial for quickly acquiring the desired waveform.

MSO5000HD series offers several advanced trigger types, including various serial bus triggers. This chapter describes each trigger type in detail.


Advanced protocol triggered decoding supports the models and standards listed in the table below:

Option Name	Description	Models	Standard/Option
Computer serial bus triggering and analysis	RS - 232/422/485/UART	MSO5000HD Series	Standard
Embedded serial bus triggering and analysis	I ² C, SPI	MSO5000HD Series	Standard
Automobile serial bus triggering and analysis	CAN, LIN	MSO5000HD Series	Standard
Automobile serial bus triggering and analysis	CAN-FD, CAN - XL	MSO5000HD Series	Option

Automobile serial bus triggering and analysis	FlexRay	MSO5000HD Series	Option
Automobile sensor bus triggering and analysis	SENT	MSO5000HD Series	Option
Audio serial bus triggering and analysis	Audio, LJ, RJ, TDM, I3C	MSO5000HD Series	Option
Aerospace serial bus triggering and analysis	MIL - STD - 1553, ARINC 429	MSO5000HD Series	Option
Wireless communication trigger and analysis	Manchester	MSO5000HD Series	Option
Sensor & RFID	1-WIRE	MSO5000HD Series	Option

Follow the steps below to access the “Trigger” menu.

- Press the **Menu** key on the front panel to enter the “Trigger Setting” menu.
- Tap the T trigger label on the top (as shown in the following figure) to enter the “Trigger Setting” menu.



8.1. Noun Explanation of Triggering System

(1) Trigger Source

A signal is used to generate a trigger. The trigger can be obtained from various sources, such as analog channels (C1 - C4), digital signals (D0 - D15), an external trigger (EXT), or mains electricity.


- a. Select any of the analog signal input ports C1 - C4 on the front panel of the oscilloscope as the trigger signal.
- b. When a digital signal is connected and the digital channels are enabled, select any of the digital channels as the trigger signal.
- c. Select the EXT Trig input signal on the rear panel of the oscilloscope as the trigger signal. For example, the user can input an external clock signal to EXT Trig and set it as the trigger source. The EXT trigger level can be set within the range of -9 V to +9 V.
- d. Mains electricity: This source is used to observe signals related to mains electricity, such as the relationship between lighting equipment and power supply equipment, to achieve stable synchronization.

Press the trigger **Menu** soft key on the front panel or tap the T trigger label at the top to open the "Trigger" menu, tap "Source" to set the trigger source.

(2) Trigger Mode

The trigger mode is used to determine how the oscilloscope behaves during the trigger condition. The following is a brief introduction to the trigger acquisition process of the oscilloscope through the pre-trigger buffer and the post-trigger buffer.

When the oscilloscope is operating, the pre-trigger buffer is filled first, continuously storing data as the system searches for a trigger event. The data is transferred to the pre-trigger buffer in a FIFO (First In, First Out) manner. Once a trigger event is detected, the pre-trigger buffer contains data captured before the trigger. The oscilloscope then proceeds to fill the post-trigger buffer with the data captured after the trigger and displays the sampled waveform.



This oscilloscope provides three trigger modes: auto, normal, and single. Set the trigger mode using the following steps.

- Press the Mode soft key in the trigger area on the front panel to switch between the trigger modes.
- Press the Menu softkey in the trigger area on the front panel or tap the T trigger label at the top to open the “Trigger” menu to select the desired trigger mode.
 - a. Auto: In Auto mode, when no trigger signal is detected, the oscilloscope will automatically collect and display data. Once a trigger signal is generated, the oscilloscope will automatically switch to sweep mode, ensuring signal synchronization. The auto mode is suitable for the following condition.
 - Checking DC signal or a signal with unknown electric feature.

Note: In auto mode, the oscilloscope can operate at 50 ms/div or slower when no trigger signal is detected in ROLL mode.
 - b. Normal: The oscilloscope collects waveforms only when the trigger condition is met. If no trigger signal is detected, the oscilloscope will stop collecting data and enter a wait state. When the trigger condition is satisfied, the oscilloscope refreshes the waveform on the screen; otherwise, it retains the last triggered waveform. The normal mode is suitable for the following conditions.
 - Only collect the specified event appointed by the trigger setting.
 - A rare trigger event. The normal mode can prevent the oscilloscope from

automatically triggering, so that the waveform can be displayed stably.

- c. Single: In the single trigger mode, press the **Single** key on the front panel clears the waveform on the screen, and the oscilloscope enters a wait state. When a trigger is detected, the oscilloscope samples and displays the waveform, then enters the STOP state. Press the **Single** key again, the waveform on the screen will be deleted and the oscilloscope will quickly enter the single mode.

The single mode is suitable for the following conditions.

- Capture a single event by accident or non-periodic signal, such as rising or falling waveforms.
- A rare trigger event.

(3) Trigger Coupling


Trigger coupling determines which part of the signal will be transmitted to the trigger circuit. This setting is available only when the edge trigger is selected, and the trigger source is an analogue channel.

Press the **Menu** softkey on the front panel or tap the T trigger label at the top to enter the "Trigger" menu. Click on the "Trigger Coupling" to select the desired trigger coupling mode (Default: DC).


- a. DC: Passes all DC and AC components of the signal.
- b. AC: Blocks the DC component of the signal.
- c. HF reject: Attenuates high-frequency components above 40 kHz.
- d. LF reject: Attenuates low-frequency components below 40 kHz.

(4) Trigger Level

Trigger level is used to set the edge position of trigger point, and the trigger level is related to the trigger source.

- When the trigger source is C1 - C4, rotate the **Position** rotary knob on the right to adjust the trigger level. If the trigger window is opened, tap on the trigger level and then rotate the **Multipurpose A** rotary knob to adjust the trigger level; or double-click on the "Trigger Level" input field to open the virtual keyboard to set the trigger level. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). During this process, a trigger level line (the color is consistent with the channel color) and a trigger icon  will appear on the screen, this line will move up and down according to the change of trigger level. Once the adjustment is stopped, the trigger level line will disappear after 2 seconds. The current trigger level is displayed in the trigger label on the screen.


For runt-amplitude trigger, ramp trigger and over-amplitude trigger, high level and low

level must be set. If the trigger window is opened, tap on “High” or “Low” and rotate the Multipurpose A rotary knob to set the high or low level; or open the virtual keyboard to set the trigger level. Two trigger level icons  are displayed on the right.

- When the trigger source is AC Line, it has no trigger level.
- When the trigger source is EXT, rotate the Position rotary knob on the right to adjust the trigger level; If the trigger window is opened, tap on the trigger level and then rotate the Multipurpose A rotary knob to adjust the trigger level; or double-click on the “Trigger level” input field to open the virtual keyboard to set the trigger level. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). The current trigger level is displayed in the trigger label on the screen. For this trigger source, only the trigger level change is displayed, but no trigger level line.

(5) Trigger Holdoff

Trigger holdoff is used to stabilize the display of complex or overlapping waveforms, such as pulse trains with multiple edges or events. It specifies the amount of time the oscilloscope waits before restarting the trigger circuit after a trigger condition is met. During the trigger holdoff, even if the trigger condition is met, the oscilloscope will not trigger until the end of holdoff time. For example, a set of pulse trains that require triggering on the first pulse of the train, then the holdoff time can be set to the width of the pulse train.



Press the Menu softkey on the front panel or tap the T trigger label at the top to enter the “Trigger” menu. Click on the “Trigger Holdoff” input field to open the numeric keypad to set the

trigger holdoff time (until the waveform is stably triggered, the default is 80 ns). For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, rotate the Multipurpose A rotary knob on the front panel to set the trigger holdoff time. The adjustable ranges from 0 s to 10 s.

(6) Noise Rejection

Noise rejection is used to attenuate the high-frequency noise in a signal, to reduce the error trigger probability of the oscilloscope. Press the Menu softkey on the front panel or tap the T trigger label at the top to enter the “Trigger” menu. Click on the “Noise Rejection” to toggle it ON or OFF.

(7) Trigger Sensitivity

When noise is present in the signal, check the trigger sensitivity and adjust it as needed. Adjusting the trigger sensitivity changes the probability of noise triggering the system. The adjustable range is from 0% to 100%.

(8) Force Trigger

Press the Force key to manually generate a trigger signal.

If the waveform is not displayed on the screen in the “Normal” or “Single” mode, press the Force key to collect the signal baseline, allowing you to confirm that the acquisition is functioning normally.

(9) Pre-trigger/Delay Trigger

The sampled data before trigger event/post-trigger event.

Trigger position is usually set at the horizontal center of the screen. The user can observe 5 grids of pre-trigger and delay information. The user can move the waveform horizontally to view more pre-trigger information. By observing the pre-trigger data, the waveform before generated can be observed. For example, capturing the glitch at the start of the circuit, observing and analyzing the pre-trigger data to find out the cause of the glitch.


8.2. Edge Triggering

The edge can be identified by looking for the specified edge (rising edge, falling edge, and rising & falling edge) and electrical level. Press the edge trigger menu to set the source, trigger coupling, trigger mode, edge type, and trigger level. A stable waveform can be generated when the condition is satisfied.

Press the Menu softkey on the front panel or tap the T trigger label at the top to enter the “Trigger” menu. Click on the “Edge Trigger” to set.

(1) Trigger Type

Press the **Menu** softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Edge” to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Source

Click on the “Source” to select C1 - C4, main electricity, EXT, or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label on the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Trigger Coupling

Click on the “Trigger Coupling” to select DC, AC, LF reject, or HF reject. For more details on *Trigger Coupling*, refer to the section [Noun Explanation of Triggering System](#).

(5) Edge Type

Select a signal and specify the edge on which to trigger. The current edge type will be displayed in the trigger label at the top of the screen.

- a. Rising edge: Set a signal to trigger on the rising edge.
- b. Falling edge: Set a signal to trigger on the falling edge.

c. Arbitrary edge: Set a signal to trigger on both the rising and falling edges.

(6) Trigger Level


Tap to select “Level”, the trigger level can be changed by using the [Multipurpose A](#), trigger [Position](#) rotary knob, and the numeric keypad on the front panel. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).

8.3. Pulse Width Triggering

Pulse width triggering sets the oscilloscope to trigger on the specified width and a positive or negative pulse meets the judgment conditions. The pulse width triggering menu can set the source, trigger condition, the upper/lower limit, polarity (positive/negative pulse width trigger), trigger type, trigger mode, and trigger level.

(1) Trigger Type

Press the [Menu](#) softkey in the trigger area on the front panel or tap the T trigger label at the top to enter the “Trigger” menu. Tap on the “Trigger Type” to select “Pulse Width”.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Source

Click on the “Source” to select C1 - C4, main electricity, EXT, or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source

is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Trigger Condition

- a. $>$: When the pulse width of the trigger signal (positive pulse width, negative pulse width) is greater than the set pulse width, the lower limit can be set.
- b. $<$: When the pulse width of the trigger signal (positive pulse width, negative pulse width) is less than the set pulse width, the upper limit can be set.
- c. $\leq \geq$: When the pulse width of the trigger signal (positive pulse width, negative pulse width) is the same as the set pulse width or the pulse width of the trigger signal is triggered within the set range, the upper and lower limit can be set.

(5) Upper/Lower Limit

The set pulse width is compared to the pulse width of the trigger signal. The oscilloscope will be generated when the trigger condition is met. The adjustable range is from 800 ps to 4 s.

- When the trigger condition is set to “ $>$ ” or “ $<$ ”, click on the input field of the lower limit or upper limit to open the numeric keypad to set the lower or upper limit. Alternatively, rotate the Multipurpose A rotary knob on the front panel to adjust the lower or upper limit.
- When the trigger condition is set to “ $\leq \geq$ ”, click on the input field of the lower limit or the upper limit to open the numeric keypad to set the lower or upper limit. Alternatively, rotate the Multipurpose A rotary knob on the front panel to adjust the lower or upper limit. The lower limit must be less than or equal to the upper limit.

(6) Level

Tap to select “Level”, the trigger level can be changed by using the Multipurpose A, trigger Position rotary knob, and the numeric keypad on the front panel. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).

8.4. Video Triggering

The video signal includes the image and the timing information. It has multiple standards and formats. MSO5000HD can be triggered on the field or line of the standard video signal, i.e. NTSC (National Television Standards Committee), PAL (Phase Alternating Line), and SECAM (Sequential Couleur A Memoire).

(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Video Trigger”

to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Source

Click on the “Source” to select C1 - C4. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Video Format

Click on the “Video Format” to select from the following options.

- PAL: The frame frequency is 25 frames per second, the TV scan line is 625 lines, the odd field is in the front and the even field is in the rear.
- NTSC: The field frequency is 60 fields per second, and the frame frequency is 30 frames per second. The TV scan line is 525 lines. The even field is in the front and the odd field is in the rear.
- SECAM: The frame frequency is 25 frames per second, the TV scan line is 625 lines, interlaced scanning.

Video Format	Frame Frequency (Frame)	Sweep Type	TV Scan Line (Line)
NTSC	30	Interlaced scanning	525
PAL/SECAM	25	Interlaced scanning	625
525 p/60	60	Progressive scanning	525
625 p/50	50	Progressive scanning	625
720 p/24	24	Progressive scanning	750
720 p/25	25	Progressive scanning	750
720 p/30	30	Progressive scanning	750
720 p/50 Hz	50	Progressive scanning	750
720 p/60 Hz	60	Progressive scanning	750
1080 p/24 Hz	24	Progressive scanning	1125
1080 p/25 Hz	25	Progressive scanning	1125
1080 p/30 Hz	30	Progressive scanning	1125
1080 i/25 Hz	25	Progressive scanning	1125
1080 i/30 Hz	30	Progressive scanning	1125
1080 Psf/24	24	Progressive scanning	1125

(5) Sync (Synchronization)

Synchronization can be set to even field, odd field, full field, all lines, or specified lines.

- a. Even field: Triggered on the rising edge of the first sawtooth pulse in the even field. This option is available only for NTSC and PAL/SECAM video formats.
- b. Odd field: Triggered on the rising edge of the first sawtooth pulse in the odd field. This option is available only for NTSC and PAL/SECAM video formats.

- c. Full field: Triggered on the rising edge of the first pulse in the vertical synchronization interval.
- d. All lines: Triggered and synchronized on the first line of the video signal.
- e. Specified lines: Triggered and synchronized on the specified lines. The line number can be set using the [Multipurpose A](#) rotary knob. The line number range depends on the video format: 1-525 (NTSC), 1-625 (PAL/SECAM), 1-525 (525p), 1-625 (625p), 1-750 (720p), and 1-1125 (1080p/1080i).

(6) Level

Tap to select “Level”, the trigger level can be changed by using the [Multipurpose A](#), trigger [Position](#) rotary knob, and the numeric keypad on the front panel. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).

Note: To observe detailed waveforms in the video signal, increase the memory depth.


MSO5000HD series incorporates UNI-T's proprietary digital 3D technology, featuring a multi-level greyscale display. This allows varying brightness levels to indicate the frequency of different signal components, helping experienced users quickly assess signal quality and identify anomalies during debugging.

8.5. Slope Triggering

Slope triggering refers to triggering on the rising or falling edge within a specified time, making it suitable for observing sawtooth and triangular waves. The slope trigger menu allows you to configure the source, trigger mode, edge type (rising or falling), slope condition, upper and lower time limits, and high and low levels.

(1) Trigger Type

Press the [Menu](#) softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Slope Trigger” to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Source

Click on the “Source” to select C1 - C4. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Edge Type

Select the slope trigger edge to rising edge or falling edge.


- Rising edge: Uses the rising edge of a trigger signal to perform the slope trigger.
- Falling edge: Uses the falling edge of a trigger signal to perform the slope trigger.

(5) Time Condition

- >: When the slope time of the trigger signal (positive pulse width, negative pulse width) is greater than the set slope time, the lower limit of time can be set.
- <: When the slope time of the trigger signal (positive pulse width, negative pulse width) is less than the set slope time, the upper limit of time can be set.
- $\leq \geq$: When the slope time of the trigger signal (positive pulse width, negative pulse width) is the same as the set slope time or triggered within the set slope time, the lower and upper

limit of time can be set.

Note: The slope time of the trigger signal refers to both the **slope time of the rising edge** and the **slope time of the falling edge**, as illustrated in the figure below.



(6) High/Low Level

The slope trigger requires the high level and low level to be set. The slope trigger can only be stable generated when all conditions are met.

Tap to select “High Level” or “Low Level”, the high level and low level can be changed by using the Multipurpose A or the numeric keypad on the front panel or pressing the trigger level Position rotary knob on the right side of the front panel to switch the selected level. The selected level is displayed as in solid line. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).

Correlation: Tick the correlation, i.e. if one level changes, the other will also change.

(7) Lower/Upper Limit of Time

- When the trigger condition is “>” or “<”, click on the input field of the lower limit or the upper limit to open the numeric keypad to set the lower or upper limit of time. Alternatively, rotate the Multipurpose A rotary knob on the front panel to adjust the lower or upper limit of time.
- When the trigger condition is “≤ ≥”, click on the input field of the lower limit or the upper limit to open the numeric keypad to set the lower or upper limit of time. Alternatively, rotate the Multipurpose A rotary knob on the front panel to adjust the lower or upper limit of time, the lower limit of time must be less than or equal to the upper limit of time. The time range can be set from 400 ps to 1 s.

Note: The set slew rate is displayed at the bottom left of the screen.

The formula for calculating the slew rate: **(High level threshold - low level threshold) ÷ Time**


In this formula, "Time" refers to the set slope time.

8.6. Runt Pulse Triggering

The runt pulse triggering is used to trigger a pulse that has crossed one trigger level but not the

other.


In this oscilloscope, the positive runt pulse is the pulse that crosses the lower limit of the trigger level but does not cross the upper limit of the trigger level; the negative runt pulse is the pulse that crosses the upper limit of the trigger level but does not cross the lower limit of the trigger level, as shown in the following figure.



The runt trigger menu can set the source, trigger mode, polarity (positive, negative), runt condition (irrelevance, $<$, $>$, \leq , \geq), the lower/upper limit of time, and high/low level.

(1) Trigger Type

Press the **Menu** softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Runt Trigger” to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Source

Click on the “Source” to select C1 - C4. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Polarity

- a. Positive: Triggered on the positive runt pulse.
- b. Negative: Triggered on the negative runt pulse.

(5) Runt Condition

- a. $>$: When the runt pulse width is greater than the lower limit of the set pulse width, the lower limit of time can be set.
- b. $<$: When the runt pulse width is less than the upper limit of the set pulse width, the upper limit of time can be set.
- c. $\leq \geq$: When the runt pulse width is equal to the lower or upper limit of time, the upper and lower limit of time can be set at the same time.
- d. Irrelevance: The runt pulse width is not compared to the time.

(6) High/Low Level

The runt plus trigger requires the high level and low level to be set. The runt plus trigger can only be stable generated when all conditions are met.

Tap to select “High Level” or “Low Level”, the high level and low level can be changed by using the [Multipurpose A](#) or the numeric keypad on the front panel. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).

Correlation: Tick the correlation, i.e. if one level changes, the other will also change.

(7) Lower/Upper Limit of Time

- When the trigger condition is “ $>$ ” or “ $<$ ”, click on the input field of the lower limit or the upper limit to open the numeric keypad to set the lower or upper limit of time. Alternatively, rotate the [Multipurpose A](#) rotary knob on the front panel to adjust the lower or upper limit of time.
- When the trigger condition is “ $\leq \geq$ ”, click on the input field of the lower limit or the upper limit to open the numeric keypad to set the lower or upper limit of time. Alternatively, rotate the [Multipurpose A](#) rotary knob on the front panel to adjust the lower or upper limit of time, the lower limit of time must be less than or equal to the upper limit of time. The time range can be set from 3.2 ns to 10 s.


8.7. Over-amplitude Pulse Triggering

The over-amplitude pulse trigger has both a high level and a low level. The oscilloscope will Triggers when the rising edge of the input signal crosses the high level or the falling edge crosses the low level, as shown in the following figure.

The over-amplitude pulse trigger menu can set the source, trigger mode, over-amplitude type (rising edge, falling edge, and arbitrary edge), trigger position (enter, exit, and time), over-amplitude time, and high/low level.

(1) Trigger Type

Press the **Menu** softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Over-amplitude Pulse Trigger” to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Source

Click on the “Source” to select C1 - C4. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Over-amplitude Type

Set the input signal to trigger on the specified edge type, which can be rising, falling, or arbitrary edge. The current over-amplitude type is displayed at the top-right of the screen of the screen.

- a. Rising edge: Triggered on the rising edge of the input signal when the voltage level exceeds the set high level.
- b. Falling edge: Triggered on the falling edge of the input signal when the voltage level falls below the set low level.
- c. Arbitrary edge: Triggered on any edge of the input signal when the voltage level meets the set high or low level.

(5) Trigger Position

The trigger position can be set to enter, exit, or time. It is helpful to further confirm the trigger time.

- a. Enter: Triggered when the input signal crosses the specified trigger level.
- b. Exit: Triggered when the input signal crosses out of the specified trigger level.
- c. Time: Triggered when the accumulated hold time of the over-amplitude exceeds or equals the preset over-amplitude time.

(6) Over-amplitude Time

If the trigger position is “Time” and the over-amplitude time is available, the oscilloscope will be generated when the condition is met. Click on the “Over-amplitude” input field to open the numeric keypad to set the over-amplitude time. Alternatively, rotate the Multipurpose A rotary knob on the front panel to set the over-amplitude time.

The over-amplitude time can be set from 3.2 ns to 10 s.

(7) High/Low Level

The over-amplitude trigger requires the high level and low level to be set. The over-amplitude trigger can only be stably generated when all conditions are met.


Tap to select “High Level” or “Low Level”, the high level and low level can be changed by using the Multipurpose A or the numeric keypad on the front panel. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).

Correlation: Tick the correlation, i.e. if one level changes, the other will also change.

8.8. Delay Triggering

Delay triggering requires configuring both Trigger Source 1 and Trigger Source 2. When the time difference (ΔT) between the edge set by source 1 (Edge 1) and the edge set by source 2 (Edge 2)

meets the preset time limit, the oscilloscope will be triggered, as shown in the following figure.




Edge 1 is set as the rising edge. Edge 2 is set as the falling edge. ΔT is the area marked in red.

Note: Edge 1 and edge 2 must be adjacent edges.

Note: Only the channel that has a connected signal and to be the trigger source can be triggered stably.

(1) Trigger Type

Press the **Menu** softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Delay Trigger” to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Source 1

Click on the “Source 1” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Edge 1

Click on the “Edge 1” to set the delay trigger for “Source 1”, it can be set to rising or falling edge.

(5) Source 2

Click on the “Source 2” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(6) Edge 2

Click on the “Edge 2” to set the delay trigger for “Source 2”, it can be set to rising or falling edge.

(7) Delay Condition

- a. $>$: The oscilloscope will be generated when the time difference (ΔT) between the edge of source 1 and the edge of source 2 is greater than the set lower limit of time, and the lower limit of time can be set.
- b. $<$: The oscilloscope will be generated when the time difference (ΔT) between the edge of source 1 and the edge of source 2 is greater than the set upper limit of time, and the upper limit of time can be set.
- c. $\leq \geq$: The oscilloscope will be generated when the time difference (ΔT) between the edge of source 1 and the edge of source 2 is greater than or equal to the set lower limit of time and less than or equal to the set upper limit of time, and the upper/lower limit of time can be set.
- d. $> <$: The oscilloscope will be generated when the time difference (ΔT) between the edge of source 1 and the edge of source 2 is less than the set lower limit of time or greater than the set upper limit of time, and the upper/lower limit of time can be set.

(8) Lower/Upper Limit of Time

- When the trigger condition is “ $>$ ” or “ $<$ ”, click on the input field of the lower limit or the upper limit to open the numeric keypad to set the lower or upper limit of time. Alternatively, rotate the [Multipurpose A](#) rotary knob on the front panel to adjust the lower or upper limit of time.


- When the trigger condition is " \leq " or " \geq ", click on the input field of the lower limit or the upper limit to open the numeric keypad to set the lower or upper limit of time. Alternatively, rotate the Multipurpose A rotary knob on the front panel to adjust the lower or upper limit of time, the lower limit of time must be less than or equal to the upper limit of time. The time range can be set from 3.2 ns to 10 s.

(9) Level 1, Low-level 2

The delay trigger requires both trigger source 1 and trigger source 2 to be set. It will only be generated when all conditions are met. The level can be adjusted using the Multipurpose A rotary knob or the numeric keypad on the front panel. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).


8.9. Timeout Triggering

The oscilloscope will be triggered when the time interval (ΔT) from the rising edge (or falling edge) of the input signal across the trigger level and to the adjacent falling edge (rising edge) across the trigger level is greater than the set timeout time, as shown in the following figure.



(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the "Trigger" menu. Tap "Trigger Type" to open the dropdown menu, then select "Timeout Trigger" to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Edge Type

Select the edge type on which the input signal will trigger. The current edge type is displayed in the trigger label at the top of the screen.

- Rising edge: Counts the time when the rising edge of the input signal crosses the trigger level.
- Falling edge: Counts the time when the falling edge of the input signal crosses the trigger level.
- Arbitrary edge: Counts the time when either the rising or falling edge of the input signal crosses the trigger level.

(5) Timeout

Timeout is used to set the maximum hold time after the input signal across the trigger level. The

oscilloscope will be generated when $\text{timeout} < \Delta T$. Click on the "Timeout" input field to open the numeric keypad to set the timeout. Alternatively, rotate the Multipurpose A rotary knob on the front panel to adjust the timeout.


The timeout range can be set from 3.2 ns to 10 s.

(6) Level

Tap to select "Level", the trigger level can be changed by using the Multipurpose A, trigger Position rotary knob, and the numeric keypad on the front panel. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).


8.10. Duration Triggering

When the duration triggering is selected, the oscilloscope identifies the trigger condition by looking for the duration of the specified codes. The code pattern is the combination of channel logic "AND", and the value of each channel can be H (high), L (low), or X (ignore). The oscilloscope will be generated when the duration (ΔT) of the code pattern meets a preset time, as shown in the following figure.



(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the "Trigger" menu. Tap "Trigger Type" to open the dropdown menu, then select "Duration Trigger" to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Code Pattern

The code pattern can be set to H, L, or X. The code pattern for each channel is displayed at the bottom of the screen, as shown in the figure above.

- H: Set the code pattern for the selected channel to “High”, i.e. the voltage level is higher than the trigger level of the channel.
- L: Set the code pattern for the selected channel to “Low”, i.e. the voltage level is lower than the trigger level of the channel.
- X: Set the code pattern for the selected channel to “X”, i.e. the channel is not part of the code pattern. The oscilloscope will not be triggered if all channel in the code pattern is set to “X”.

(5) Trigger Condition

- a. $>$: The oscilloscope will be generated when the duration is greater than the set lower limit of time, and the lower limit of time can be set.
- b. $<$: The oscilloscope will be generated when the duration is less than the set upper limit of time, and the upper limit of time can be set.
- c. $\leq \geq$: The oscilloscope will be generated when the duration is less than or equal to the set upper limit of time and greater than or equal to the lower limit of time, and the upper/lower limit of time can be set.

(6) Lower/Upper Limit of Time


- When the trigger condition is “ $>$ ” or “ $<$ ”, click on the input field of the lower limit or the upper limit to open the numeric keypad to set the lower or upper limit of time. Alternatively, rotate the Multipurpose A rotary knob on the front panel to adjust the lower or upper limit of time.
- When the trigger condition is “ $\leq \geq$ ”, click on the input field of the lower limit or the upper limit to open the numeric keypad to set the lower or upper limit of time. Alternatively, rotate the Multipurpose A rotary knob on the front panel to adjust the lower or upper limit of time, the lower limit of time must be less than or equal to the upper limit of time. The time range can be set from 3.2 ns to 10 s.

(7) Level

Tap to select “Level”, the trigger level can be changed by using the Multipurpose A, trigger Position rotary knob, and the numeric keypad on the front panel. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).


8.11. Setup & Hold Triggering

The setup/hold triggering requires the data signal line and clock signal line to be set. The setup time begins when the data signal crosses the trigger level and ends when the specified clock edge arrives. The hold time begins when the specified clock edge arrives and ends when the data signal crosses the trigger level again (as shown in the following figure). The oscilloscope will be triggered when the setup time or the hold time is less than the pre-set time. It is mainly used to locate and find the error code, and quickly find the signal that cannot meet setup and hold time.



(1) Trigger Type

Press the **Menu** softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Setup & Hold” to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Data Source

Click on the “Data Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as

the trigger source.

(4) Data Type

Select the valid code pattern for the data signal. It can be set to H or L.

- a. H: Sets the valid code pattern for the data signal to a high level.
- b. L: Sets the valid code pattern for the data signal to a low level.

(5) Clock Source

Click on the “Clock Source” to select C1 - C4. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(6) Edge Type

- a. Rising edge: Sets the clock edge to the rising edge.
- b. Falling edge: Sets the clock edge to the falling edge.

(7) Trigger Condition

- a. Setup: The oscilloscope will be generated when the setup time is less than the set time.
- b. Hold: The oscilloscope will be generated when the hold time is less than the set time.
- c. Setup & Hold: The oscilloscope will be generated when the setup and hold time is less than the set time.

(8) Time

The setup and hold time ΔT is compared to the set time, the oscilloscope will be generated when the condition is met. Click on the “Time” input field to open the numeric keypad to set the time. Alternatively, rotate the [Multipurpose A](#) and the numeric keypad on the front panel to adjust the time.

The time range can be set from 3.2 ns to 10 s.

(9) Data Level, Clock Level


The setup & hold trigger requires the data level, clock level to be set. The setup & hold trigger can only be stable generated when all conditions are met.

Tap to select “Data Level” or “Clock Level”, the data level and clock level can be changed by using the [Multipurpose A](#) or the numeric keypad on the front panel. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).

8.12. Nth Edge Triggering

The Nth edge triggering refers to be triggered on the Nth edge after the specified idle time. For


example, waveform as shown in the following figure, it is set to trigger on the 2nd rising edge after the specified idle time (the time between two adjacent rising edges), then set the idle time as $P < \text{idle time} < M$, M is the time between the 1st rising edge and the next rising edge, P is the maximum time between the counting rising edge, as shown in the following figure.



$$P < \text{Idle time} < M$$

(1) Trigger Type

Press the **Menu** softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Nth Edge Trigger” to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer

to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Edge Type

Select an input signal to trigger on which edge.

- a. Rising edge: Set a signal to trigger on the rising edge.
- b. Falling edge: Set a signal to trigger on the falling edge.

(5) Idle Time

The idle time is compared to pulse time, the oscilloscope will be generated when the condition is met. Click the “Idle Time” input field to open the numeric keypad to set the idle time.

Alternatively, rotate the [Multipurpose A](#) rotary knob on the front panel to adjust the idle time.

The idle time range can be set from 3.2 ns to 10 s.

(6) Edge Number

The edge number represents Nth edge value. Click on the “Edge Number” input field to open the numeric keypad to set the edge number. Alternatively, rotate the [Multipurpose A](#) rotary knob on the front panel to adjust the edge number. The edge number range can be set from 1 to 65535.


(7) Level

Tap to select “Level”, the trigger level can be changed by using the [Multipurpose A](#), trigger [Position](#) rotary knob, and the numeric keypad on the front panel. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).

8.13. Code Pattern Triggering


The code pattern triggering identifies the trigger condition by detecting specified patterns. The pattern trigger type uses a logical AND combination of the channel settings, where each channel can be set to H (high), L (low), or X (omitted). Additionally, the user can specify a rising edge or falling edge for one channel (only one edge can be specified).

When an edge is assigned, the oscilloscope will trigger on the specified edge if the pattern of the other channels meets the preset pattern type (i.e., if the actual pattern matches the preset pattern). If no edge is assigned, the oscilloscope will trigger on the last edge where the pattern was “true”. If all channels are set to X (ignored), the oscilloscope will not trigger.



(1) Trigger Type

Press the **Menu** softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Code Pattern” to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on *Trigger Mode*, refer to the section [Noun Explanation of Triggering System](#).

(3) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Code Pattern

The code pattern can be set to H, L, X, rising edge, or falling edge. The current code pattern is

displayed at the top-right of the screen.

- a. H: Set the code pattern for the selected channel to “H”, i.e. the voltage level is higher than the trigger level of the channel.
- b. L: Set the code pattern for the selected channel to “Low”, i.e. the voltage level is lower than the trigger level of the channel.
- c. X: Set the code pattern for the selected channel to “X”, i.e. the channel is not part of the code pattern. The oscilloscope will not be triggered if all channel in the code pattern is set to “X”.
- d. Rising edge: Set the code pattern for the selected channel to the rising edge.
- e. Falling edge: Set the code pattern for the selected channel to the falling edge.

(5) Level


Tap to select “Level”, the trigger level can be changed by using the Multipurpose A, trigger Position rotary knob, and the numeric keypad on the front panel. For more details on *Trigger Level*, refer to the section [Noun Explanation of Triggering System](#).

8.14. Extreme Value Triggering

When using edge, pulse width, or other advanced triggering methods on signals with variable amplitudes and periods, achieving stable triggering can be challenging. Extreme value triggering is a specialized method designed for such scenarios. When the oscilloscope receives a signal with varying amplitude and period, it searches for the extreme value of the input signal within a defined time window and records its position as the trigger point. This allows the oscilloscope to stabilize on the identified extreme value and display a consistent waveform.

(1) Trigger Type

Press the Menu softkey on the front panel or tap the **T** trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Extremum” to configure the trigger settings.



(2) Trigger Mode

Set the trigger mode to auto, normal, or single. For more details on Trigger Mode, refer to the section [Noun Explanation of Triggering System](#).

(3) Source

Click on the “Source” to select C1 – C4. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(4) Extreme Value

Set the extreme value for signal triggering to either the maximum or minimum value.

- Maximum value: Triggers on the maximum value detected within the defined time range.
- Minimum value: Triggers on the minimum value detected within the defined time range.

(5) Time

Set the time range used to search for extreme values. When the maximum or minimum value of the signal is found within this range, the waveform can be triggered stably. Click on the “Time” to open the numeric keypad to set time value, or rotate the [Multipurpose A](#) rotary knob on the front panel to adjust the time value.

The maximum settable time is DDR total time to pre-trigger time.

(6) Filter Enable

Click on the “Filter Enable” to enable or disable the low pass filter. When the input signal

contains high-frequency noise, enabling the filter and adjusting its dynamic parameters can suppress such interference, resulting in more stable triggering.

(7) Filter Level

This setting is available when “Filter Enable” is turned on. Set the level of the low-pass filter, ranging from 0 to 31. A higher level corresponds to a lower cutoff frequency, allowing more high-frequency noise to be filtered out.

(8) Threshold

Set the threshold for extreme value triggering. If the difference between the maximum and minimum values of the waveform is less than the threshold, it indicates that the signal amplitude is too small, and triggering will not occur. This helps avoid false triggering from insignificant or noisy signals.

The settable range is 0 to 8 div.

8.15. RS232 Triggering

RS232 bus triggering is a serial communication method for transferring data between computers or between a computer and a terminal.

(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “RS232 Trigger” to configure the trigger settings.

The screenshot displays the 'Trigger' configuration window. At the top, the 'Type' is set to 'RS232'. Below this, the 'Mode' is set to 'Auto'. The 'Source' is 'C1', 'Polarity' is 'Positive', and 'Level' is '0.000V'. The 'Bitrate' is '115200 bps', 'Parity' is 'None', 'StopBit' is '2 bits', and 'Data Bits' is '8 bits'. The 'When' section has radio buttons for 'Start', 'StopBit', 'CheckErr', and 'Data', with 'Data' selected. The 'Data' field is set to '55'. At the bottom, there is a checkbox for 'AdjustSensitivity' which is checked, a 'Sensitivity' slider set to '50%', a 'Holdoff' field set to '80.000 ns', and a 'Noise Reject' button set to 'Off'.

(2) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) Level

Double-click on the “Level” input field to open the numeric keypad to set the trigger level; rotate the Multipurpose A rotary knob or rotate the trigger Position rotary knob on the right side of the front panel to adjust the trigger level.

When the trigger level is changed, a dotted line appears on the screen indicating the current trigger level. Once the change is stopped, the dotted line of the trigger level disappears after about 2 seconds.

(4) Polarity

- a. Negative: The reversed polarity of logic level, i.e. the high level is 0 and the low level is 1.
- b. Positive: The normal polarity of logic level, i.e. the high level is 1 and the low level is 0.

(5) Parity Check

Set the Parity check for data transmission. Click on the “Parity Check” to select none, even parity check, or odd parity check.

(6) Data Bit Width

Set the data bit width for RS232 signal, click on the “Data Bit” to select 5 bits, 6 bits, 7 bits, or 8 bits.

(7) Bit Sequence

Set the data bit sequence for RS232 signal, click on the “Bit Sequence” to select MSB or LSB

- a. MSB: The Most Significant Bit, i.e., the bit with the highest value in a sequence, transmitted first.
- b. LSB: The Least Significant Bit, i.e., the bit with the lowest value in a sequence, transmitted last.

(8) Stop Bit

Set the stop bit for each data, click on the “Stop Bit” to select 1 bit or 2 bits.

(9) Btrate

When RS232 communication is asynchronous transmission communication, no accompanying clock signal during the data transmission process, to solve the determination of data bits, the protocol requires that the two sides of communication to agree on the bit rate. Generally, the bit rate is defined as the number of bits that can be transmitted for 1 s time, for example, 9600

bps means that 9600 bits can be transmitted for 1 s. The bitrate is not directly equal to the effective data transmission rate. Note that the start bit, data bit, checksum and stop bit are all counted as bit bits, so the bitrate is not directly equal to the effective data rate. The oscilloscope will set the bitrate according to the bitrate form bit sampling.

Bitrate can be set to 2400 bps, 4800 bps, 9600 bps, 19200 bps, 38400 bps, 57600 bps, 115200 bps, or custom. Open the numeric keypad to set the custom bitrate.

It is recommended to make reasonable settings according to your RS232 communication hardware and software. Due to the basic model of this transmission protocol, RS232 protocol is usually used in short distance (less than 20 m), low speed (less than 1 Mbps) transmission occasions, and the communication outside of this range is susceptible to interference and becomes unreliable.

(10) Trigger Condition

- a. Start frame: The oscilloscope will trigger on the start bit of RS232. When sending a single string or sending the same string several times, this trigger can be used to see a stable signal waveform, and if the sent data changes, the corresponding waveform will also be changed.
- b. Stop Bit: Triggers on the occurrence of the stop bit in the RS232 protocol, specifically at the first stop bit. Regardless of whether the device under test (DUT) uses 1 or 2 stop bits, the trigger is executed automatically. Users do not need to manually configure the stop bit setting for the DUT.
- c. Parity error: When RS232 has the parity bit, set the parity bit to 0 or 1 according to the parity check method.

The parity checking rules are as follows:

- Odd parity check: The transmission is considered correct if the number of 1s in both the data bits and the parity bit is odd.
- Even parity check: The transmission is considered correct if the total number of 1s in both the data bits and the parity bit is even.

With this setting, the user can quickly locate and find the transmission process of parity error during the RS232 communication. It is useful for analyzing the fault.

- d. Data: The trigger will be generated when data acquired by the oscilloscope is the same as the custom 2 bits in hexadecimal. It can help the user to quickly find the transmission signal that the specific data they are interested in.

When the data is selected, the data menu can be configured.

- Data: The data is related to the frame length, double-click on the "Data" input field to open the numeric keypad to set the data. For details on the use of the numeric keypad,

refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data value. The data range can be set from 00 to FF.

8.16. I2C Triggering

I²C bus triggering is a two-wire serial bus and used to connect the microcontroller and peripheral device. It's widely applied in micro-electronics areas.

(1) Trigger Type

Press the **Menu** softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “I²C Trigger” to configure the trigger settings.

The screenshot shows the 'Trigger' menu with the following settings:

- Type:** I2C (dropdown)
- Force:** (button)
- Mode:** Auto (selected), Normal, Single
- SCL:** C1 (dropdown)
- Level A:** 188.00mV
- SDA:** C2 (dropdown)
- Level B:** 26.400mV
- When:** A & D (dropdown)
- Direction:** Read (selected), Write
- Addr Length:** 7 bits (selected), 10 bits
- Addr:** 48
- Bytes:** 1 (dropdown)
- Data(hex):** 55
- AdjustSensitivity:** (checked checkbox)
- Sensitivity:** (slider at 50%)
- Holdoff:** 80.000 ns
- Noise Reject:** Off

(2) Source Setting

Set both the clock source and the data source. The oscilloscope will only trigger stably if the selected channel has a connected signal and is set as the trigger source.

a. Clock Source

Click on the “Clock Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

b. Data Source

Click on the “Data Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) Level Setting

Click on the “Level A, Level B”, and double-click on “Level” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the [Multipurpose A](#) rotary knob to adjust the trigger level, or press the trigger [Position](#) rotary knob on the right side of the front panel to switch the selected trigger level (the selected threshold is displayed in full line) and then rotate rotary knob to change the trigger level.

(4) Operating Direction

Click on the “Operating Direction” to select “Read” or “Write”.

- a. Write: The oscilloscope will be generated when I²C protocol “Read/write” bit is set to “Write”.
- b. Read: The oscilloscope will be generated when I²C protocol “Read/write” bit is set to “Read”.

(5) Trigger Condition

- a. Start: Triggered on the start time.
- b. Restart: Triggered on the restart time, i.e. a start signal appears again after a start signal has appeared, but a stop has not appeared yet.
- c. Stop: Triggered on the stop bit, i.e. SDA signal goes from low to high when SCL is at the high level.
- d. Loss confirmed: In I²C protocol, every time after 8 bits information is transmitted, the data receiver needs to send an acknowledgement signal, which is the ACK bit in the above figure when the SCL is in the high level and the SDA signal is low. The loss trigger will occur while the SCL and SDA signal at the ACK bit are both high.
- e. Address: The oscilloscope will be generated when the communication address is the same as the user setting address. It can help the user to quickly locate the address transmission. When the address length or address is selected, the corresponding menus can be configured.
 - Address length: Set the address bit width of I²C signal, click on the “Address Length” to select 7 bits or 10 bits.
 - Address: Set the trigger address, double-click on the “Address” input field to open the numeric keypad to set the address. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the

Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the address. The range can be set from 00 to 7F and from 000 to 3FF.

- f. Data: The waveform will be generated when the data acquired by I²C is the same as the custom data. It can help the user to quickly find the transmission signal that the specific data they are interested in.

When the byte length or data is selected, the corresponding menus can be configured.

- Byte length: Click on the “Byte Length” input field to set the byte length for the specified data. The byte length range can be set from 1 to 5.
- Data: The data is related to the frame length, double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data value. The data range can be set from 00 to FFFFFFFF (10 Fs).

- g. Address & Data: The oscilloscope will be generated when the same address is found during the transmission and the data relation is conform to the set condition. With this trigger condition, it can easily generate the specified address and data trigger of I²C and helpful for the user to analyze the transmission.

When the address length, address, byte length, or data is selected, the corresponding menus can be configured. For the setting of each parameter, refer to *(5) Trigger Condition “Address” and “Data”* above.

8.17. SPI Triggering

(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “SPI” to configure the trigger settings.

Trigger

Type: SPI

Force: Auto

Mode: Auto

SCL: C1, Polarity A: Positive, Level A: 188.00mV

SDA: C2, Polarity B: Positive, Level B: 500.00mV

Mode: Timeout, CS, When: Data

CS: C3, Polarity C: Positive, Level C: 500.00mV

Bit Wide: 8, FrameLen: 1

MOSI Data: 55

AdjustSensitivity: ☒ Sensitivity: 50%

Holdoff: 80.000 ns, Noise Reject: Off

(2) Source Setting

Set the clock source, data source, and CS (Chip Selection) source. The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

a. Clock Source

Click on the “Clock Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

b. Data Source

Click on the “Data Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

c. Chip Selection Source

It can be set when the mode is CS. Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

(3) Edge Setting

a. Clock Polarity

Click on the “Clock Polarity” to select “Positive” or “Negative”.

Positive: Set to trigger on the positive edge of the clock signal.

Negative: Set to trigger on the negative edge of the clock signal.

b. CS Polarity

It can be set when the mode is CS. Click on the “CS Polarity” to select “Positive” or “Negative”.

Positive: The signal is set to 1 if it is greater than the threshold; otherwise, it is 0.

Negative: The signal is set to 1 if it is less than the threshold; otherwise, it is 0.

c. Data Polarity

Click on the “Data Polarity” to select “Positive” or “Negative”.

Positive: The signal is set to 1 if it is greater than the threshold; otherwise, it is 0.

Negative: The signal is set to 1 if it is less than the threshold; otherwise, it is 0.

(4) Level Setting

Click on the “Level A, Level B, or Level C”, and double-click on “Level” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the Multipurpose A rotary knob to adjust the trigger level, or press the trigger Position rotary knob on the right side of the front panel to switch the selected trigger level (the selected threshold is displayed in full line) and then rotate rotary knob to change the trigger level.

(5) Mode

Click on the “Mode” to select SPI mode. In SPI mode, timeout and chip selection can be set.

- Timeout: After the clock signal (CLK) remains idle for the specified time, the oscilloscope will Triggers when it detects data on MISO that meets the trigger conditions.
- Chip selection: When the Chip Select (CS) signal is valid, the oscilloscope triggers upon detecting data on SDA that meets the specified trigger conditions.

(6) Trigger Condition

Set the trigger condition for SPI. The start and data can be set.

- a. Start: A clock signal will be generated when the timeout meets the trigger condition. When the timeout is selected, the timeout menu can be configured.

- Timeout: Double-click on the “Timeout” input field to open the numeric keypad to set the timeout. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the timeout. The setting range can be set from 3.2 ns to 1 s.

- b. Data: A trigger will be generated when the clock signal meets the idle time and the data signal satisfies the data condition.

When the mode is timeout, timeout, data bit width, and data can be set.

When the mode is CS, data bit width, frame length, and data can be set.

- Timeout: Set the idle time. For the setting method, refer to “Idle time” mentioned

above.

- Data bit width: Set the bit width for each unit in SPI protocol, double-click on the “Data Bit Width” input field to open the numeric keypad to set the data bit width. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the data bit width. The setting range can be set from 4 to 32 bits.
- Frame length: Set the length for data unit. Double click on the “Frame Length” input field to open the numeric keypad to set the frame length. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the frame length. The setting range can be set from 1 to 32.
- Data: The data is related to the frame length. Double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data value. The setting range can be set from 0 – FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF (32 Fs).

8.18. CAN Triggering

(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “CAN” to configure the trigger settings.

(2) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) Level

Double-click on the “Level” input field to open the numeric keypad to set the trigger level.

Alternatively, rotate the Multipurpose A rotary knob to adjust the trigger level; or press the trigger Position rotary knob on the right side of the front panel to change the trigger level.

When the trigger level is changed, a dotted line appears on the screen indicating the current trigger level. Once the change is stopped, the dotted line of the trigger level disappears after about 2 seconds.

(4) Signal Type

Select whether the current signal accessed by the source is a high data line signal or a low data line signal. Click on the “Signal type” to select “CAN_H”, or “CAN_L”.

(5) Bitrate

Select the bitrate for CAN serial bus data, click on the “Bitrate” to select 10 kbps, 19.2 kbps, 20 kbps, 33.3 kbps, 38.4 kbps, 50 kbps, 57.6 kbps, 62.5 kbps, 83.3 kbps, 100 kbps, 115.2 kbps, 125 kbps, 230.4 kbps, 250 kbps, 490.8 kbps, 500 kbps, 800 kbps, 921.6 kbps, 1 Mbps, 2 Mbps, 3 Mbps, 4 Mbps, 5 Mbps, or a custom bitrate.

If "Custom" is selected, a custom bitrate can be entered.

(6) Trigger Condition

- a. Start frame: The oscilloscope will trigger on the start of the CAN signal frame.
- b. Data frame: Triggered on the data frame that matches with the CAN signal.
- c. Remote frame: Triggered on the remote frame.
- d. Error frame: Triggered on the error frame of the CAN signal.
- e. Overload frame: Triggered on the overload frame of the CAN signal.
- f. Identifier: Triggered on the data frame that matches with the specified ID.

When the identifier, frame format, or direction is selected, the corresponding menus can be configured.

- Identifier: Double-click on the "Identifier" input field to open the numeric keypad to set the identifier. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the identifier. The setting range can be set from 000 to 7FF and from 00000000 to 1FFFFFFF.
- Frame format: Click on the "Frame Format" to set the format to standard or extend. The different frame formats have different ID ranges.
- Direction: Click on the "Direction" to set the direction for the identifier. The direction can be set to "Write", "Read", or "Read or Write".
 - Write: The oscilloscope will be generated when CAN protocol "Read/Write" bit is "Write".
 - Read: The oscilloscope will be generated when CAN protocol "Read/Write" bit is "Read".
 - Read or write: The oscilloscope will be generated when CAN protocol "Read/Write" bit is "Read or Write".
- g. Data: The waveform will be generated when the data acquired by CAN is the same as the custom data. It can help the user to quickly find the transmission signal that the specific data they are interested in.

When the byte length or data is selected, the corresponding menus can be configured.

- Byte length: Different byte lengths have different data ranges. Double-click on the "Byte Length" input field to select the byte length. The setting range can be set from 1 to 8.
- Data: Set the trigger data, double-click on the "Data" input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the

section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data.

- h. ID and Data: Triggered on the data frame that matches the specified ID and data. When the identifier, frame format, direction, byte length, or data is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (6) Trigger Condition “*Identifier*” and “*Data*” mentioned above.
- i. End of frame: Triggered on the end of frame of CAN signal.
- j. Loss confirmed: Triggered on the loss confirmed of CAN signal.
- k. Bit stuff error: In the segment requiring bit filling, the waveform will trigger upon detecting an error from 6 consecutive bits of the same level.
- l. CRC error: Triggered when a CRC error occurs.
- m. All error: Triggered by all errors, including bit stuff errors and CRC errors.

8.19. CAN-FD Triggering

(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “CAN-FD” to configure the trigger settings.

The screenshot shows the 'Trigger' configuration window. At the top, there are tabs for 'Type' (CAN-FD), 'Force', 'Mode' (Auto, Normal, Single), and 'Signal Type' (CAN_L, CAN_H). Below these are various settings: Source (C1), Level (188.00mV), Bitrate (500 kbps), FD Bitrate (5 Mbps), Sample Pos (75.000%), ID (70F), When (ID&Data), Format (Base), Bytes (1), Data (55), Bias (Off), AdjustSensitivity (checked), Sensitivity (50%), Holdoff (80.000 ns), and Noise Reject (Off).

(2) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) Level

Double-click on the “Level” input field to open the numeric keypad to set the trigger level.

Alternatively, rotate the Multipurpose A rotary knob to adjust the trigger level; or press the trigger Position rotary knob on the right side of the front panel to change the trigger level.

When the trigger level is changed, a dotted line appears on the screen indicating the current trigger level. Once the change is stopped, the dotted line of the trigger level disappears after about 2 seconds.

(4) Signal Type

Select whether the current signal accessed by the source is a high data line signal or a low data line signal. Click on the “Signal type” to select “CAN_H”, or “CAN_L”.

(5) Bitrate

Select the bitrate for CAN-FD serial bus data, click on the “Bitrate” to select 10 kbps, 19.2 kbps, 20 kbps, 33.3 kbps, 38.4 kbps, 50 kbps, 57.6 kbps, 62.5 kbps, 83.3 kbps, 100 kbps, 115.2 kbps, 125 kbps, 230.4 kbps, 250 kbps, 490.8 kbps, 500 kbps, 800 kbps, 921.6 kbps, 1 Mbps, 2 Mbps, 3 Mbps, 4 Mbps, 5 Mbps, or a custom bitrate.

If "Custom" is selected, a custom bitrate can be entered.

(6) FD Bitrate

Select the FD bitrate for CAN-FD serial bus data, click on the “FD Bitrate” to select 250 kbps, 500 kbps, 800 kbps, 1 Mbps, 1.5 Mbps, 2 Mbps, 4 Mbps, 5 Mbps, 6 Mbps, 8 Mbps, or a custom FD bitrate. If "Custom" is selected, a custom FD bitrate can be entered.

(7) Sampling Position

The sample position is the point in the bit time where the oscilloscope samples the bit level. The sample position is expressed as a percentage of the "Time from bit start to sample point" and the “Bit Time”.

Click on the “Sampling position” input field to open the numeric keypad to set the sampling position. Alternatively, rotate the Multipurpose A rotary knob to adjust the sampling position.

The range can be set to from 30% to 90%.

(8) Trigger Condition

- a. Start frame: The oscilloscope will trigger on the start of the CAN-FD signal frame.

- b. Data frame: Triggered on the data frame that matches with the CAN-FD signal.
- c. Remote frame: Triggered on the remote frame.
- d. Error frame: Triggered on the error frame of the CAN-FD signal.
- e. Overload frame: Triggered on the overload frame of the CAN-FD signal.
- f. Identifier: Triggered on the data frame that matches with the specified ID.

When the ID or frame format is selected, the corresponding menus can be configured.

- a. ID: Double-click on the “ID” input field to open the numeric keypad to set the ID. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the ID. The ID range can be set from 000 to 7FF and from 00000000 to 1FFFFFFF.
- b. Frame format: Click on the “Frame Format” to set the format to standard, extend, FD standard, or FD extend. The different frame formats have different ID ranges. The standard and extend format are suitable for CAN signal. FD standard and FD extend format are suitable for CAN-FD signal.
- g. Data: The waveform will be generated when the data acquired by CAN-FD is the same as the custom data. It can help the user to quickly find the transmission signal that the specific data they are interested in.

When the byte length, data, offset, or byte offset is selected, the corresponding menus can be configured.

- Byte length: Different byte lengths have different data ranges. Double-click on the “Byte Length” input field to select the byte length. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the byte length. The setting range can be set from 1 to 16.
- Data: Set the trigger data, double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data.
- Offset: Set the data offset of byte data for delay trigger. Click on the “Offset” to toggle it ON or OFF.
 - ON: Displays the “Byte Offset” menu.
 - OFF: Hide the “Byte Offset” menu.
- Byte offset: Double-click on the “Byte Offset” input field to open the numeric keypad


to set the byte offset. Double-click on the “Byte Offset” input field to select the byte offset. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the byte offset. The setting range can be set from 0 to 63.

- h. ID and Data: Triggered on the data frame that matches the specified ID and data. When the ID, frame format, byte length, data, offset, or byte offset is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (8) Trigger Condition “*Identifier*” and “*Data*” mentioned above.
- i. End of frame: Triggered on the end of frame of CAN - FD signal.
- j. Loss confirmed: Triggered on the loss confirmed of CAN - FD signal.
- k. Bit stuff error: In the segment requiring bit filling, the waveform will trigger upon detecting an error from 6 consecutive bits of the same level.
- l. CRC error: Triggered when a CRC error occurs.
- m. All error: Triggered by all errors, including bit stuff errors and CRC errors.

8.20. CAN-XL Triggering

(1) Trigger Type

Press the Menu softkey on the front panel or tap the **T** trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “CAN-XL” to configure the trigger settings.



(2) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) Level

Double-click on the “Level” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the Multipurpose A rotary knob to adjust the trigger level; or press the trigger Position rotary knob on the right side of the front panel to change the trigger level. When the trigger level is changed, a dotted line appears on the screen indicating the current trigger level. Once the change is stopped, the dotted line of the trigger level disappears after about 2 seconds.

(4) Signal Type

Select whether the current signal accessed by the source is a high data line signal or a low data line signal. Click on the “Signal Type” to select “CAN_H” or “CAN_L”.

(5) Bitrate

Select the bitrate for CAN-XL serial bus data, click on the “Bitrate” to select 10 kbps, 19.2 kbps, 20 kbps, 33.3 kbps, 38.4 kbps, 50 kbps, 57.6 kbps, 62.5 kbps, 83.3 kbps, 100 kbps, 115.2 kbps, 125 kbps, 230.4 kbps, 250 kbps, 490.8 kbps, 500 kbps, 800 kbps, 921.6 kbps, 1 Mbps, 2 Mbps, 3 Mbps, 4 Mbps, 5 Mbps, or a custom bitrate.

(6) FD Bitrate

Select the FD bitrate for CAN-FD serial bus data, click on the “FD Bitrate” to select 250 kbps, 500 kbps, 800 kbps, 1 Mbps, 1.5 Mbps, 2 Mbps, 4 Mbps, 5 Mbps, 6 Mbps, 8 Mbps, or a custom FD bitrate. If "Custom" is selected, a custom FD bitrate can be entered.

(7) XL Bitrate

Select the XL bitrate for CAN-FD serial bus data, click on the “XL Bitrate” to select 250 kbps, 500 kbps, 800 kbps, 1 Mbps, 1.5 Mbps, 2 Mbps, 4 Mbps, 5 Mbps, 6 Mbps, 8 Mbps, 10 Mbps, 20 Mbps, or a custom XL bitrate. If "Custom" is selected, a custom XL bitrate can be entered.

(8) Sampling Position

The sampling position is the point in the bit time where the oscilloscope samples the bit level. It is expressed as a percentage of the "Time from bit start to sample point" and the “Bit Time”. Click on the “Sampling position” input field to open the numeric keypad to set the sampling position. Alternatively, rotate the Multipurpose A rotary knob to adjust the sampling position. The range can be set to from 30% to 90%.

(9) Trigger Condition

- a. Start frame: The oscilloscope will trigger on the start of the CAN-XL signal frame.
- b. Data frame: Triggered on the data frame that matches with the CAN-XL signal.
 - Frame type: Triggers when the specified frame type is detected.
 - CC data frame: Triggers on a CAN protocol data frame.
 - CC remote frame: Triggers on a CAN protocol remote frame.
 - FD data frame: Triggers on a CAN-FD protocol data frame.
 - XL data frame: Triggers on a CAN-XL protocol data frame.
 - Error frame: Triggers on an error frame.
 - Overload frame: Triggers on an overload frame.
 - Frame format: Set the frame format corresponding to the selected frame type. The available options are standard and extended, selectable based on the chosen frame type. The oscilloscope triggers when the frame format matches the selected frame type.
- c. Identifier: Triggered on the data frame that matches with the specified ID. When the ID or frame format is selected, the corresponding menus can be configured.
 - Frame type: Refer to Trigger Condition “Frame type” mentioned above.
 - ID: Double-click on the “ID” input field to open the numeric keypad to set the ID. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, then use the Multipurpose A rotary knob to adjust the ID. The ID range

- can be set from 000 to 7FF and from 00000000 to 1FFFFFFF.
- Frame format: Click on the “Frame Format” to set the format to standard, extend, XL standard, or XL extend. The different frame formats have different ID ranges. The standard and extend format are suitable for CAN signal. “XL standard, XL extend” format is suitable for CAN-XL signal.
- d. Data: The waveform will be generated when the data acquired by CAN-XL is the same as the custom data. It can help the user to quickly find the transmission signal that the specific data they are interested in. When the byte length, data, offset, or byte offset is selected, the corresponding menus can be configured.
- Byte length: Different byte lengths have different data ranges. Double-click on the “Byte Length” input field to select the byte length. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the byte length. The setting range can be set from 1 to 16.
 - Data: Set the trigger data, double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data.
 - Offset: Set the data offset of byte data for delay trigger. Click on the “Offset” to toggle it ON or OFF.
ON: Displays the “Byte Offset” menu.
OFF: Hide the “Byte Offset” menu.
 - Byte offset: Double-click on the “Byte Offset” input field to select the byte offset. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the byte offset. The setting range can be set from 0 to 2047.
- e. ID and Data: Triggered on the data frame that matches the specified ID and data. When the frame type, ID, frame format, byte length, data, offset, or byte offset is selected, the corresponding menus can be configured. For the setting of each parameter, refer to Trigger Condition “*Identifier*” and “*Data*” mentioned above.
- f. SDT: Set the SDT field data as needed. Double-click on the “SDT” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to

- adjust the data.
- g. VCID: Set the VCID field data as needed. Double-click on the “VCID” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data.
 - h. AF: Set the AF field data as needed. Double-click on the “AF” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data.
 - i. End of frame: Triggered on the end of frame of CAN-XL signal.
 - j. Loss confirmed: Triggered on the loss confirmed of CAN-XL signal.
 - k. Bit stuff error: In the segment requiring bit filling, the waveform will trigger upon detecting an error from 6 consecutive bits of the same level.
 - l. Format error: Triggers at the position where a format error occurs.
 - m. CRC error: Triggered when a CRC error occurs.
 - n. All error: Triggered by all errors, including bit stuff errors and CRC errors.

8.21. LIN Triggering

(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “LIN” to configure the trigger settings.

(2) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) Polarity

Click on the “Polarity” to select the polarity to “Positive” or “Negative”.

(4) Level

Double-click on the “Level” input field to open the numeric keypad to set the trigger level.

Alternatively, rotate the [Multipurpose A](#) rotary knob to adjust the trigger level; or press the trigger [Position](#) rotary knob on the right side of the front panel to change the trigger level.

When the trigger level is changed, a dotted line appears on the screen indicating the current trigger level. Once the change is stopped, the dotted line of the trigger level disappears after about 2 seconds.

(5) Version

Click on the “Version” to select the signal version to v1.x, v2.x, or arbitrary.

(6) Bitrate

Select the bitrate for LIN, click on the “Bitrate” to select 1.2 kbps, 2.4 kbps, 4.8 kbps, 9.6 kbps, 10.417 kbps, 19.2 kbps, 20 kbps, or a custom bitrate.

If "Custom" is selected, a custom bitrate can be entered.

(7) ID Parity Check

Set ID Parity check to toggle it ON or OFF.

ON: Includes parity bit and ID.

OFF: Does not include parity bit and ID.

(8) Data Length Menu

Set whether to display the data length menu. Click on the “Data Length” to toggle it ON or OFF.

ON: Displays the data length menu.

OFF: Hide the data length menu.

(9) Data Length

Set LIN data length. Double-click on the “Data Length” input field to open the numeric keypad to set the data length. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the byte offset. The data length can be set from 1 to 8. It is only available when the data length menu is displayed.

(10) Trigger Condition

- a. Synchronization: The oscilloscope will be generated when detecting a synchronizing signal.
- b. Identifier: The oscilloscope will be generated when detecting ID is equal to the setting frame.

When the ID is selected, the ID menu can be configured.

- ID: Double-click on the “ID” input field to open the numeric keypad to set the ID. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the ID.

When ID including parity bit is set to “ON”, the range is from 00 to FF.

When ID including parity bit is set to “OFF”, the range is from 00 to 3F.

- c. Data: The waveform will be generated when the data is the same as the custom data. It can help the user to quickly find the transmission signal that the specific data they are interested in.

When the byte length or data is selected, the corresponding menus can be configured.

- Byte length: Different byte lengths have different data ranges. Click on the “Data” input field to select the byte length. The setting range can be set from 1 to 8.
- Data: Set the trigger data. Double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A

rotary knob to adjust the data. The data range can be set from 00 to FFFFFFFFFFFFFFFF.

- d. ID and Data: Triggered on the data frame that matches the specified ID and data.

When the ID, byte length, or data is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (10) Trigger Condition “*Identifier*” and “*Data*” mentioned above.

- e. Wake-up frame: Triggered on the signal's wake-up frame.
- f. Sleep frame: Triggered on the signal's sleep frame.
- g. Error: Triggered on the LIN signal's sleep frame.


When the error type is selected, the error type menu can be configured.

- Error type: Click on the “Error type” to select synchronization, ID Parity check, and checksum.
 - Synchronization: Synchronizing error
 - ID Parity check: ID parity check error
 - Checksum: Data check and error

8.22. FlexRay Triggering

(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “FlexRay” to configure the trigger settings.



(2) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) Polarity

Click on the “Polarity” to select BDiff, BP, or BM.

(4) Level

Double-click on the “Level” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the [Multipurpose A](#) rotary knob to adjust the trigger level; or press the trigger [Position](#) rotary knob on the right side of the front panel to change the trigger level.

(5) Channel Type

Click on the “Channel Type” to select A or B.

(6) Bitrate

Click on the “Bitrate” to select 2.5 Mbps, 5 Mbps, 10 Mbps, or a custom bitrate.

If "Custom" is selected, a custom bitrate can be entered.

(7) Trigger Condition

- a. Start frame: Triggered at the start of a frame.
- b. Indicating bit: The oscilloscope will Triggers when the acquired data matches the set indicating bit.

When the indicating bit is selected, the indicating bit menu can be configured.

- Indicating bit: Set the indicating bit of FlexRay trigger, click on the “Indicating Bit” to set normal (01XX), static load (11XX), null (00XX), synchronization (XX10), or start (XX11).
- c. Identifier: The oscilloscope will Triggers when the acquired data matches the set identifier. When the ID is selected, the ID menu can be configured.

- ID: Double-click on the “ID” input field to open the numeric keypad to set the ID. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the ID. The data range can be set from 000 to 7FF.
- d. Period number: The oscilloscope will be generated when the acquired period number is the same as the set period number.

When the period number is selected, the period number menu can be configured.

- Period number: Double-click on the “Period Number” input field to open the numeric keypad to set the period number. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the period number. The data range can be set from 00 to 3F.
- e. Header filed: The oscilloscope will be generated when header filed is the same as the setting.

When the identifier bit, ID, static load, header CRC, or period number is selected, the corresponding menus can be configured.

- Identifier bit: Double-click on the “Identifier Bit” input field to open the numeric keypad to set the identifier bit. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the identifier bit. The data range can be set from 00 to 1F.
- ID: For setting ID, refer to Trigger Condition “*Identifier*” mentioned above.
- Static load: Double-click on the “Static Load Length” input field to open the numeric keypad to set the static load length. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the static load. The data range can be set from 00 to 7F.
- Header CRC: Double-click on the “Header CRC” input field to open the numeric keypad to set the header CRC. For details on the use of the numeric keypad, refer to the

section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the header CRC. The data range can be set from 000 to 7FF.

- Period number: For setting the period number, refer to Trigger Condition *“Period Number”* mentioned above.
- f. Data: The waveform will be generated when the acquired data is the same as the custom data. It can help the user to quickly find the transmission signal that the specific data they are interested in.

When the byte length, offset, data, or byte offset is selected, the corresponding menus can be configured.

- Byte length: Different byte lengths have different data ranges. Double-click on the “Byte Length” input field to open the numeric keypad to set the byte length. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust the byte length. The range of byte length can be set from 1 to 16.
 - Offset: Click on the “Offset” input field to toggle it ON or OFF.
 - Data: Double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust the data. The byte length range can be set from 00 to FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF (32 Fs).
 - Byte offset: Set the byte offset and display the off-screen data on the screen. Double-click on the “Byte Offset” input field to open the numeric keypad to set the byte offset. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust the byte offset. The byte offset range can be set from 0 to 253.
- g. ID and Data: Triggered on the data frame that matches the specified ID and data. When the ID, byte length, bias, data, or byte offset is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (7) Trigger Condition *“Identifier”* and *“Data”* mentioned above.
- h. End of frame: Triggered at the end of frame of the oscilloscope. When the frame type is selected, the frame type menu can be configured.
- Frame type: Click on the “Frame Type” to select static, dynamic (DTS), and all.
 - Static frame: Triggered on the static frame.
 - Dynamic frame (DTS): Triggered on the dynamic frame.
 - All: Triggered on the static and dynamic frame.


- i. Error: The oscilloscope will be generated when the bus error occurs.

When the error is selected, the error menu can be configured.

- Error: Click on the “Error” to select header CRC, end of frame CRC, empty frame static error, empty dynamic error, synchronization frame, or start frame.
 - Header CRC: Header CRC error of bus
 - End of frame CRC: End of frame CRC error of bus
 - Empty frame static error: Empty frame static error of bus
 - Empty dynamic error: Empty dynamic error of bus
 - Synchronization frame: The header frame of FlexRay has a dedicated indicating bit, the data frame will be the synchronization frame when the indicating bit is valid.
 - Start frame: The start frame of FlexRay has a dedicated indicating bit, the data frame will be the synchronization frame when the indicating bit is valid.

8.23. Audio Triggering

In the Audio triggering type, the oscilloscope recognizes the trigger condition by referencing the specified data value. The serial clock line (SCLK) should be specified, which receives 1 pulse on the clock line for every 1-bit digital audio data sent), the frame clock line (WS, which toggles the data of the audio channel), and the serial data line (SDA, which transmits the audio data expressed as binary complements). The following figure shows the Audio bus sequence chart.



(1) Trigger Type


Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Audio” to configure the trigger settings.

Trigger						
Type	AUDIO	Force	Mode	Auto	Normal	Single
Format	Standard	Bit Order	MSB	LSB	Word Size	8
Bit Clock	C1	Clock Edge	Rising	Falling	Level A	188.00mV
Data	C2	Data Polarity	High=1	High=0	Level B	500.00mV
Word	C3	WS Polarity	Normal	Inverted	Level C	500.00mV
When	Word					
<input checked="" type="checkbox"/> AdjustSensitivity Sensitivity <input type="range" value="50"/> 50%						
Holdoff	80.000 ns	Noise Reject	Off			


(2) Format

Click on the “Format” to select standard, left justifying, right justifying, or TDM.


- Standard: The MSB of each sampled data is sent first, followed by the LSB. The MSB is displayed on the SDATA line one clock bit after the WS transition edge.




- Left justifying: Data transmission (MSB first) starts at the WS transition edge, without the one-bit delay used in the standard format.



- Right justifying: Data transmission (MSB first) is right aligned with the WS signal.



- TDM: (Time Division Multiplexing) mode allows the transmission of multi-channel data.



(3) Bit Sequence

Click on the "Bit Sequence" to select "LSB" or "MSB". The default is "MSB".

(4) Source Setting

Set bit clock, bit selection, and data source. The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

a. Bit Clock

Click on the "Bit Clock" to select C1 - C4 or D0 - D15. For more details on *Trigger Source*,

refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen. The clock line (SCLK) provides the clock signal for synchronizing audio data transmission.

b. Bit Selection

Click on the “Bit Selection” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen. The bit selection indicates the audio data of the current transmission is left channel or right channel.

c. Data

Click on the “Data” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen. The data line is used to transmit actual audio data.

d. Frame Synchronization

Click on the “Frame Synchronization” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

(5) Edge Setting

a. Clock Edge

Click on the “Clock” to select “Rising” or “Falling” edge.

Rising edge: Samples SDA on the rising edge of the clock.

Falling edge: Samples SDA on the falling edge of the clock.

b. WS Polarity

Click on the “WS Polarity” to select “Normal” or “Reverse”. The WS polarity determines the valid level for the bit selection signal. The bit selection signal indicates the start frame and end of frame for the audio data.

c. Data Polarity

Click on the “Data Polarity” to select “high=1” or “high=0”.

d. Polarity Synchronization

Click on the “Polarity Synchronization” to set the edge for the frame synchronization signal to the “Rising” or “Falling” edge.

(6) Level

Click on the “Level A, Level B, Level C, or Level D”, and double-click on “Level” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the [Multipurpose A](#) rotary knob to adjust the trigger level, or press the trigger [Position](#) rotary knob on the right side of the front panel to switch the selected trigger level (the selected threshold is displayed in full line)

and then rotate rotary knob to change the trigger level.

(7) Data Format (do not select TDM)

When the data format is set to standard, left justifying, or right justifying, the bit size and trigger mode (bit selection and data) menus can be configured.

a. Bit Size

The bit size can be set when the format is standard, left justifying, or right justifying.

Double-click on the “Bit Size” input field to open the numeric keypad to set the bit size. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

Alternatively, use the Multipurpose A rotary knob to adjust the byte offset. The byte offset range can be set from 4 to 32.

b. Trigger Type

- Bit Selection: Triggered on the bit selection.
- Data: The oscilloscope will be generated when the data meets the setting value in the sound channel.

When the Audio or data is selected, the corresponding menus can be configured.

- Audio: Click on the “Audio” to select any, left channel, or right channel.
- Data: Double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data.

(8) Data Format (select TDM)

When the format is standard, left justifying, right justifying, data bit per channel, clock bit per channel, channel number per frame, bit delay, or trigger condition (frame synchronization, data, channel, and data) is selected, the corresponding menus can be configured.

a. Data Bit per Channel

Double-click on the “Data Bit per Channel” input field to open the numeric keypad to set this value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust this value.

The setting range can be set from 4 to 32.

The set value of each channel data bit \leq the set value of each channel clock bit.

b. Clock Bit per Channel

Double-click on the “Clock Bit per Channel” input field to open the numeric keypad to set this value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust this value.

The setting range can be set from 4 to 32.

c. Channel Number per Frame

Double-click on the “Channel Number per Frame” input field to open the numeric keypad to set this value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust this value.

The setting range can be set from 2 to 64.

d. Bit Delay

Double-click on the “Bit Delay” input field to open the numeric keypad to set this value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust this value. The setting range can be set from 0 to 31.

The set value of bit delay < The set value of each channel clock bit.

e. Trigger Condition

- Synchronization frame: Triggered on the synchronization frame.
- Data: The oscilloscope will be generated when the data meets the setting value.
When the data is selected, the data menu can be configured.
 - Data: Double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust the data.
- Channel and data: The oscilloscope will be generated when the channel and data meet the setting value.
When the channel or data is selected, the corresponding menus can be configured.
 - Channel: Double-click on the “Channel” input field to open the numeric keypad to set the channel number. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust the channel number.
 - Data: Double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust the data.

8.24. 1553B Triggering

(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “1553B” to

configure the trigger settings.

(2) Source

Click on the “Source” to select C1 - C4. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) Polarity

Click on the “Polarity” to select “Positive” or “Negative”.

(4) High/Low Level

Double-click on “High Level (Low Level)” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the [Multipurpose A](#) rotary knob to adjust the trigger level, or press the trigger [Position](#) rotary knob on the right side of the front panel to switch the selected trigger level (the selected threshold is displayed in full line) and then rotate rotary knob to change the trigger level.

(5) Format

Click on the “Format” to set command word or state word.

If the format is the command word, the state trigger condition will be hidden.

If the format is the state word, the command trigger condition will be hidden.

(6) Trigger Condition

- a. Synchronization: Triggered when a synchronization signal is detected.

- b. Command: Triggered when the command fully matches the set parameters.
- When the terminal address, T/R bit, sub-address/mode, word count/code, or parity check, the corresponding menus can be configured.
- Terminal address: Set the terminal address for a command word. Double-click on the “Terminal Address” input field to open the numeric keypad to set the terminal address. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the terminal address.
 - T/R bit: Select the “T/R Bit” to set X, 0 (R), or 1 (T). The default is X.
 - Sub-address/mode: Set the sub-address for a command word. Double-click on the “Sub-address” input field to open the numeric keypad to set the sub-address. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the sub-address.
 - Word count/code: Set the word count/code for a command word, double-click on the “Word count/code” input field to open the numeric keypad to set the word count/code. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the word count/code.
 - Parity check: Select the “Parity Check” to set X, 0, or 1. The default is X.
- c. State: Triggered when the state word completely matches the set parameters. When the terminal address, error message (9), Instr (10), service request (11), BCR (15), Busy (16), system flag (17), DBCA (18), terminal flag (19), or parity check, the corresponding menus can be configured.
- Terminal address: Set the terminal address for a state word. Double-click on the “Terminal Address” input field to open the numeric keypad to set the terminal address. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the terminal address.
 - Error message (9): Select the “Error message (9)” to set X, 0, or 1. The default is X.
 - Instr (10): Select the “Instr (10)” to set X, 0, or 1. The default is X.
 - Service request (11): Select the “Service request (11)” to set X, 0, or 1. The default is X.

- BCR (15): Select the “BCR (15)” to set X, 0, or 1. The default is X.
 - Busy (16): Select the “Busy (16)” to set X, 0, or 1. The default is X.
 - System flag (17): Select the “System flag (17)” to set X, 0, or 1. The default is X.
 - DBCA (18): Select the “DBCA (18)” to set X, 0, or 1. The default is X.
 - Terminal flag (19): Select the “Terminal flag (19)” to set X, 0, or 1. The default is X.
 - Parity check: Select the “Parity Check” to set X, 0, or 1. The default is X.
- d. Data: Triggered when the data word matches the set parameters.

When the data or parity check is selected, the corresponding menus can be configured.

- Data: Triggered on the specified data word. Double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data.
 - Parity check: Select the “Parity Check” to set X, 0, or 1. The default is X.
- e. Error: Triggered on the specified error type.

When the error type (Parity check, synchronization, Manchester, and non-continuous data) is selected, the corresponding menus can be configured.

- Parity check: Triggered when the odd or even parity check is incorrect for the data in the word.
- Synchronization: Triggered when an invalid synchronizing pulse is detected.
- Manchester: Triggered when a Manchester error is detected.
- Non-continuous data: Triggered when non-continuous data is detected.

8.25. Manchester Triggering

(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “Manchester” to configure the trigger settings.

(2) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) Level

Double-click on the “Level” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the Multipurpose A rotary knob to adjust the trigger level; or press the trigger Position rotary knob on the right side of the front panel to change the trigger level.

(4) Encode Mode

Click on the “Encode Mode” to switch between IEEE and G.E.

- IEEE: “1” indicates that a jump from low to high; “0” indicates that a jump from high to low.
- G.E: “1” indicates that a jump from low to high; “0” indicates that a jump from high to low.

(5) Bitrate

Click on the “Bitrate” to select the bitrate for DUT to 1.2 kbps, 2.4 kbps, 4.8 kbps, 9.6 kbps, 10.417 kbps, 19.2 kbps, 125 kbps, 250 kbps, 500 kbps, 1 Mbps, 2 Mbps, 5 Mbps, 10 Mbps or custom. The custom baud bitrate must match the DUT, the default bitrate is 1.2 kbps.

(6) Bit Sequence

Click on the “Bit Sequence” to switch between MSB and LSB.

- MSB: The Most Significant Bit, i.e., the bit with the highest value in a sequence, transmitted

first.

- LSB: The Least Significant Bit, i.e. the bit with the least value in a sequence, transmitted first.

(7) Idle State

Click on the “Idle State” to switch between 0 or 1.

- 0: The bus state is at a low level when no data is present.
- 1: The bus state is at a high level when no data is present.

(8) Trigger Condition

- a. Start frame: Triggered at the start of a frame.
- b. Header field: Triggered on the header field when the condition is met.

When the header field is selected, the header field menu can be configured.

- Header field: Set the trigger data for the header field. The data length is limited by the length of “Header Field”. Double-click on “Header field” input field to open the numeric keypad to set the header field. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the header field.

- c. Data field: Triggered on the data field when the condition is met.

When the data field is selected, the data field menu can be configured.

- Bitrate: Set the data length for the triggering data of data field, double-click on the “Bitrate” input field to pop up the numeric keyboard to set the bitrate value. For details on the use of the numeric keyboard, refer to the section of [5.8 Parameter Setting](#). Select this parameter and use the Multipurpose rotary knob to adjust the bitrate value
- Data field: Set the trigger data for the data field, the data length is limited by the “Data Bit” and “Bit Size”. Double-click on “Data Field” input field to open the numeric keypad to set the data field. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data field.

- d. End field: Triggered on the end field when the condition is met.

- End field: Set the trigger data for the end field, the data length is limited by the “End Field”. Double-click on “End Field” input field to open the numeric keypad to set the end field. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the

end field.

- e. Error field: Triggered on the error field.

(9) Start Frame Bit

Click on the “Start Frame Bit” input field to open the numeric keypad to enter the start frame bit. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the start frame bit. The range can be set from 1 to 32.

(10) Synchronization Field

Click on the “Synchronization Field” input field to open the numeric keypad to enter the synchronization field. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the synchronization field. The setting range can be set from 0 to 32.

(11) Middle Field 1

Click on the “Middle Field 1” input field to open the numeric keypad to enter the middle field 1. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the middle field 1. The setting range can be set from 0 to 32.

(12) Header Field

This parameter setting is valid only for header field triggering. Click on “Header Field” input field to open the numeric keypad to enter the header field. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the header field. The setting range can be set from 0 to 32.

(13) Middle Field 2

Click on the “Middle Field 2” input field to open the numeric keypad to enter the middle field 2. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the middle field 2. The setting range can be set from 0 to 32.

(14) Word

Click on the “Word” input field to open the numeric keypad to enter the word value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the word value. The setting range can be set from 1 to 255.

(15) Bit Size

Click on the “Bit Size” input field to open the numeric keypad to enter the bit size. For details

on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the bit size. The setting range can be set from 1 to 8.

(16) Middle Field 3

Click on the “Middle Field 3” input field to open the numeric keypad to enter the middle field 3. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the middle field 3. The setting range can be set from 0 to 32.

(17) End Field

This parameter setting is valid only for end field triggering. Click on the “End Field” input field to open the numeric keypad to enter the end field. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the end field. The setting range can be set from 0 to 32.

(18) Inter-frame Space

Click on the “Inter-frame Space” input field to open the numeric keypad to enter the inter-frame space. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the inter-frame space. The setting range can be set from 0 to 32.

8.26. SENT Triggering

(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “SENT” to configure the trigger settings.

Trigger

Type: SENT Force Mode: Auto Normal Single

Source: C1 Level: 188.00mV Mode: Fast Slow

CLK Cycle: 3.00 μs TOL: 30.000%

Half Count: 6 Pause Mode: On DS Format: Half Fast CH

When: S&D&CRC Data SEG: 554 State Data: C

CRC Data: 2

☒ AdjustSensitivity Sensitivity: 50%

Holdoff: 80.000 ns Noise Reject: Off

(2) Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) Level

Double-click on the “Level” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the Multipurpose A rotary knob to adjust the trigger level; or press the trigger Position rotary knob on the right side of the front panel to change the trigger level.

(4) Clock Period

Tap to select the “Clock Period”, use the Multipurpose A rotary knob to change the clock period. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, double-click on the “Clock Period” input field, use the Multipurpose A rotary knob to adjust the clock period. The setting rang can be set from 500 ns to 300 μs.

(5) Tolerance

Set the percentage tolerance to specify a percentage tolerance for determining whether the sync pulse is valid for decoding data. If the time of the measured sync pulse is within the percentage tolerance of the rated clock period, then the decoding will continue; otherwise, the sync pulse causes an error and data decoding will not be performed. The tolerance range can be set from 3% to 30%.

(6) Half Byte

Set the half byte for fast channel message, double-click on “Half Byte” input field to open the numeric keypad to set the half byte. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the half byte. The setting range can be set from 1 to 6.

(7) Pause Mode

Click on the “Pause Mode” to set whether there is a pause pulse between the fast channel messages. It can be switched to ON or OFF.

- OFF: There is no pause pulse between the fast channel messages.

There is no idle time on the SENT serial bus without pause pulses. This means that during normal operation the fast channel decode line shows a continuous stream of packets, i.e. one packet closes, and a new packet opens immediately.

- ON: Add a pause pulse between the fast channel messages, so that the frames arrive at equal intervals.

If there is a pause pulse (switch on), the idle time will display between the messages.

(8) Mode

Click on the “Mode” to switch the trigger signal mode to fast or slow.

(9) Trigger Condition

The trigger condition can be set when the fast mode is selected, i.e. set the trigger condition under SENT fast mode.

When synchronization, state, data, CRC, state and data, state+data+CRC, fast CRC error, or continuous pulse error is selected, the corresponding menus can be configured.

- a. Synchronization: Triggered on the synchronization data.
- b. State: The state will be triggered when the condition is met.

When the state data is selected, the state data menu can be configured.

- State data: Double-click on the “state data” input field to open the numeric keypad to enter the state data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the state data.

- c. Data: Triggered when the condition is met.

When the half byte, data field, or data field is selected, the corresponding menus can be configured.

- Half byte: Double-click on the “Half Byte” input field to open the numeric keypad to set the half byte. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary

knob to adjust the half byte. Trigger half byte ≤ Half byte. The setting range can be set from 1 to 6.

- Data field: Double-click on the “Data Field” input field to open the numeric keypad to set the data field. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data field.
 - Data field format: Click on the “Data Field Format” to set the format to half byte or fast channel.
 - Half byte: Triggered according to the set “Half Byte”.
 - Fast channel: Triggered according to the fast channel data field.
- d. CRC: CRC data will be triggered when the condition is met.

When the CRC data is selected, the CRC data menu can be configured.

- CRC data: Double-click on the “CRC Data” input field to open the numeric keypad to set the CRC data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust the CRC data.
- e. State and data: The oscilloscope will be generated when the state and data meet the condition.
- When the half byte, data field, data field format, or state data is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (9) Trigger Condition “*State*” and “*Data*” mentioned above.
- f. State + data + CRC: The oscilloscope will be generated when the state, data and CRC meet the condition.
- When the half byte, data field, data field format, state data, or CRC data is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (9) Trigger Condition “*State*”, “*Data*”, and “*CRC*” mentioned above.
- g. Fast CRC error: Triggered on fast CRC error.
- h. Continuous pulse error: Triggered on continuous pulse error.

(10) Frame Type

“Frame Type” can be set when the mode is slow mode. Click on the “Frame Type” to switch the trigger signal mode to A or B.

(11) Trigger Condition for Slow Speed

“Trigger Condition for Slow Speed” can be set when the mode is slow, i.e. set the trigger condition for slow SENT signal.

When the synchronization, short ID, short data, short CRC, short ID and data, enhanced ID,

enhanced data, enhanced CRC, enhanced ID and data, or slow channel CRC error is selected, the corresponding menus can be configured.

- a. Synchronization: Triggered on the synchronization data.
- b. Short ID: The oscilloscope will be generated when short ID meets the condition.

When the short ID menu is selected, the short ID menu can be configured.

- Short ID: Double-click on the “Short ID” input field to open the numeric keypad to set the short ID. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust the short ID.

- c. Short data: The oscilloscope will be generated when short data meets the condition. When the short data is selected, the short data menu can be configured.

- Short data: Double-click on the “Short Data” input field to open the numeric keypad to set the short data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust the short data.

- d. Short CRC: The oscilloscope will be generated when short CRC meets the condition. When the short CRC is selected, the short CRC menu can be configured.

- Short CRC: Double-click on the “Short CRC” input field to open the numeric keypad to set the short CRC. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose A rotary knob to adjust the short CRC.

- e. Short ID+ data: The oscilloscope will be generated when short ID and short data meet the condition.

When the short ID or short data is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (11) Trigger Condition “*Short ID*” and “*Short Data*” mentioned above.

- f. Enhanced ID: The oscilloscope will be generated when enhanced ID meets the condition. When the enhanced ID is selected, the enhanced ID menu can be configured.

- Enhanced ID: Double-click on the “Enhanced ID” input field to open the numeric keypad to set the enhanced ID. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the enhanced ID.

- g. Enhanced data: The oscilloscope will be generated when enhanced data meets the condition.


When the enhanced data is selected, the enhanced data menu can be configured.

- Enhanced data: Double-click on the “Enhanced Data” input field to open the numeric keypad to set the enhanced data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the enhanced data.
- h. Enhanced CRC: The oscilloscope will be generated when enhanced CRC meets the condition. When the enhanced CRC is selected, the enhanced CRC menu can be configured.
 - Enhanced CRC: Double-click on the “Enhanced CRC” input field to open the numeric keypad to set the enhanced CRC. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the enhanced CRC.
- i. Enhanced ID+ data: The oscilloscope will be generated when enhanced ID and enhanced CRC meet the condition. When the enhanced ID or enhanced CRC is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (11) Trigger Condition “*Enhanced ID*” and “*Enhanced data*” mentioned above.
- j. Slow channel CRC error: Triggered on slow channel CRC error.

8.27. ARINC429 Triggering

(1) Trigger Type

Press the Menu softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “ARINC429” to configure the trigger settings.



(2) Source

Click on the “Source” to select C1 - C4. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) High/Low Level

Double-click on “High Level (Low Level)” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the Multipurpose A rotary knob to adjust the trigger level, or press the trigger Position rotary knob on the right side of the front panel to switch the selected trigger level (the selected threshold is displayed in full line) and then rotate rotary knob to change the trigger level.

(4) Speed

Click on the “Speed” to set the transmission rate to high (100kb/s), low (12.5kb/s), or custom.

(5) Trigger Condition

- a. Start bit: Triggered on the start bit of frame.
- b. End bit: Triggered on the end bit of frame.
- c. Label: Triggered on when the specified label occurs.

When the label menu is selected, the label menu can be configured.

- Label: Double-click on the “Label” input field to open the numeric keypad to set the label. For details on the use of the numeric keypad, refer to the section of [5.8](#)

[Parameter Setting](#). Alternatively, use the [Multipurpose B](#) rotary knob to move the selected cursor, and use the [Multipurpose A](#) rotary knob to adjust the label. The range can be set from 00 to FF.

- d. SDI: Triggered on when the specified SDI occurs.

When the SDI is selected, the SDI menu can be configured.

- SDI: Double-click on the “SDI” input field to open the numeric keypad to set the label. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the [Multipurpose A](#) rotary knob to adjust the SDI. The range can be set from 0 to 3.

- e. Data: The waveform will be triggered when data acquired by ARINC429 protocol. It can help the user to quickly find the transmission signal that the specific data they are interested in.

When the data is selected, the data menu can be configured.

- Data: Double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the [Multipurpose B](#) rotary knob to move the selected cursor, and use the [Multipurpose A](#) rotary knob to adjust the data. The data range can be set from 00000 to 7FFFF.

- f. SSM: The waveform will be triggered when symbol state matrix is the same as custom symbol state matrix.

When the SSM is selected, the SSM menu can be configured.

- SSM: Double-click on “SSM” input field to open the numeric keypad to set the SSM. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the [Multipurpose A](#) rotary knob to adjust the SSM. The range can be set from 0 to 3.


- g. Label + bit: The oscilloscope will be generated when the specified label and other fields. When the label, data, SSM, or SDI is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (5) Trigger Condition “Address”, “SDI”, “Data”, and “SSM” mentioned above.

- h. Parity check error: The oscilloscope will be generated when a parity check error occurs.
- i. Bit error: The oscilloscope will be generated when a bit error occurs.
- j. Interval error: The oscilloscope will be generated when an interval error occurs.
- k. All error: The oscilloscope will be generated when one of the above errors occurs.

8.28. 1-WIRE Triggering

(1) Trigger Type

Press the **Menu** softkey on the front panel or tap the T trigger label at the top to open the “Trigger” menu. Tap “Trigger Type” to open the dropdown menu, then select “1-WIRE” to configure the trigger settings.



(2) Source

Click on the “Source” to select C1-C4 or D0-D15. For more details on Trigger Source, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

(3) Level

Double-click on the “Level” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the Multipurpose A rotary knob to adjust the trigger level; or press the trigger Position rotary knob on the right side of the front panel to change the trigger level.

When the trigger level is changed, a dotted line appears on the screen indicating the current trigger level. Once the change is stopped, the dotted line of the trigger level disappears after about 2 seconds.

(4) Speed Mode

Click on the “Speed Mode” to set the signal mode to standard or drive.

(5) Trigger Condition

- a. Start field: Triggers on the start field.
- b. Command field: Triggers when the trigger command field is detected. When the trigger command field is selected, the trigger command can be configured.
 - Match (55h): Triggers when the ROM command is 55h.
 - Read (33h): Triggers when the ROM command is 33h.
 - Skip (CCh): Triggers when the ROM command is CCh.
 - Search (F0h): Triggers when the ROM command is F0h.
 - Alarm Search (ECh): Triggers when the ROM command is ECh.
- c. Device command field: Triggers when the device command field is detected. When the device command is selected, the device command can be configured.
 - Device command: Double-click on the “Device Command” input field to open the numeric keypad to set the command. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the command. The range can be set from 00 to FF.
- d. ID: Triggered on the data frame that matches the specified ID. When the ID is selected, the ID can be configured.
 - ID: Double-click on the “ID” input field to open the numeric keypad to set the ID. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the ID. The range can be set from 0000000000000000 to FFFFFFFFFFFFFFFF.
- e. Data: The waveform is generated when the collected data matches the custom data. It can help the user to quickly find the transmission signal that the specific data they are interested in. When the data is selected, the corresponding menus can be configured.
 - Data: Double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data. The range can be set from 00 to FF.
- f. Custom: Triggers when the custom instructions and the interval bit width are satisfied. When the command 1, command 2, or interval bit width is selected, the corresponding menus can be configured.
 - Command 1: Double-click the "Command 1" input field to open the numeric keypad to

set the command 1. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust command 1. The range can be set from 00 to FF.

- Command 2: Double-click the "Command 2" input field to open the numeric keypad to set the command 2. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust command 2. The range can be set from 00 to FF.
- Interval bit width: Double-click the "Interval Bit Width" input field to open the numeric keypad to set the interval bit width. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the interval bit width. The range can be set from 0 to 255.

8.29. I3C Triggering

(1) Trigger Type

Press the **Menu** softkey on the front panel or tap the **T** trigger label at the top to open the "Trigger" menu. Tap "Trigger Type" to open the dropdown menu, then select "I3C" to configure the trigger settings.



(2) Source Setting

Set the clock source and data source. The source can only trigger stably if the selected channel has a connected signal and is set as the trigger source.

■ Clock Source

Click on the “Clock Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

■ Data Source

Click on the “Data Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

(3) Level Setting

Click on the “Level A, Level B”, and double-click on “Level” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the Multipurpose A rotary knob to adjust the trigger level, or press the trigger Position rotary knob on the right side of the front panel to switch the selected trigger level (the selected threshold is displayed in full line) and then rotate rotary knob to change the trigger level.

(4) Operating Direction

Click on the “Operating Direction” to select “Read” or “Write”.

- a. Write: Triggers when the I3C protocol “Read/write” bit is set to “Write”.
- b. Read: Triggers when the I3C protocol “Read/write” bit is set to “Read”.

(5) Mode

Specifies the data transmission protocol used in I3C communication. Click on the “Mode” to select either I2C or I3C.

- a. I2C: Operates in traditional I2C mode.
- b. I3C: Supports both single data rate (SDR) and high data rate (HDR) modes.

(6) Trigger Condition

Available trigger conditions vary depending on the selected mode.

① When I2C is selected, the following trigger conditions can be configured:

- a. SDR Start: Triggers at the start of an I2C message.
- b. SDR Restart: Triggers at a restart condition, that is, when a start signal appears again before a stop signal.
- c. SDR Stop: Triggers when a stop bit is detected. This occurs when SCL is high and SDA transitions from low to high.

- d. SDR Address: Triggers when the detected communication address matches the user-defined address value. When the operating direction or address is selected, the corresponding menus can be configured.
 - Operating direction: Specifies the read/write bit of the protocol. Set to either write or read.
 - Address: Double-click on the “Address” input field to open the numeric keypad to set the address. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust address. The range can be set from 00 to 7F.
- e. SDR data: The waveform will be generated when data acquired by the oscilloscope is the same as custom data. It can help the user to quickly find the transmission signal that the specific data they are interested in. When the byte length or data is selected, the corresponding menus can be configured.

When the byte length or data is selected, the corresponding menus can be configured.

- Byte length: Click on the “Byte Length” input field to set the byte length for the specified data. The byte length range can be set from 1 to 4.
 - Data: The data is related to the frame length, double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data value. The range can be set from 00 to FFFFFFFF (8Fs).
- f. SDR Address & Data: The oscilloscope will be generated when the same address is found during the transmission and the data relation is conform to the set condition. With this trigger condition, it can easily generate the specified address and data trigger of I²C and helpful for the user to analyze the transmission.

When the address length, address, byte length, or data is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (6) Trigger Condition “*SDR Address*” and “*SDR Data*” mentioned above.
 - g. SDR loss confirmed: In I²C protocol, every time after 8 bits information is transmitted, the data receiver needs to send an acknowledgement signal, which is the ACK bit in the above figure when the SCL is in the high level and the SDA signal is low. The loss trigger will occur while the SCL and SDA signal at the ACK bit are both high.

② When I3C is selected, the following trigger conditions can be configured:

- a. SDR start: Triggers at the start of a single data rate (SDR) message.
- b. SDR restart: Triggers at the restart point of an SDR message, that is, when a start condition appears again after an initial start but before a stop condition.
- c. SDR stop: Triggers when the stop bit of an SDR message appears. This occurs when SCL is high and the SDA signal transitions from low to high.
- d. SDR global broadcast address: Triggers when the SDR global broadcast address 7Eh is detected.
- e. SDR universal command code: The waveform will be triggered when universal command code acquired by the oscilloscope is the same as customized universal command code. When the universal command code is selected, the corresponding menu can be configured.
 - Universal command code: Double-click on the “Universal Command Code” input field to open the numeric keypad to set the universal command code. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the [Multipurpose B](#) rotary knob to move the selected cursor, and use the [Multipurpose A](#) rotary knob to adjust the universal command code. The range can be set from 00 to FF.
- f. SDR address: The oscilloscope will be generated when the communication address is the same as the user setting address. It can help the user to quickly locate the address transmission. When the operating direction or address is selected, the corresponding menus can be configured.
 - Operating direction: Specifies the read/write bit of the protocol. Set to either write or read.
 - Address: Double-click on the “Address” input field to open the numeric keypad to set the address. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the [Multipurpose B](#) rotary knob to move the selected cursor, and use the [Multipurpose A](#) rotary knob to adjust address. The range can be set from 00 to 7F.
- g. SDR data: Triggers when the acquired data matches the custom data. It can help the user to quickly find the transmission signal that the specific data they are interested in. When the byte length or data is selected, the corresponding menus can be configured.
 - Byte length: Click on the “Byte Length” input field to set the byte length for the specified data. The byte length range can be set from 1 to 4.
 - Data: The data is related to the frame length, double-click on the “Data” input field to open the numeric keypad to set the data. For details on the use of the numeric

keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data value. The range can be set from 00 to FFFFFFFF (8Fs).

- h. SDR Address & Data: Triggers when the same address is found during the transmission and the data relation matches the set condition. With this trigger condition, it can easily generate the specified address and data trigger of I³C and helpful for the user to analyze the transmission.

When the address length, address, byte length, or data is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (6) Trigger Condition “*SDR Address*” and “*SDR Data*” mentioned above.

- i. SDR target to end of a read: Triggers when the receiver initiates an end-read operation at the “T” bit in SDR read operation mode.
- j. SDR target reset: Triggers when a target reset command is detected.
- k. SDR acknowledgment loss: In the I²C protocol, after each 8-bit transmission, the data receiver must send an acknowledgment signal. During the acknowledgment bit, when SCL is high, the SDA signal should be low. This trigger activates when, at the acknowledgment bit moment, both SCL and SDA are high, indicating a loss of acknowledgment.
- l. SDR parity error: Triggers when a parity error is detected at the “T” bit, which serves as the parity bit in SDR mode.
- m. HDR entry mode: Triggers when the oscilloscope detects a transition from SDR mode to HDR mode.
- n. HDR restart mode: Triggers when an HDR restart command is detected in HDR mode.
- o. HDR exit mode: Triggers when an HDR exit command is detected in HDR mode.
- p. HDR global broadcast address: Triggers when the HDR global broadcast address 7Eh is detected.
- q. HDR universal command code: The waveform will be triggered when universal command code acquired by the oscilloscope is the same as customized universal command code. When the universal command code is selected, the corresponding menu can be configured.
 - Universal command code: Double-click on the “Universal Command Code” input field to open the numeric keypad to set the universal command code. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and

- use the Multipurpose A rotary knob to adjust the universal command code. The range can be set from 00 to FF.
- r. HDR command word: The waveform will be triggered when command word acquired by the oscilloscope is the same as customized command word. When the operating direction or command word is selected, the corresponding menu can be configured.
- Operating direction: Specifies the read/write bit of the protocol. Set to either write or read.
 - Command word: Double-click on the "Command Word" input field to open the numeric keypad to set the command word. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the command word. The range can be set from 00 to 7FFF.
- s. HDR data word: The waveform will be generated when data acquired by the oscilloscope is the same as custom data. When the byte length or data is selected, the corresponding menus can be configured.
- Byte length: Double-click on the "Byte Length" input field to open the numeric keypad to set the command word. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the byte length. The range can be set from 1 to 2.
 - Data: The data is related to the byte length, double-click on the "Data" input field to open the numeric keypad to set the data. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust data. The range can be set from 00 to FFFF.
- t. HDR command word & data word: This trigger condition is activated when both the command word and data word during transmission meet the specified conditions. When the operating direction, command word, byte length, or data is selected, the corresponding menus can be configured. For the setting of each parameter, refer to (6) Trigger Condition "*HDR Command Word*" and "*HDR Data Word*" mentioned above.
- u. HDR acknowledgment loss / interruption: Triggers when a NACK (Negative Acknowledgment) is detected at the "Preamble" bit after the command field or data field, or when the controller is interrupted in HDR mode.
- v. HDR parity error: Triggers when a parity error is detected during HDR transmission.

- w. HDR CRC error: Triggers when a CRC (Cyclic Redundancy Check) error is detected during HDR transmission.

8.30. Zone Triggering

For complicated and volatile circuit signals in circuit debugging, the oscilloscope with high waveform capture rate can easily observe fleeting accidental abnormal signal. If users want to separate the abnormal signal from complicated and volatile circuit and to stable triggered. It may take a lot of time to learn the use of some advanced trigger, and even so, some more powerful advanced trigger also cannot be fully triggered.

MSO5000HD series adds the screen touch regional trigger function, it's helpful for users to get the use of advanced trigger. Zone triggering function is very easy to use. Users only need to open rectangle drawing function to draw one or two rectangle areas in the corresponding signal, it can quickly separate it and for observing signal. Zone triggering can be combined with basic trigger, advanced trigger and protocol trigger function, and it also supports decoding, waveform recording and pass/fail test. It's handy for debugging complicated signals.

Area Trigger Menu					
A Enable	Off	On	B Enable	Off	On
Source A	C1 ▼		Source B	C1 ▼	
Area A	Cross	No Cross	Area B	Cross	No Cross
Ax0	233.11ns		Bx0	0.000s	
Ax1	1.793μs		Bx1	0.000s	
Ay0	85.039mV		By0	0.000V	
Ay1	-55.643mV		By1	0.000V	

Zone triggering provides two rectangle areas: Zone A and Zone B. Both regions support setting the region trigger condition to intersection or non-intersection; and the two regions support setting the corresponding enable sources C1 - C4.

- (1) "Rectangle drawing" setting menu: Enable Zone A, Source A, Zone A, enable Zone B, Source B, and Zone B.

- a. Enable Zone A: Toggle Zone A to ON or OFF.
If there is a zone box on the screen, ON: displays the zone box, OFF: hides the region box.
- b. Source A: Set the source of Zone A, it can set to C1 - C4.
- c. Zone A: Set whether Zone A is intersected with Source A.
- d. Enable Zone B: Toggle Zone B to ON or OFF.
If there is a region box on the screen, ON: displays the region box, OFF: hides the region box.
- e. Source B: Set the source of Zone B, it can be set to C1 - C4.
- f. Zone B: Set whether Zone B is intersected with Source B.

(2) Zone box setting menu: Cancel, 1: intersection, 1: non-intersection, 2: intersection, 2: non-intersection.

- a. Cancel: Close the currently drawn zone and cancel the condition setting.
- b. A: intersection: The currently drawn region as Zone A, condition: Zone A will trigger if it intersects with the waveform and will not trigger if it does not intersect the waveform.
- c. A: non-intersection: The currently drawn region as Zone A, condition: Zone A will trigger if it does not intersect the waveform and will not trigger if it does intersect the waveform.
- d. B: intersection: The currently drawn region as Zone B, condition: Zone B will trigger if it intersects with the waveform and will not trigger if it does not intersect the waveform.
- e. B: non-intersection: The currently drawn region as Zone B, condition: Zone B will trigger if it does not intersect the waveform and will not trigger if it does intersect the waveform.

(3) Zone boundary setting

Area trigger boxes can be quickly drawn with gestures, and for boundary fine-tuning, check the corresponding boundary input box and use the Multipurpose rotary knob to modify the data values.

- a. Ax0, Ax1, Ay0, and Ay1 represent the left, right, top, and bottom boundaries of zone A, respectively.
- b. Bx0, Bx1, By0, By1 represent the left, right, top, and bottom boundaries of zone B, respectively.

Intersecting areas display blue borders, while non-intersecting areas display gray borders. The setting menu can be displayed by clicking the region trigger box on the screen. Or the user can touch the horizontal position and vertical position of the region trigger box in the moving area. When adjusting the time base scale and volts/div of the waveform, the region trigger box will expand and compress accordingly.

Open the region trigger on the abnormal signal, as shown in the following figure.



If the currently selected region already exists, then the current region trigger information will replace the original region trigger message and the region trigger box will be closed. When the instrument is rebooted up, the region trigger setting will not be saved.

Note: If both area A and area B are enabled simultaneously, the "AND" operation becomes the final trigger condition.

9. Protocol Decoding




- [RS23S Decoding](#)
- [I²C Decoding](#)
- [SPI Decoding](#)
- [FlexRay Decoding](#)
- [CAN Decoding](#)
- [CAN-FD Decoding](#)
- [CAN-XL Decoding](#)
- [LIN Decoding](#)
- [Audio Decoding](#)
- [1553B Decoding](#)
- [Manchester Decoding](#)
- [SENT Decoding](#)
- [ARINC429 Decoding](#)
- [1-WIRE Decoding](#)
- [I3C Decoding](#)

Users can easily find errors, debug hardware and accelerate the development progress through the protocol decoding, to provide a guarantee of high speed and high quality to complete the project. MSO5000HD provides four bus decoder modules (Decoder 1, Decoder 2, Decoder 3, and Decoder 4) to decode common protocols for analogue channel input signals. MSO5000HD has protocol decoding of RS232, I²C, SPI, CAN, CAN-FD, CAN-XL, LIN, FlexRay, Audio, Manchester, SNET, ARINC429, 1-Wire, and I3C.

As Decode 1, Decode 2, Decode 3, and Decode 4 have the same decoding function and setting method, this chapter uses Decode 1 as an example.

Access the decoding setting menu using the following steps.

- Press the key Bus on the front panel to enter the decoding setting menu.

- Click the Home icon  at the top-right of the screen of the screen, click the decoding icon  to enter the decoding setting menu.
- If the decoding function is added in the toolbar, click the decoding icon  at the top-right of the screen of the screen to enter the decoding setting menu.


9.1. RS232 Decoding

RS232 is an asynchronous transmission standard interface established by Electronic Industries Association. It usually includes two application formats DB-9 or DB-25. It is suitable for the communication that the data transmission rate within the range 0-29491200/s.

It is widely used in microcomputer interface, the data to be transmitted is combined into a specified set of serial bits according to the protocol rules and sent it in an asynchronous serial way.

The data to be transmitted for each time, composed by the following rules.


Send one start bit first, and send 5-8 data bits, and send optional parity check bit, and send one or two stop bits at last. The number of data bits is agreed by both communicating parties, it can be 5-8 bits, with no parity check bit, odd parity check bit, or even parity check bit. The stop bit can be set to one bit or two bits. In the following description, a transmission of a data string is referred to as a frame.



(1) Decoding Menu Setting

a. Protocol Type

Click on the "Protocol Type" to select "UART/RS232".



b. Source

Click on the “Source” to select CH1-CH4 or D0 - D15. The current source is displayed at the top-right of the screen of the screen. When the digital channel is enabled, the source can be set to D0 - D15 and displayed.

Note: The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

c. Threshold

Set the threshold of source. Tap to select the “Threshold” input field, rotate the Multipurpose A rotary knob to adjust the threshold. Alternatively, double-click on the “Threshold” input field to open the numeric keypad to set the threshold. The threshold range is related to the vertical scale and vertical offset of the source.

d. Polarity

Click on the “Polarity” to select positive or negative.

- Negative: The reversed polarity of logic level, i.e. the high level is 0 and the low level is 1.
- Positive: The normal polarity of logic level, i.e. the high level is 1 and the low level is 0.

e. Parity Check

Set the parity check of data transmission. Click on the “Parity Check” to select none, even parity check, or odd parity check.

f. Data Bit

Set the data bit width for the specified decoding RS232 protocol signal. Click on the “Data

Bit” to select 5 bits, 6 bits, 7 bits, or 8 bits.

g. Bit Sequence

Set the data bit sequence for RS232 protocol signal. Click on the “Bit Sequence” to select MSB or LSB.

- MSB: The Most Significant Bit, i.e., the bit with the highest value in a sequence, transmitted first.
- LSB: The Least Significant Bit, i.e., the bit with the lowest value in a sequence, transmitted last.

h. Stop Bit

Set the stop bit for each data, click on the “Stop Bit” to select 1 bit or 2 bits.

i. Bitrate

When RS232 communication is asynchronous transmission communication, no accompanying clock signal during the data transmission process, to solve the determination of data bits, the protocol requires that the two sides of communication to agree on the bit rate. Generally, the bit rate is defined as the number of bits that can be transmitted for 1 s time, for example, 9600 bps means that 9600 bits can be transmitted for 1 s. The bitrate is not directly equal to the effective data transmission rate. Note that the start bit, data bit, checksum and stop bit are all counted as bit bits, so the bitrate is not directly equal to the effective data rate. The oscilloscope will set the bitrate according to the bitrate form bit sampling.

Bitrate can be set to 2400 bps, 4800 bps, 9600 bps, 19200 bps, 38400 bps, 57600 bps, 115200 bps, or a custom bitrate. Open the numeric keypad to set the custom bitrate.

It is recommended to make reasonable settings according to your RS232 communication hardware and software. Due to the basic model of this transmission protocol, RS232 protocol is usually used in short distance (less than 20 m), low speed (less than 1 Mbps) transmission occasions, and the communication outside of this range is susceptible to interference and becomes unreliable.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to open the numeric keypad to set the position. The range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same

with the decoding type.


(6) Copy Trigger Settings

When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.

9.2. I2C Decoding

I2C trigger is usually used to connect microcontrollers and peripheral devices, it's widely used in microelectronics area. This bus protocol has two lines to transmit, one line is serial data SDA, and another line is serial clock SCL. Use a master-slave system for communication, enabling two-way communication between the master and slave computers.


This bus is the bus of multiple masters, preventing data corruption through conflict demodulation and arbitration mechanisms. It is worth noting that the I²C bus has two address bit width, 7 bits and 10 bits, 10 bits and 7 bits address are compatible and can be used in combination. SCL and SDA on the I²C bus can both be connected to the positive supply via a pull-up resistor. When the bus is idle, both lines are high level. When any device on the bus outputs a low level, it causes the bus signal to become low, i.e. a logical "AND" between the signals of multiple devices. This special logical relationship is the key to realizing bus arbitration. The protocol requires the data signal SDA to remain stable while the clock signal SCL is high, and data is usually transmitted in MSB form, as shown in the following figure.



(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “I²C”.



b. Source Setting

Set the clock source and data source. The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

■ Clock Source

Click on the “Clock Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

■ Data Source

Click on the “Data Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

c. Threshold Setting

Click to select “SCL threshold, SDA threshold”, and double-click on the “Threshold” input field to open the numeric keypad to set the threshold. Alternatively, rotate the Multipurpose A rotary knob to adjust the threshold.

d. Address Length

Set the address bit width of I²C signal, click on the “Address Length” to select 7 bits or 10 bits.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to open the numeric keypad to set the position. The range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.


d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display current protocol type.

When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive

(when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings

When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.

9.3. SPI Decoding


SPI (Serial Peripheral Interface) allows the host to communicate with peripheral devices in a serial way. It's full-duplex and synchronous communication bus. It usually uses 4 signal connection line, MOSI: data output from master device, data input from slave device; MISO: data input from master device, data output from slave device; SCLK: clock signal is generated from master device; CS: chip select enable signal from slave device.

The SPI interface is mainly used for synchronous serial data transfer between the host and low-speed peripherals. Data is transferred bit by bit under the shift pulse of the master device, and the transfer format is MSB. SPI interface is widely used because it does not require slave address addressing, it is full duplex communication and the protocol is simple. The transmission of SPI protocol is shown in the following figure

(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “SPI”.



b. Source Setting

Set the clock source, data source, and CS source. The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

■ Clock Source

Click on the “Clock Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

■ Data Source

Click on the “Data Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

■ Chip Source

Click on the “Chip Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

c. Edge Setting

■ Clock Polarity

Click on the “Clock Polarity” to select “Positive” or “Negative”.

Positive: Set to trigger on the positive of clock signal.

Negative: Set to trigger on the negative of clock signal.

■ CS Polarity

Click on the “CS Polarity” to select “Positive” or “Negative”.

Positive: It is set to 1 if the signal is greater than the threshold, otherwise, it is 0.

Negative: It is set to 1 if 1 when the signal is less than the threshold, otherwise, it is 0.

■ Data polarity

Click on the “Data Polarity” to select “Positive” or “Negative”.

Positive: It is set to 1 if the signal is greater than the threshold, otherwise, it is 0.

Negative: It is set to 1 if 1 when the signal is less than the threshold, otherwise, it is 0.

d. Threshold Setting

Click to select “Threshold A, Threshold B, or Threshold C”, and double-click on the “Threshold” input field to open the numeric keypad to set the threshold. Alternatively, rotate the Multipurpose A rotary knob to adjust the threshold.

e. Mode

Click on the “Mode” to select SPI. When SPI is selected, timeout and CS menus can be configured.

■ Timeout: After the clock signal (CLK) remains idle for the specified time, the oscilloscope triggers when it searches for data that meets the trigger conditions (MISO).

■ CS: When the CS is valid, the oscilloscope triggers when it searches for data that meets the trigger conditions (SDA).

f. Bit Sequence

Set the bit sequence for RS232, click on the “Bit Sequence” to select MSB or LSB.

■ MSB: The Most Significant Bit, i.e., the bit with the highest value in a sequence, transmitted first.

■ LSB: The Least Significant Bit, i.e., the bit with the lowest value in a sequence, transmitted last.

g. Bit Width

Set the bit width for each data unit in the SPI protocol signal. Double-click on the “Bit Width” input field to set the bit width. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the bit width. The setting range can be set from 4 to 32.

h. Timeout

Double-click on the “Timeout” input field to set the timeout. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the

Multipurpose A rotary knob to adjust the timeout. The setting range can be set from 3.2 ns to 1 s.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings

When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.


9.4. FlexRay Decoding

FlexRay is a differential serial bus configured with three consecutive segments (header, payload and tail). The oscilloscope samples the FlexRay signal at the specified sampling position and determines whether each data point is a logic "1" or a logic "0" based on a set threshold level. FlexRay decoding requires the signal type and rate to be specified.

(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “FlexRay”.



b. Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

Note: The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

c. Polarity

Click on the “Polarity” to select BDiff, BP, or BM.

d. Threshold

Double-click on the “Threshold” input field to open the numeric keypad to set the threshold. Alternatively, rotate the Multipurpose A rotary knob to adjust the threshold.

e. Channel Type

Click on the “Channel Type” to select A or B.

f. Bitrate

Click on the “Bitrate” to select 2.5 Mbps, 5 Mbps, 10 Mbp, or a custom bitrate.

If "Custom" is selected, a custom bitrate can be entered.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using [Multipurpose A](#) rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings


When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.

9.5. CAN Decoding

(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “CAN”.



b. Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

Note: The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

c. Threshold

Double-click on the “Threshold” input field to open the numeric keypad to set the threshold. Alternatively, rotate the Multipurpose A rotary knob to adjust the threshold.

When the threshold is changed, a dotted line appears on the screen indicating the current trigger level. Once the change is stopped, the dotted line of the threshold disappears after about 2 seconds.

d. Signal Type

Select whether the current signal accessed by the source is a high data line signal or a low data line signal. Click on the “Signal Type” to select “CAN_H”, or “CAN_L”.

e. Bitrate

Select the bitrate for CAN serial bus data. Click on the “Bitrate” to select 10 kbps, 19.2 kbps, 20 kbps, 33.3 kbps, 38.4 kbps, 50 kbps, 57.6 kbps, 62.5 kbps, 83.3 kbps, 100 kbps, 115.2 kbps, 125 kbps, 230.4 kbps, 250 kbps, 490.8 kbps, 500 kbps, 800 kbps, 921.6 kbps, 1 Mbps, 2 Mbps, 3 Mbps, 4 Mbps, 5 Mbps, or a custom bitrate.

If "Custom" is selected, a custom bitrate can be entered.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings


When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.

9.6. CAN-FD Decoding

(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “CAN-FD”.



b. Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

Note: The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

c. Threshold

Double-click on the “Threshold” input field to open the numeric keypad to set the threshold. Alternatively, rotate the Multipurpose A rotary knob to adjust the threshold.

When the threshold is changed, a dotted line appears on the screen indicating the current threshold. If the change is stopped, the dotted line of the threshold disappears after about 2 seconds.

d. Signal Type

Select whether the current signal accessed by the source is a high data line signal or a low data line signal. Click on the “Signal Type” to select “CAN_H” or “CAN_L”.

e. Bitrate

Select the bitrate for CAN-FD serial bus data. Click on the “Bitrate” to select 10 kbps, 19.2 kbps, 20 kbps, 33.3 kbps, 38.4 kbps, 50 kbps, 57.6 kbps, 62.5 kbps, 83.3 kbps, 100 kbps, 115.2 kbps, 125 kbps, 230.4 kbps, 250 kbps, 490.8 kbps, 500 kbps, 800 kbps, 921.6 kbps, 1 Mbps, 2 Mbps, 3 Mbps, 4 Mbps, 5 Mbps, or a custom bitrate.

If "Custom" is selected, a custom bitrate can be entered.

f. FD Bitrate

Select the FD bitrate for CAN-FD serial bus data, click on the “Bitrate” to select 250 kbps, 500 kbps, 800 kbps, 1 Mbps, 1.5 Mbps, 2 Mbps, 4 Mbps, 6 Mbps, 8 Mbps or a custom bitrate.

g. Sampling Position

The sampling position is the point in the bit time where the oscilloscope samples the bit level. It is expressed as a percentage of the “Time from bit start to sample point” and the “Bit Time”.

Click on the “Sampling Position” input field to open the numeric keypad to set the sampling position. Alternatively, rotate the Multipurpose A rotary knob to adjust the sampling position. The range can be set from 30% to 90%.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.


When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.

9.7. CAN - XL Decoding

(1) Decoding Menu Setting

a. Protocol Type

Click on the "Protocol Type" to select "CAN-XL".



b. Source

Click on the "Source" to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

Note: The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

c. Threshold

Double-click on the "Threshold" input field to open the numeric keypad to set the threshold. Alternatively, rotate the Multipurpose A rotary knob to adjust the threshold.

d. Signal Type

Select whether the current signal accessed by the source is a high data line signal or a low data line signal. Click on the "Signal Type" to select "CAN_H" or "CAN_L".

e. Bitrate

Select the bitrate for CAN-XL serial bus data. Click on the "Bitrate" input field to select 10 kbps, 19.2 kbps, 20 kbps, 33.3 kbps, 38.4 kbps, 50 kbps, 57.6 kbps, 62.5 kbps, 83.3 kbps, 100 kbps, 115.2 kbps, 125 kbps, 230.4 kbps, 250 kbps, 490.8 kbps, 500 kbps, 800 kbps,

921.6 kbps, 1 Mbps, 2 Mbps, 3 Mbps, 4 Mbps, 5 Mbps, or a custom bitrate. If "Custom" is selected, a custom bitrate can be entered.

f. FD Bitrate

Select the FD Bitrate for CAN-XL serial bus data. Click on the "FD Bitrate" input field to select 250 kbps, 500 kbps, 800 kbps, 1 Mbps, 1.5 Mbps, 2 Mbps, 4 Mbps, 5 Mbps, 6 Mbps, 8 Mbps, or a custom bitrate. If "Custom" is selected, a custom FD bitrate can be entered.

g. XL Bitrate

Select the XL Bitrate for CAN-XL serial bus data. Click on the "XL Bitrate" input field to select 250 kbps, 500 kbps, 800 kbps, 1 Mbps, 1.5 Mbps, 2 Mbps, 4 Mbps, 5 Mbps, 6 Mbps, 8 Mbps, 10 Mbps, 20 Mbps, or a custom bitrate. If "Custom" is selected, a custom XL bitrate can be entered.

h. Sampling Position

The sampling position is the point in the bit time where the oscilloscope samples the bit level. It is expressed as a percentage of the "Time from bit start to sample point" and the "Bit Time".

Click on the "Sampling Position" input field to open the numeric keypad to set the sampling position. Alternatively, rotate the Multipurpose A rotary knob to adjust the sampling position. The range can be set from 30% to 90%.

(2) Decoding Bus Setting

a. Bus Switch

Click on the "Bus Switch" to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the "Decoding Line" input field to set the position. The setting range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the "Format" input field to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the "Label" to switch on/off the decoding bus label. When the decoding bus label is switched on, it be displayed at the left top and show the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the "Event List" to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon "x" at the top right to

close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings

When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.

9.8. LIN Decoding

(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “LIN”.

The screenshot shows the 'Decode' window with the following settings:

- Bus:** Bus1 (selected)
- Type:** LIN
- Source:** C1
- Threshold:** 560mV
- Bitrate:** 20 kbps
- Data Length:** On
- Display:** On
- Position:** 0
- Polarity:** Negative
- Version:** v2.x
- ID Parity:** Yes
- Data Length:** 8
- Format:** Hex
- Labels:** Off
- Event List:** On
- Buttons:** Trigger, Copy Trigger, Save Event List

b. Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

Note: The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

c. Polarity

Click on the “Polarity” to select the polarity to “Positive” or “Negative”.

d. Threshold

Double-click on “Threshold” input field to open the numeric keypad to set the threshold. Alternatively, rotate the [Multipurpose A](#) rotary knob to adjust the threshold.

When the threshold is changed, a dotted line appears on the screen indicating the current threshold. If the change is stopped, the dotted line of the threshold disappears after about 2 seconds.

e. Version

Click on the “Version” to select the signal version to v1.x, v2.x, or arbitrary.

f. Bitrate

Select the bitrate for LIN, click on the “Bitrate” to select 1.2 kbps, 2.4 kbps, 4.8 kbps, 9.6 kbps, 10.417 kbps, 19.2 kbps, 20 kbps, or a custom bitrate.

If "Custom" is selected, a custom bitrate can be entered.

g. ID Parity check

Set ID Parity check to toggle it ON or OFF.

ON: Includes parity bit and ID.

OFF: Does not include parity bit and ID.

h. Data Length Menu

Set whether to display the data length menu, click on the “Data Length” to toggle it ON or OFF.

ON: Displays the data length menu.

OFF: Hide the data length menu.

i. Data Length

Set LIN data length, double-click on the “Data Length” input field to open the numeric keypad to set the data length. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the data length. The data length can be set from 1 to 8. It is only available when the data length menu is displayed.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings

When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.


9.9. Audio Decoding

Audio (Inter—IC Sound) bus, also known as the Integrated Circuit Built-in Audio Bus, is a bus standard developed by Philips for the transmission of audio data between digital audio devices.

(1) Decoding Menu Setting

a. Protocol Type


Click on the “Protocol Type” to select “Audio”.




b. Format

Click on the “Format” to select standard, left justifying, right justifying, or TDM.


- Standard: MSB of each sampled data is sent first and the LSB is sent last. MSB is displayed on the SDATA line, which at one clock bit clock after the edge of WS transition.




- Left justifying: Data transmission (MSB first) starts at the edge of the WS conversion (without the one-bit delay used by the standard format).



- Right justifying: Data transmission (MSB first) is right justifying with WS.



- TDM: (Time Division Multiplexing) mode can transmit multi-channel data.



c. Bit Sequence

Click on the “Bit Sequence” to select “LSB” or “MSB”. The default is “MSB”.

d. Source Setting

Set the bit clock, bit selection, and data source. The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

■ Bit Clock

Click on the “Bit Clock” to select C1 - C4 or D0 - D15. For more details on *Trigger*

Source, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen. The clock line (SCLK) provides the clock signal for synchronizing audio data transmission.

- Bit Selection

Click on the “Bit Selection” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

The bit selection indicates the audio data of the current transmission is left channel or right channel.

- Data

Click on the “Data” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen. The data line is used to transmit the actual audio data.

- Frame Synchronization

Click on the “Frame Synchronization” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

e. Edge Setting

- Clock Edge

Click on the “Clock” to select “Rising/Falling” edge.

Rising edge: Samples SDA on the rising edge of clock.

Falling edge: Samples SDA on the falling edge of clock.

- WS Polarity

Click on the “WS Polarity” to select “Normal” or “Reverse”. The WS polarity determines the valid level for the bit selection signal. The bit selection signal indicates the start frame and end of frame for the audio data.

- Data Polarity

Click on the “Data Polarity” to select “high=1” or “high=0”.

- Polarity Synchronization

Click on the “Polarity Synchronization” to set the edge for signal synchronization, which can set to “Rising” or “Falling” edge.

f. Threshold

Click to select the threshold of the corresponding source and change the threshold.

Double-click on the “Threshold” input field to open the numeric keypad to set the threshold.

For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).
Alternatively, select the parameter, use the Multipurpose A to adjust the threshold.

g. Bit Size

The bit size can be set when the format is standard, left justifying or right justifying.
Double-click on the “Bit Size” input field to open the numeric keypad to set the bit size. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).
Alternatively, select the parameter, use the Multipurpose A to adjust the bit size. The setting range can be set from 4 to 32.

h. Data Bit of Each Channel

Double-click on the “Data Bit of Each Channel” input field to pop up the numeric keyboard to set this value. For details on the use of the numeric keyboard, refer to the section of [5.8 Parameter Setting](#). Select this parameter and use the Multipurpose rotary knob to change this value. The range of data bit can be set from 4 to 32.

Data bit setting for each channel \leq Clock bit setting for each channel

i. Clock Bit of Each Channel

Double-click on the “Clock Bit of Each Channel” input field to pop up the numeric keyboard to set this value. For details on the use of the numeric keyboard, refer to the section of [5.8 Parameter Setting](#). Select this parameter and use the Multipurpose rotary knob to change this value. The range of clock bit can be set from 4 to 32.

j. Frame of Each Channel

Double-click on the “Frame of Each Channel” input field to pop up the numeric keyboard to set this value. For details on the use of the numeric keyboard, refer to the section of [5.8 Parameter Setting](#). Select this parameter and use the Multipurpose rotary knob to change this value. The range of frames can be set from 2 to 64.

k. Bit Delay

Double-click on the “Bit Delay” input field to pop up the numeric keyboard to set this value. For details on the use of the numeric keyboard, refer to the section of [5.8 Parameter Setting](#). Select this parameter and use the Multipurpose rotary knob to change this value. The range of bit delay can be set from 0 to 31.

Bit delay $<$ Clock bit setting for each channel

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding

line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format


Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings

When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.


9.10. 1553B Decoding

The oscilloscope samples the 1553B signal and determines whether each data point is a logic "1" or "0" based on a set threshold. 1553B decoding requires the data channel source and threshold to be specified.

(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “1553B”.



b. Source

Click on the “Source” to select C1 - C4. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

Note: The decoded data can only be obtained when the signal source is set to the channel

with the connected signal as its source.

c. Polarity

Click on the “Polarity” to select “Positive” or “Negative”. The default is positive.

d. High/Low Threshold

Double-click on “Threshold (High/Low)” input field to open the numeric keypad to set the threshold. Alternatively, rotate the Multipurpose A rotary knob to adjust the threshold. The threshold range is related to the vertical scale and vertical offset of the source.

e. Block Control

Click on the “Block Control” to select “Data” or “Data block” to decoding. The default is data.

f. Format

Click on the “Format” to set command word or state word.

If the format is the command word, the state trigger condition will be hidden.

If the format is the state word, the command trigger condition will be hidden.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings

When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.

9.11. Manchester Decoding

Manchester encoding, also called phase encoding (PE), is a synchronous clock coding technique used by the physical layer to encode the clock and data of a synchronous bit stream. Manchester encoding is used in Ethernet medium systems.

Manchester encoding provides a simple way of encoding simple binary sequences without long cycles and without conversion levels, thus preventing loss of clock synchronization or analogue link bit errors due to low frequency shifts with poor compensation. In this technique, the actual binary data transmitted through the cable is not sent as a sequence of logical 1's or 0's (technically known as Non-Return to Zero (NRZ)). Instead, these bits are converted into a slightly different format, which has many advantages than the use of binary coding.

Manchester coding is commonly used in LAN transmission. Manchester coding is used to encode binary data '0' and '1' by level jumps.

(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “Manchester”.

b. Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

Note: The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

c. Threshold

Double-click on the “Threshold” input field to open the numeric keypad to set the threshold. Alternatively, rotate the Multipurpose A rotary knob to adjust the threshold.

d. Encode Mode

Click on the “Encode Mode” to switch to IEEE or G.E.

- IEEE: “1” indicates that a jump from low to high; “0” indicates that a jump from high to low.
- G.E: “1” indicates that a jump from low to high; “0” indicates that a jump from high to low.

e. Bitrate

Click on the “Bitrate” to select the baud rate of DUT to 1.2 kbps, 2.4 kbps, ps4.8 kbps, 9.6 kbps, 10.417 kbps, 19.2 kbps, 125 kbps, 250 kbps, 200 kbps, 1 Mbps, 2 Mbps, 5 Mbps, 10 Mbps, or a custom bitrate. The custom bitrate must match with the DUT, the default bitrate is 1.2 kbps.

f. Bit Sequence

Click on the “Bit Sequence” to switch between “MSB” and “LSB”.

- MSB: The Most Significant Bit, i.e., the bit with the highest value in a sequence, transmitted first.
- LSB: The Least Significant Bit, i.e. the bit with the least value in a sequence, transmitted first.

g. Idle State

Click on the “Idle State” to switch to 0 or 1.

- 0: The bus state is at a low level when no data is present.
- 1: The bus state is at a high level when no data is present.

h. Start Frame Bit

Click on the “Start Frame Bit” input field to open the numeric keypad to enter the start frame bit. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the start frame bit. The range can be set from 1 to 32.

i. Synchronization Field

Click on the “Synchronization Field” input field to open the numeric keypad to enter the synchronization field. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the synchronization field. The setting range can be set from 0 to 32.

j. Middle Field 1

Click on the “Middle Field 1” input field to open the numeric keypad to enter the middle field 1. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the middle field 1. The setting range can be set from 0 to 32.

k. Header Field

Click on “Header Field” input field to open the numeric keypad to enter the header field. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the header field. The setting range can be set from 0 to 32.

l. Middle Field 2

Click on the “Middle Field 2” input field to open the numeric keypad to enter the middle field 2. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the middle field 2. The setting range can be set from 0 to 32.

m. Word count

Click on the “Word count” input field to open the numeric keypad to enter the data bit. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the data bit. The setting range can be set from 1 to 255.

n. Bit Size

Click on the “Bit Size” input field to open the numeric keypad to enter the bit size. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the data bit. The setting range can be set from 1 to 8.

o. Middle Field 3

Click on the “Middle Field 3” input field to open the numeric keypad to enter the middle field 3. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the middle field 3. The setting range can be set from 0 to 32.

p. End Field

Click on the “End Field” input field to open the numeric keypad to enter the end field. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the end field. The setting range can be set from 0 to 32.

q. Inter-frame Space

Click on the “Inter-frame Space” input field to open the numeric keypad to enter the inter-frame space. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to adjust the inter-frame space. The setting range can be set from 0 to 32.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to toggle the bus function to on or off.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.


(6) Copy Trigger Settings

When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.

9.12. SENT Decoding

SENT (Single Edge Nibble Transmission) protocol is a point-to-point, unidirectional transmission scheme introduced by SAE, which is used for data transmission between on-board sensors and electronic control units (ECUs).

SENT high and low signal level requirements: 0-0.5 V for logic level 0, 4.1-5 V for logic level 1.



The data of the SENT protocol is coded using a half-byte nibble, i.e. 4 bits, and a half-byte nibble is defined by the time difference between two falling edges.

(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “SENT”.

The screenshot shows the 'Decode' configuration window. It has a dark background with white text and blue highlights for selected options. The 'Bus1' tab is active. The 'Type' is set to 'SENT', 'Display' is 'On', and 'Position' is '0'. The 'Source' is 'C1', 'Threshold' is '-440mV', and 'Mode' is 'Fast'. The 'CLK Cycle' is '3.00 μs', 'TOL' is '30.000%', and 'DS Format' is 'Half'. The 'Half Count' is '6', and 'Pause Mode' is 'On'. The 'Format' is 'Hex', 'Labels' are 'Off', and 'Event List' is 'On'. At the bottom, there are three buttons: 'Trigger', 'Copy Trigger', and 'Save Event List'.

b. Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

Note: The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

c. Threshold

Double-click on the “Threshold” input field to open the numeric keypad to set the threshold. Alternatively, rotate the Multipurpose A rotary knob to adjust the threshold.

d. Mode

Click on the “Mode” to switch the trigger signal mode to fast or slow.

e. Clock Period

Tap to select the “Clock Period” and use the Multipurpose A rotary knob to change the clock period; or double-click on the “Clock period” input field to open the numeric keypad to set the clock period. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). The setting range can be set from 500 ns to 300 μs.

f. Tolerance

Set the percentage tolerance to specify a percentage tolerance for determining whether the sync pulse is valid for decoding data. If the time of the measured sync pulse is within the percentage tolerance of the rated clock period, then the decoding will continue,

otherwise, the sync pulse occurs an error and data decoding will not be performed.

g. Half Byte

Set the half byte for fast channel message, double-click on “Half Byte” input field to open the numeric keypad to set the half byte. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the half byte.

h. Pause Mode

Click on the “Pause Mode” to set whether there is a pause pulse between the fast channel messages. It can be switched to ON or OFF.

- OFF: There is no pause pulse between the fast channel messages.

There is no idle time on the SENT serial bus without pause pulses. This means that during normal operation the fast channel decode line shows a continuous stream of packets, i.e. one packet closes, and a new packet opens immediately.

- ON: Add a pause pulse between the fast channel messages, so that the frames arrive at equal intervals.

If there is a pause pulse (switch on), the idle time will display between the messages.

i. Data Field Format

Set the display format of decoding data field, it can be set to half byte or fast channel.

- Half byte: The decoding data of data field is displayed in half byte.
- Fast channel: The decoding data of data field is displayed together.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format


Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Format

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu


Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings

When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.

9.13. ARINC429 Decoding


The ARINC 429 bus is a serial standard, interface-oriented, unidirectional broadcast transmission bus.



(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “ARINC429”.



b. Source

Click on the “Source” to select C1 - C45. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

Note: The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

c. High/Low Threshold

Double-click on “Threshold (High/Low)” input field to open the numeric keypad to set the threshold. Alternatively, rotate the Multipurpose A rotary knob to adjust the threshold.

d. Speed

Click on the “Speed” to set the transmission rate to high (100kb/s), low (12.5kb/s), or

custom.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format


Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Format

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can

be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings


When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.

9.14. 1-WIRE Decoding

(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “1-WIRE”.



b. Source

Click on the “Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

Note: The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

c. Threshold

Double-click on the “Threshold” input field to open the numeric keypad to set the threshold. Alternatively, rotate the Multipurpose A rotary knob to adjust the threshold.

d. Speed Mode

Click on the “Speed Mode” to set the signal mode to standard or drive.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the "Save Event List" key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the "Trigger" to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings


When the trigger type and parameter settings are completed, and the decoding type is the same, click on the "Copy Trigger" on the decoding page to transfer the parameter settings to the decoding menu.

9.15. I3C Decoding

(1) Decoding Menu Setting

a. Protocol Type

Click on the “Protocol Type” to select “I3C”.



b. Source Setting

Set the clock source and data source. The decoded data can only be obtained when the signal source is set to the channel with the connected signal as its source.

■ Clock Source

Click on the “Clock Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

■ Data Source

Click on the “Data Source” to select C1 - C4 or D0 - D15. For more details on *Trigger Source*, refer to the section [Noun Explanation of Triggering System](#). The current source is displayed in the trigger label at the top of the screen.

c. Level Setting

Click on the “SCL Threshold, SDA Threshold”, and double-click on the “Level” input field to open the numeric keypad to set the trigger level. Alternatively, rotate the [Multipurpose A](#) rotary knob to adjust the trigger level.

d. Mode

Distinguish between the different data transmission methods used in the I3C protocol. Click on the “Mode” item to select either “I2C” or “I3C”.

- I2C: Operates in traditional I2C mode.

- I3C: Supports both single data rate (SDR) mode and high data rate (HDR) mode.

(2) Decoding Bus Setting

a. Bus Switch

Click on the “Bus Switch” to switch on/off the bus function.

b. Decoding Line

Set the display position of decoding bus on the screen. The display position of decoding line can be adjusted by using Multipurpose A rotary knob. Alternatively, double-click on the “Decoding Line” input field to set the position. The setting range can be set from 0 to 546.

c. Format

Set the display format for the decoding bus and event list decoding. Click on the “Format” to select hexadecimal, decimal, binary, or ASCII.

d. Label

Click on the “Label” to switch on/off the decoding bus label. When the decoding bus label is switched on, it will display at the top left and display the current protocol type. When the decoding bus label is switched off, it will not be displayed.

(3) Event List

Click on the “Event List” to switch on/off the event list. When the event list is switched on, it will be displayed as shown in the following figure. Click the event list icon “x” at the top right to close it.



(4) Save Event List

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event List” key in the decoding menu to open the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB flash drive (when a USB flash drive is detected). For the setting steps, refer to [Save and Load](#) section.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.

(5) Jump to Trigger Menu

Click on the “Trigger” to directly navigate to the trigger menu, where the trigger type is same with the decoding type.

(6) Copy Trigger Settings




When the trigger type and parameter settings are completed, and the decoding type is the same, click on the “Copy Trigger” on the decoding page to transfer the parameter settings to the decoding menu.

10. Automatic Measurement

- [Parameter Measurement Overview](#)
- [Counter](#)
- [Voltmeter](#)
- [Parameter Snapshot](#)
- [Parameter Measurement](#)
- [Measurement Statistics](#)
- [Add Parameter](#)
- [Clear Added Measurement](#)
- [Global Setting](#)

MSO5000HD series measurement menu can access all parameter measurement menu, including parameter snapshots, custom parameters, parameter statistics, counters, voltmeters, etc., as well as global settings for parameter measurements.


The “Measure” menu can be entered using the following steps.

- Press the Measure key on the front panel to enter the “Measure” menu.
- Click the Home icon  at the top-right of the screen and select the measurement icon  to enter the “Measure” menu.
- If the measurement is added to the toolbar, click the measurement icon  in the toolbar at the top-right of the screen to enter the “Measure” menu.

10.1. Parameter Measurement Overview

MSO5000HD series oscilloscope can automatically measure 56 kinds of parameter, such as voltage, time, and other parameters.

■ Voltage Parameter



Maximum (V_{max}): The voltage from the highest point of the waveform to GND.

Minimum (V_{min}): The voltage from the lowest point of the waveform to GND.

Top (V_{top}): The voltage value from the flat top of the waveform to GND.

Bottom (V_{base}): The voltage value from the bottom of the waveform to GND.

Middle: Half of the sum of the voltage values at the top and bottom of the waveform

Peak-to-peak (V_{pp}): The voltage value from the highest point to the lowest point of the waveform.

Amplitude (V_{amp}): The voltage from top to bottom of the waveform.

Average (Mean): The average amplitude of the waveform in one cycle.

Root mean square (RMS): The energy generated by the conversion of AC signal; it corresponds to the DC voltage that generates equivalent energy.

RMS of cycle (CycRMS): The energy generated by the conversion of AC signal in one cycle, it corresponds to the DC voltage that generates equivalent energy.

AC RMS of cycle: Standard deviation of voltage value of waveform data in one cycle, which DC component has removed.

Area: The algebraic sum of the product of voltage and time for all points on the screen

Cycle area: The algebraic sum of the product of the voltage and the time at all the points in a cycle of the waveform.

Positive area: The algebraic sum of the product of all voltages and times on the screen greater than GND (ground).

Negative area: The algebraic sum of the product of all voltages and times on the screen less than GND (ground).

Positive cycle area: The algebraic sum of the product of all voltages and times greater than GND (ground) in a cycle.

Negative cycle area: The algebraic sum of the product of all voltages and times less than GND

(ground) in a cycle.


Positive overshoot: The nearest extreme point after the signal along the rising edge of the waveform crosses the upper threshold limit.

Negative overshoot: The nearest extreme point after the signal along the falling edge of the waveform crosses the lower threshold limit.

Positive pre-shoot: The nearest extreme point before the signal along the rising edge of the waveform crosses the upper threshold limit.

Negative pre-shoot: The nearest extreme point before the signal along the falling edge of the waveform crosses the lower threshold limit.

■ Time Parameter



Period: The time between two consecutive, homopolar edges of a repetitive waveform with the same threshold median crossing point.

Frequency: The reciprocal of the cycle

Rise time: Time needed for waveform amplitude rising from the lower threshold to the upper threshold.

Fall time: Time needed for waveform amplitude rising from the upper threshold to the lower threshold.

Positive pulse width: The time difference between the time at the middle threshold on the rising edge of the pulse and the time at the middle threshold on the falling edge of the pulse immediately following.

Negative pulse width: The time difference between the time at the middle threshold on the falling edge of the pulse and the time at the middle threshold on the rising edge of the pulse immediately following.

Positive duty ratio: The ratio of the positive pulse width to period.

Negative duty ratio: The ratio of the negative pulse width to period.

Positive pulse number: The number of positive pulses from the lower threshold to the upper threshold.

Negative pulse number: The number of negative pulses from the upper threshold to the lower threshold.

Rising edge number: The number of rising edges from the lower threshold to the upper threshold.

Falling edge number: The number of falling edges from the upper threshold to the lower threshold.

Burst width: Length of time that the intermediate reference level is exceeded more than once in a row.

Burst interval: The interval between two burst events.

Burst period: Burst period that satisfies burst width and burst interval.

Burst period number: The number that satisfies burst period.

■ Other Parameters

Ratio: The ratio of the AC effective voltages of the master and slave sources, expressed in dB.

Period ratio: The ratio of the periodic AC RMS voltages of the master and slave sources, expressed in dB.

Setup time: The time from when the specified intermediate reference level on the data source was exceeded to the last time the specified intermediate reference level on the clock source was exceeded.

Hold time: The time from when the specified intermediate reference level on the clock source was exceeded to the last time the specified intermediate reference level on the data source was exceeded.

Setup and Hold ratio: The ratio of the total time of setup time and hold time

FRFR: Time at the middle threshold intersection from the first rising edge of source 1 to the first rising edge of source 2.

FRFF: Time at the middle threshold intersection from the first rising edge of source 1 to the first falling edge of source 2.

FFFR: Time at the middle threshold intersection from the first falling edge of source 1 to the first rising edge of source 2.

FFFF: Time at the middle threshold intersection from the first falling edge of source 1 to the first falling edge of source 2.

FRLF: Time at the middle threshold intersection from the first rising edge of source 1 to the last falling edge of source 2.

FRLR: Time at the middle threshold intersection from the first rising edge of source 1 to the last rising edge of source 2.

FFLR: Time at the middle threshold intersection from the first falling edge of source 1 to the last rising edge of source 2.

FFLF: Time at the middle threshold intersection from the first falling edge of source 1 to the last falling edge of source 2.

Phase (r-r): The phase offset between the rising edge of the master source and the rising edge of the slave source at the median waveform threshold, expressed in degrees.

Phase (f-f): The phase offset between the falling edge of the master source and the falling edge of the slave source at the median waveform threshold, expressed in degrees.

Delay (r - r): The delay time between the rising edge of the main signal source and the rising edge of the slave signal source, measured at the median threshold value of the waveform.

Delay (f - f): The delay time between the falling edge of the main signal source and the falling edge of the slave signal source, measured at the median threshold value of the waveform.

■ Power Analysis

- Power Quality Parameters

Voltage peak: The maximum value of the voltage waveform.

Voltage RMS: The root mean square (RMS) value of the voltage waveform.

Peak voltage factor: The ratio of the peak value to the RMS value of the voltage waveform.

Current peak: The maximum value of the current waveform.

Current RMS: The root mean square (RMS) value of the current waveform.

Current peak factor: The ratio of the peak value of the current waveform to its RMS value.

Active power: The power actually consumed by the load, measured in watts (W).

Reactive power: The power due to inductance and capacitance in a circuit, measured in volt-amperes reactive (var).

Apparent power: The product of the RMS values of voltage and current, measured in volt-amperes (VA).

Power factor: The ratio of active power to apparent power.

Power phase angle: The angle between active power and apparent power, measured in degrees (°).

- Surge current parameters

Surge current: The peak current flows into the power supply equipment at the moment the

power supply is turned on.

- Rds (on) Parameters

Rds(on): The effective resistance of the power switching device during its conducting stage.

- Switching Loss Parameters

Number of switching cycles: Total count of switching cycles that meet predefined criteria.

Turn-on power loss: Power dissipated during the turn-on phase of the switching device, measured in Watts (W).

Conduction power loss: Power dissipated during the conduction phase, measured in Watts (W).

Turn-off power loss: Power dissipated during the turn-off phase of the switching device, measured in Watts (W).

Total power loss: Combined power loss across the entire switching cycle, measured in Watts (W).

Turn-on energy loss: Energy consumed during the turn-on phase, measured in Joule (J).

Conduction energy loss: Energy consumed during the conduction phase, measured in Joule (J).

Turn-off energy loss: Energy consumed during the turn-off phase, measured in Joule (J).

Total energy loss: Total energy consumption over the full switching cycle, measured in Joule (J).

- Slew Rate Parameters

dv/dt: The rate of change of voltage over time is analyzed during the switching process of a power switching device.

di/dt: The rate of change of current over time is analyzed during the switching process of a power switching device.

- Ripple Analysis Parameters

Peak-to-peak ripple value: The difference between the maximum and minimum values of the ripple waveform.

Root Mean Square (RMS) Ripple Value: The RMS value calculated from the ripple waveform.

- Startup/Shutdown Time Parameters

Startup time: The time it takes for the output voltage to rise to 90% of its steady-state value after the power supply is powered on.



Shutdown time: The time it takes for the output voltage to fall to 10% of its maximum value after the power supply is turned off.

Note: Parameters in the power quality category can only be customized after the power quality analysis is enabled.

10.2. Counter

The counter analysis function provides counting measurements of frequency, period or product on any analogue channel.

The counter function can be entered using the following steps.

- Press the **Measure** key on the front panel, click on the “Counter” in the “Measure” menu to open the counter analysis function.
- Press the **Analyze** key on the front panel, click on the “Counter” in the “Analyze” menu to open the counter analysis function.
- Click the Home icon at the top-right of the screen and select the counter icon  to open the counter box to switch on the counter analysis function.
- Click the counter icon  in the toolbar at the top-right of the screen, to open the counter box to switch on the counter analysis function.

The results of count measurement are displayed above the volts/div box. Counter analysis can be used for multiple channels.



(1) Counter Setting

Once the counter is enabled, tap the counter parameter to open the counter box to set the

display state, source, test type, refresh time, effective digit, and clear count.

a. Display State

Click on the “Display” to switch on/off the counter display.

ON: The result of count measurement will be displayed at the bottom of the screen.

b. Source

Click on the “Source” to select the source to be tested. C1 - C4 and the trigger source can both serve as the source for the counter.

c. Test Type

Select the “Frequency”, “Period”, or “Accumulation” parameter to be tested. “Accumulation” is the counting of signal edge events.

d. Refresh Time

Set the refresh time for the results of count measurement. Click on the “Refresh Time” input field to rotate the Multipurpose A rotary knob to change the time; or double-click on the “Refresh time” input field to open the numeric keypad to set the time. The time range can be set from 200 ms to 10 s.

e. Effective Digit

The display bit of the counter measured results can be set in the “Frequency”, “Period” parameter. Click on the “Effective digit” input field to rotate the Multipurpose A rotary knob to change the effective digit; or double-click on the “Effective digit” input field to open the numeric keypad to set the effective digit. The range of effective digits can be set from 3 to 7.

f. Clear Count



If the “Accumulation” is selected and the count of signal edge event is being measured, click on the “Clear Count” to delete the count results and restart the count measurement.

10.3. Voltmeter

The built-in digital voltmeter (DVM) of this oscilloscope can measure 4 effective digits of voltage on any analogue channel. DVM measurements are asynchronous to the oscilloscope's acquisition system and are always acquired.

DVM measurement can be entered using the following steps.

- Press the Measure key on the front panel, click on the “Voltmeter” in the “Measure” menu to open the voltmeter measurement.
- Press the Analyze key on the front panel, click on the “Voltmeter” in the “Analyze” menu to open the voltmeter measurement.

- Click the Home icon at the top-right of the screen and select the voltmeter icon  to open the voltmeter box to switch on the voltmeter measurement.
- Click the voltmeter icon  in the toolbar at the top-right of the screen, to open the voltmeter box to switch on the voltmeter measurement.

The results of voltmeter measurement are displayed above the volts/div box. Voltmeter measurement can be used for multiple channels.



(1) Voltmeter Setting

Once the voltmeter is enabled, tap the voltmeter parameter to open the voltmeter box to set the display state, source, test type, refresh time, and beep.

a. Display State

Click on the “Display” to switch on/off the voltmeter display.

ON: The result of voltmeter measurement will be displayed at the bottom of the screen.

b. Source

Click on the “Source” to select the source to be tested. C1 - C4 and the trigger source can both serve as the source for the counter. DVM measurement can be performed even if C1 - C4 is not open.

c. Test Type

- DC: Displays the average of the collected data.
- AC RMS: Displays RMS of the collected data that the DC component has removed.
- DC+AC RMS: Displays RMS of the collected data.

d. Refresh Time

Set the refresh time for the results of count measurement. Click on the “Refresh Time” input field to rotate the Multipurpose A rotary knob to change the time; or double-click on the “Refresh Time” input field to open the numeric keypad to set the time. The time range can be set from 200 ms to 10 s.

(2) Output Setting

a. Aux Output

Click on "Aux Output" and select either ON to enable or OFF to disable the DVM pulse output from the AUX connector.

- ON: The Auxiliary menu automatically sets the AUX output mode to DVM. When a DVM alarm is triggered, a pulse signal will be output from the [AUX OUT] connector on the rear panel.
- OFF: The Auxiliary menu automatically sets the AUX output mode to Trigger Output. The output from the [AUX OUT] connector is not linked to the DVM test.

b. Output Pulse Width

Double-click on the “Output Pulse Width” to open the numeric keypad to set the output pulse width. Alternatively, rotate the Multipurpose A rotary knob to adjust the output pulse width. The range of output pulse width can be set from 200 ns to 1.5 s.

c. Output Polarity

Click on the “Output Polarity” to set the polarity to positive or negative.

(3) Beep Setting

Set the display state, limit condition, and the lower/upper limit for the beep.

a. Display State

Click on the “Display” to switch on/off the beep.

ON: The oscilloscope will have an alarm if the test result meets the condition, otherwise, the alarm will not be sound.

b. Limit Condition

- >: The oscilloscope will have an alarm if the DVM value is greater than the set lower limit, and the lower limit can be set.
- <: The oscilloscope will have an alarm if the DVM value is less than the set upper limit, and the upper limit can be set.
- <>: The oscilloscope will have an alarm if the DVM value is greater than the set lower limit and less than the set upper limit, and the upper/lower limit can be set.
- ><: The oscilloscope will have an alarm if the DVM value is less than the set lower limit and greater than the set upper limit, and the upper/lower limit can be set.

c. Upper/Lower Limit

The set voltage is compared to DVM value, and the range can be set from -500 V to 500 V.

- When the trigger condition is “>” or “<”, click on the “Lower” or “Upper” input field to open the numeric keypad to set the lower/upper limit. Alternatively, rotate the Multipurpose A rotary knob to change the lower/upper limit.
- When the trigger condition is “<>” or “><” click on the “Lower” or “Upper” input field to open the numeric keypad to set the lower/upper limit. Alternatively, rotate the Multipurpose A rotary knob to change the lower/upper limit. The lower limit should be less than the upper limit.

10.4. Parameter Snapshot

The parameter snapshot is used to display one parameter that has performed an automatic measurement.

Press the **Measure** key on the front panel, click on the “Parameter snapshot” in the “Measure” menu to open the parameter snapshot box.



In the parameter snapshot box, click on the “Source” to select the source to be tested, CH1-CH4 and M1 - M4 can be selected.

The color of measured results is consistent with the color of all sources.

10.5. Parameter Measurement

Press the **Measure** key on the front panel, click on the “Parameter Measurement” in the “Measure” menu to open the parameter measurement. The parameter measurement info box will not be displayed if the parameter measurement is not ticked.



The parameter measurement is displayed above volts/div info box, showing the measure parameter and the current value. During the measurement, the counter, voltmeter is displayed on the far left by default, and the custom parameter follow behind. The parameter measurement supports the setting of up to 27 parameters.

The custom parameter measurement in the parameter measurement info box can be cancelled by clicking "-" at the top-right of the screen.

10.6. Measurement Statistics

Press the **Measure** key on the front panel, tick on the “Measurement Statistics” in the “Measure” menu to open the measurement statistics. The statistic results of all parameter measurement are displayed in the “Parameter measurement” box at the bottom of screen

Statistics: current value, maximum, minimum, average value, standard deviation, count, line chart, and histogram.

Once the measurement statistics are enabled, a statistical diagram based on the average value can be generated. There are two types of statistical diagram: histogram and tendency chart.

Select line chart or histogram by clicking on the diagram switch below “Measure” items on the far left.



10.7. Add Parameter

Add the parameter to be tested to the parameter measurement info box, enter the “Add parameter” menu using the following steps.

- Press the **Measure** key on the front panel, click on the “Add parameter” in the “Measure” menu to enter the add parameter menu.
- Click on the icon **⊕** in the parameter measurement info box to enter the add parameter menu.

In the add parameter menu, switch different parameter menu by clicking on the “Vertical”, “Horizontal”, “Other” or slide the menu to left or right, and select this parameter to enter the related measurement. This oscilloscope supports up to 27 kinds of parameter measurements to be opened at the same time.

a. Source

Click on the “Source 1” or “Source 2” to select C1 - C4, M1 - M4, or D0 - D15. When D0 - D15 is selected as the measurement source, only certain addible parameters are available. Supported parameters are highlighted, while unsupported parameters are grayed out.

b. Addible parameters

- Vertical parameters: Maximum, minimum, peak-to-peak, top, bottom, amplitude, middle value, average value, period average, RMS (root mean square), RMS of cycle,

AC RMS, AC RMS of cycle, area, cycle area, positive area, negative area, positive cycle area, negative cycle area, positive overshoot, negative overshoot, positive preshoot, and negative preshoot.



- Horizontal parameters: Period, frequency, rise time, fall time, positive pulse width, negative pulse width, positive duty ratio, negative duty ratio, positive pulse width number, negative pulse width number, rising edge, falling edge, rising edge number, falling edge number, burst width, burst interval, burst period, and burst period number.



- Other parameters: Ratio, period ratio, setup time, hold time, setup and hold ratio, FRFR, FRFF, FFFR, FFFF, FRLF, FRLR, FFLR, FFLF, phase (r-r), phase (f-f), delay (r-r), and delay (f-f).



When the power analysis is set to power quality mode, the power quality-related parameters can be added to the Measure module. These parameters will be hidden if the power quality analysis is not activated.

- Power quality parameters: Voltage peak, voltage RMS, voltage peak factor, current peak, current RMS, current peak factor, active power, reactive power, apparent power, power factor, and power phase angle.



■ Surge current parameter: Surge current



■ Rds(on) parameter: Rds(on)




- Switching loss parameters: Switch period count, switching-on power loss, $R_{ds(on)}$ power loss, switching-off power loss, total power loss, switching-on energy loss, $R_{ds(on)}$ energy loss, switching-off energy loss, and total energy loss.



- Slew rate parameters: dv/dt and di/dt .



■ Ripple analysis parameters: Peak-to-peak ripple analysis, RMS ripple analysis.



■ Startup/shutdown time: Starup time, shutdown time.




10.8. Clear Added Measurement

This oscilloscope allows the user to delete all added measurements.

- In the “Add measurement” menu, click on the added parameter to select and to delete.
- In the results window at the bottom of screen, click on the “-” at the top-right of the screen of any measurement to delete the currently selected measurement.
- Press the **Measure** key on the front panel, click on the “Clear” in the “Measurement” menu to delete all added measurements.

10.9. Global Setting

Press the **Measure** key on the front panel, click on the “Global setting” in the “Measurement” menu to enter the “Advanced setting” menu.



The general and measurement settings can be set in the “Advanced setting” menu.

(1) General Setting

a. Threshold

- Threshold type: Percentage, absolute value.
- Default: Click on the “Default” to restore the upper limit, middle value and lower limit to default value. When threshold type is set to absolute, the default upper and lower limits are ± 2.5 div.
- Source: Click on the “Source” to select the channel to be measured, C1 - C4, M1 - M4 can be selected.
- Upper limit: Set the upper limit of reference level for waveform measurement. Click on the “Upper limit” input field to open the numeric keypad to set the upper limit. Alternatively, rotate the Multipurpose A rotary knob adjust the upper limit. The default percentage is 90%, and the range can be set from 7% to 95%. The default absolute value is 500 mV, the setting range changes with the vertical scale.
- Middle value: Set the middle value of reference level for waveform measurement. Click on the “Middle” input field to open the numeric keypad to set the middle value. Alternatively, rotate the Multipurpose A rotary knob to adjust the middle value. The default percentage is 50%, and the range can be set from 6% to 94%. The default absolute value is 0 mV, the setting range changes with the vertical scale.
- Lower limit: set the lower limit of reference level for waveform measurement. Click on the “Lower limit” input field to open the numeric keypad to set the lower limit.

Alternatively, rotate the Multipurpose A rotary knob adjust the lower limit. The default percentage is 10%, and the range can be set from 5% to 93%. The default absolute value is -500 mV, the setting range changes with the vertical scale.

b. Measurement Range

The measurement window in the horizontal direction will affect the results of all parameter measurements. The measure range can be set to the screen area or cursor area.

- Screen area: Full screen
- Cursor area: The horizontal time cursor area allows the user to set the cursor position as required and to measure the results directly within the cursor area.


c. Maximum Count

It is a custom parameter. If the measurement statistics are switched on, the number of statistics can be set from 10 to 10000, or check unlimited times.

d. Amplitude Calculation Strategy

The amplitude measure mode can be set to auto or manual. The strategy affects the measure strategy of top and bottom value.

- Auto: According to the input signal, the amplitude calculation strategy is automatically selected.
- Manual: Based on the manually selected top and bottom strategy, the corresponding amplitude values are calculated.



e. Top Calculation Strategy

- Histogram: counting the value that greater than the peak-to-peak 1/2, the highest probability is recognized as the top value.
- Maximum: the maximum of waveform is recognized as the top value.

f. Bottom

- Histogram: counting the value that less than the peak-to-peak 1/2, the highest probability is recognized as the bottom value.
- Minimum: the minimum of waveform is recognized as the bottom value.

g. Indicator

Click on the “Indicator” to switch on/off the indicator.

When the cursor indicator is switched on, one or more cursors appear on the screen. Before opening the cursor indicator, at least one automatic measurement parameter should be

opened, and the number of cursors will change according to the measurement parameter.

(2) Measurement Setting

a. RMS

- Unit: Set the unit display for root-mean-square (RMS)-related parameters. The available options are RMS, dBm, and dB. When the unit is switched to dBm, ensure that the test load impedance is 50 Ω to maintain measurement accuracy.
- Reference value: When the unit is set to dB, the reference amplitude can be configured. The reference range can be set from 0.001 to 1000.

b. Burst

- Idle time: Set the idle time for the measurement of burst width, burst interval, burst period, and burst period number.
- Idle level: High or low level.

c. Setup & Hold Setting




- Clock edge: Rising edge, falling edge, or arbitrary edge.
- Data edge: Rising edge, falling edge, or arbitrary edge.


11. Power Analysis

- [Power Quality](#)
- [Harmonics Analysis](#)
- [Surge Current](#)
- [Rds \(on\)](#)
- [Switching Loss](#)
- [Slew Rate](#)
- [Safe Operating Area](#)
- [Modulation Analysis](#)
- [Ripple Analysis](#)
- [Startup/Shutdown Time](#)

This oscilloscope supports power analysis function (option), it can help the user to quickly analyze the efficiency and reliability of switch power. With this function, the user can analyze the power quality, harmonics analysis, surge current of the input power, Rds (on), switching loss, slew rate, safe operating area, modulation analysis, ripple analysis, and startup/shutdown time.

The power analysis menu can be entered using the following steps.

- Click the Analyze key on the front panel, click on the “Power Analysis” in the “Analyzer” menu to enter the “Power Analysis” menu.
- Click the Home icon  at the top-right of the screen and select the power analysis icon  to enter the “Power Analysis” menu.
- If the power analysis is added to the toolbar, click the power analysis icon  in the toolbar at the top-right of the screen to enter the “Power Analysis” menu.



11.1. Power Quality

The power quality can measure the quality of AC input wire. The measuring parameter of power quality analysis includes the voltage peak, RMS voltage, voltage peak factor, current peak, RMS current, current peak factor, active power, reactive power, apparent power, power factor, and power phase angle.

(1) Analysis Mode

Click on the “Type” to select “Power Quality”.

(2) Function Switch

Click on the “Function” to toggle the power analysis ON/OFF.

(3) Wiring Diagram


Click on the “Wiring Diag” to display the wiring diagram of the power quality analysis. Follow the instructions to make the wiring connections as shown in the figure below.

a. Voltage Probe

- Connect D+ to the live wire of the AC input.
- Connect D- to the neutral wire of the AC input.
- Select an appropriate probe attenuation ratio.

b. Current Probe

- Connect current probe to the live wire of the AC input. The arrow on the probe indicates the direction of the current.
- Configure "Input Voltage" and "Input Current" to assign the corresponding channels for the probe mentioned above.



(4) Input Voltage

Click on the “Input Voltage” to select the channel to collect voltage (C1 - C4), the voltage channel should set the unit and probe attenuation ratio according to the input voltage probe.

(5) Input Current

Click on the “Input Current” to select the channel to collect current (C1 - C4), the current channel should set the unit and probe attenuation ratio according to the input current probe.

(6) Period Number

Double click on the “Period Number” input field to open the numeric keypad to set the period number. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the period number. The setting range can be set from 1 to 40.

(7) Auto Setting

After configuring the input voltage and input current sources, the "AutoSet" function will automatically open the voltage and current channels, set the channel units to V and A, and close the other channels.

(8) Apply

Click on the "Apply" to automatically open the Math1 channel, set the basic operation to voltage source x current source, and will automatically add all power quality parameters while opening the statistics. The measurement results are displayed in three formats: figure, result table, and parameter measurement.

- Graph result: Voltage waveforms, current waveforms, and power waveforms (power diagrams) are the product of the current waveform and voltage waveform.
- Result table: The statistic results are displayed in a table.
- Parameter measurement: The power quality results displayed in parameter at the bottom of the screen.

(9) Power Diagram

Click on the “Power Diagram” key, the oscilloscope will open the multiply operation of Math1 by

default and display the power waveforms.

(10) Result Table

Click on the “Result Table” key to open the measurement results table of power quality analysis.



(11) Power Quality Measurement Results

Voltage peak	Maximum voltage waveform
RMS voltage	Effective voltage value $V_{rms} = \frac{1}{N} * \sqrt{\sum_{i=0}^{n-1} V_i^2}$
Voltage peak factor	$V_{Crest} = V_{peak} / V_{rms}$
Current peak	Maximum current waveform
RMS current	Root mean square of current $I_{rms} = \frac{1}{n} * \sqrt{\sum_{i=0}^{n-1} I_i^2}$
Current peak factor	$I_{Crest} = I_{peak} / I_{rms}$
Active power	The actual power consumed by the load, measured in watts (W).
Reactive power	The reactive power caused by inductors and capacitors in a circuit, measured in volt-amperes reactive (VARs).
Apparent power	The product of the effective values of voltage and current, measured in volt-amperes (VA).
Power factor	The ratio of the actual power to the apparent power.
Power phase angle	In power triangle (apparent power ² = active power ² + reactive power ²), the phase angle is the angle between the apparent power and active power, it indicates the amount of reactive power.


(12) Save Results Table

After opening the result table, click the “Save Event Table” to pop up the export setting menu, the data can be saved as *.csv and *.pdf to internal storage or external USB disk drive (when a USB is detected). For the setting steps, refer to the section of [Save and Load](#).

11.2. Harmonics Analysis

Current harmonics refer to the amplitudes of the frequency components that can be injected into AC lines, which may interfere with other devices on the same power grid or network.

The oscilloscope performs FFT (Fast Fourier Transform) on the current waveform and generates a measurement result table for up to 40 harmonics in IRMS, based on IEC 61000-3-2. It then compares the results with the limit values specified in the IEC standard to determine the pass/fail outcomes.



(1) Analysis Mode

Click on the “Type” to select “Harmonics”.

(2) Function Switch

Click on the “Function” to toggle the power analysis ON/OFF.

(3) Wiring Diagram

Click on the “Wiring Diag” to display the wiring diagram of the current harmonics analysis. Follow the instructions to make the wiring connections as shown in the figure below.


a. Voltage Probe

- Connect D+ to the live wire of the AC input.
- Connect D- to the neutral wire of the AC input.
- Select an appropriate probe attenuation ratio.

b. Current Probe

- Connect current probe to the live wire of the AC input. The arrow on the probe indicates the direction of the current.

- Configure "Input Voltage" and "Input Current" to assign the corresponding channels for the probe mentioned above.



(4) Input Voltage

Click on the "Input Voltage" to select the channel to collect voltage (C1 - C4), the voltage channel should set the unit and probe attenuation ratio according to the input voltage probe.

(5) Input Current

Click on the "Input Current" to select the channel to collect current (C1 - C4), the current channel should set the unit and probe attenuation ratio according to the input current probe.

(6) Auto Setting

After configuring the input voltage and input current sources, the "AutoSet" function will automatically open the voltage and current channels, set the channel units to V and A, and close the other channels.

(7) Line Frequency

Click on the "Line Frequency" to set the input line frequency, it can be set to auto acquire, 50 Hz, 60 Hz, or 400 Hz.

(8) Harmonic Standard

Click on the "Harmonic Standard" to select the test standard for harmonic analysis (IEC61000-3-2 A/B/C/D) .

- IEC61000-3-2 A: It is suitable for balanced three-phase equipment, household appliances (except D-type), tools (except portable tools), incandescent lamp, and audio frequency apparatus.
- IEC61000-3-2 B: It is suitable for portable tools.
- IEC61000-3-2 C: It is suitable for lighting equipment. IEC61000-3-2 D: It is suitable for the device that the rated power is less than or equal to 600W, the type is personal PC, personal computer monitors, and television receiver.

(9) Period Number

Double click on the "Period Number" input field to open the numeric keypad to set the period

number. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the period number. The setting range can be set from 1 to 40.

(10) Apply

Click on the "Apply" to enable the oscilloscope to automatically open the Math1 channel based on the user-defined input voltage, input current, and period count, then perform the harmonic analysis measurements.

The measurement results are displayed in three formats, graph, result table, and histogram.

- Graph result: Voltage waveforms, current waveforms, and harmonic analysis waveforms (FFT).
- Result table: The statistical results are displayed in a table.
- Histogram: The current harmonic results are displayed in histogram.


(11) Histogram

Click on the "Histogram" key to open the histogram of harmonic analysis.



(12) Result Table

Click on the "Result Table" key to open the measurement results table of power quality analysis.



(13) Harmonic Analysis Measurement Results

Harmonic, actual value (RMS), limit (RMS), margin, and state	<p>The following values are displayed for the first 40 harmonics.</p> <p>Actual value (RMS): The measured values are displayed with the unit that is specified by the Harmonic unit.</p> <p>Limit (RMS): Limit set by the selected harmonic analysis standard</p> <p>Margin: Margin set by the selected harmonic analysis standard.</p> <p>Pass/Fail: Whether the value passes or fails according to the selected harmonic analysis standard.</p> <p>Rows in a table or bars in a bar graph are colored according to the pass/fail value. The critical result is greater than 85% of the limit but less than 100% of the limit.</p>
THD (Total Harmonic Distortion)	<p>$TDH = 100 \times \frac{\sqrt{X_2^2 + X_3^2 + \dots + X_n^2}}{X_1}$</p> <p>$X_n$ = voltage or current of each harmonic</p> <p>X_1 = basic voltage or current</p>

(14) Save Results Table

After opening the result table, click the “Save Event Table” to pop up the export setting menu, the data can be saved as *.csv and *.pdf to internal storage or external USB disk drive (when a USB is detected). For the setting steps, refer to the section of [Save and Load](#).

11.3. Surge Current

The surge current refers to the initial surge of current consumed when the power supply is turned on for the first time. The power converter and the surge current exceed the steady-state current, due to the charging current of the input capacitor. Through a surge current test, it can be verified whether the AC switch, bridge rectifier, fuse, and EMI filter operate within their allowable current limits. When the switching loop is repeatedly turned on and off, the AC input voltage should neither damage the power supply nor cause the fuse to blow. This maximum or minimum instantaneous value can be captured using the single-shot acquisition function of an oscilloscope.

(1) Analysis Mode

Click on the "Type" to select "Surge Current".

(2) Function Switch

Click on the "Function" to toggle the power analysis ON/OFF.

(3) Wiring Diagram


Click on the "Wiring Diag" to display the wiring diagram of the power quality analysis. Follow the instructions to make the wiring connections as shown in the figure below.

a. Voltage Probe

- Connect D+ to the live wire of the AC input.
- Connect D- to the neutral wire of the AC input.
- Select an appropriate probe attenuation ratio.

b. Current Probe

- Connect current probe to the live wire of the AC input. The arrow on the probe indicates the direction of the current.
- Configure "Input Voltage" and "Input Current" to assign the corresponding channels for the probe mentioned above.



(4) Input Voltage

Click on the "Input Voltage" to select the channel to collect voltage (C1 - C4), the voltage channel should set the unit and probe attenuation ratio according to the input voltage probe.

(5) Input Current

Click on the "Input Current" to select the channel to collect current (C1 - C4), the current channel should set the unit and probe attenuation ratio according to the input current probe.

(6) Maximum Input Voltage (RMS)

Assign the maximum input voltage and set the vertical calibration of channel voltage.

Double click on the "Maximum Input Voltage (RMS)" input field to open the numeric keypad to set the maximum input voltage.

For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the maximum input voltage. The setting range can be set from 1 V to 1000 V.

(7) Prospective Current


The prospective current is used to assign the expected inrush current amplitude and set the vertical calibration of channel current.

For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the prospective current. The setting range can be set from 100 mA to 500 A.


(8) Apply

Click on the "Apply" and follow the on-screen instructions. The result will be displayed after the analysis is complete.



11.4. Rds (on)

This measurement characterizes the on-state resistance, $R_{ds(on)}$, between the drain and source of the switching device during the conduction phase of the switching cycle.



(1) Analysis Type

Click on the "Type" to select " $R_{ds(on)}$ ".

(2) Function Switch

Click on the "Function" to toggle the power analysis ON/OFF.

(3) Wiring Diagram


Click on the "Wiring Diag" to display the wiring diagram of $R_{ds(on)}$. Follow the instructions to make the wiring connections as shown in the figure below. Tap the icon in the top-right corner to close the wiring diagram.

a. Voltage Probe

- Connect D+ to the drain of the MOSFET.
- Connect D- to the source of the MOSFET.
- Select an appropriate probe attenuation ratio.

b. Current Probe

- Connect current probe to the source of the MOSFET. The arrow on the probe indicates the direction of the current.
- Configure "Input Voltage" and "Input Current" to assign the corresponding channels for the probe mentioned above.



(4) Input Voltage

Click on the "Input Voltage" to select the channel to collect voltage (C1 - C4), the voltage channel should set the unit and probe attenuation ratio according to the input voltage probe.

(5) Input Current

Click on the "Input Current" to select the channel to collect current (C1 - C4), the current channel should set the unit and probe attenuation ratio according to the input current probe.

(6) Auto Setting

After configuring the input voltage and input current sources, the "AutoSet" function will automatically open the voltage and current channels, set the channel units to V and A, and close the other channels.

(7) Apply

Click the "Apply" to perform the power analysis function, automatically add the $R_{ds(on)}$ parameters while enabling the statistics.




(8) Slew Rate Measurement Results

Rds(on)	The effective resistance of the power switch component during the conduction stage.
---------	---

11.5. Switching Loss

On-state losses occur when physical and parasitic capacitors are charged. During this process, the inductor generates a magnetic field, causing transient resistance losses. Similarly, when a switched-mode power supply is turned off, energy is discharged and interacts with various components, even if the mains power is unplugged, resulting in additional losses.



(1) Analysis Type

Click on the “Type” to select “Switching Loss”.

(2) Function Switch

Click on the “Function” to toggle the power analysis ON/OFF.

(3) Wiring Diagram


Click on the “Wiring Diag” to display the wiring diagram of switching loss. Follow the instructions to make the wiring connections as shown in the figure below. Tap the icon in the top-right corner to close the wiring diagram.

a. Voltage Probe

- Connect D+ to the drain of the MOSFET.
- Connect D- to the source of the MOSFET.
- Select an appropriate probe attenuation ratio.

b. Current Probe

- Connect current probe to the source of the MOSFET. The arrow on the probe indicates the direction of the current.
- Configure "Input Voltage" and "Input Current" to assign the corresponding channels for the probe mentioned above.



(4) Input Voltage

Click on the "Input Voltage" to select the channel to collect voltage (C1 - C4), the voltage channel should set the unit and probe attenuation ratio according to the input voltage probe.

(5) Input Current

Click on the "Input Current" to select the channel to collect current (C1 - C4), the current channel should set the unit and probe attenuation ratio according to the input current probe.

(6) Auto Setting

After configuring the input voltage and input current sources, the "AutoSet" function will automatically open the voltage and current channels, set the channel units to V and A, and close the other channels.

(7) Voltage Reference

The voltage reference is used to identify the conducting state. When the voltage falls below the voltage reference percentage of the maximum waveform voltage, it is recognized as the on-state. Select the parameter field and use the Multipurpose A rotary knob to adjust the reference value, which ranges from 1% to 100%.

(8) Current Reference

The current reference is used to identify the conducting state. When the current falls below the current reference percentage of the maximum waveform current, it is recognized as the off-state. Select the parameter field and use the Multipurpose A rotary knob to adjust the reference value, which ranges from 0% to 100%.

(9) Conduction Type

Click on the "Conduction" to select the conduction types: voltage waveform, $R_{ds(on)}$, or $V_{ce(sat)}$.

- Voltage waveform: The power waveform uses the original data. The calculation formula is $P = V * I$, $E = P * T$.
- Rds(on): For on-state areas, where the voltage or current is lower than the voltage reference (adjustable), the power calculation formula is $P = I^2 * R_{ds(on)}$.
For off-state areas, where the voltage or current is lower than the current reference (adjustable), the power calculation formula is $P = 0$ watt.
- Vce(sat): For on-state areas, where the voltage or current is lower than the voltage reference (adjustable), the power calculation formula is $P = V_{ce(sat)} * I$.
For off-state areas, where the voltage or current is lower than the current reference (adjustable), the power calculation formula is $P = 0$ watt.

(10) Rds(on)

The on-resistance can be configured when the conduction type is set to Rds(on), with a range from 1 mΩ to 200 Ω.

(11) Vce(sat)

The Vce voltage can be configured when the conduction type is set to Vce(sat), with a range from 50 mV to 2.5 V.

(12) Apply

Click on the "Apply" to enable the oscilloscope to automatically open the Math1 channel based on the user-defined input voltage, input current, voltage reference, and current reference. It will set the basic operation to "voltage source × current source" and automatically add all switching loss parameters while enabling the statistics.




(13) Switching Loss Measurement Results

Switching period number	Meets the required number of switching periods.
Switching-on power loss	The power loss of power switch device during the switching-on process, measured in watts (W).
Conduction power loss	The power loss of power switch device during the conducting process, measured in watts (W).
Switching-off power loss	The power loss of power switch device during the switching-off process, measured in watts (W).
Total power loss	The total power loss of power switch device during the whole switching period, measured in watts (W).
Switching-on energy loss	The energy loss of power switch device during the switching-on process, measured in joules (J).
Conduction energy loss	The energy loss of power switch device during the conducting process, measured in joules (J).
Switching-off energy loss	The energy loss of power switch device during the switching-off process, measured in joules (J).
Total energy loss	The total energy loss of power switch device during the whole switching period, measured in joules (J).

11.6. Slew Rate

Slew rate analysis measures the rate of voltage or current variation during the switching period.



(1) Analysis Type

Click on the “Type” to select “Slew Rate”.

(2) Function Switch

Click on the “Function” to toggle the power analysis ON/OFF.

(3) Wiring Diagram


Click on the “Wiring Diag” to display the wiring diagram of slew rate. Follow the instructions to make the wiring connections as shown in the figure below. Tap the icon in the top-right corner to close the wiring diagram.

a. Voltage Probe

- Connect D+ to the drain of the MOSFET.
- Connect D- to the source of the MOSFET.
- Select an appropriate probe attenuation ratio.

b. Current Probe

- Connect current probe to the source of the MOSFET. The arrow on the probe indicates the direction of the current.
- Configure "Input Voltage" and "Input Current" to assign the corresponding channels for the probe mentioned above.



(4) Input Voltage

Click on the "Input Voltage" to select the channel to collect voltage (C1 - C4), the voltage channel should set the unit and probe attenuation ratio according to the input voltage probe.

(5) Input Current

Click on the "Input Current" to select the channel to collect current (C1 - C4), the current channel should set the unit and probe attenuation ratio according to the input current probe.

(6) Auto Setting

After configuring the input voltage and input current sources, the "AutoSet" function will automatically open the voltage and current channels, set the channel units to V and A, and close the other channels.

(7) Edge

Select the signal edge to be tested: rising edge or falling edge.

(8) Apply

Click on the "Apply" to enable the oscilloscope to automatically open the Math1 channel based on the user-defined input voltage, input current, and edge. It will perform the current power analysis function and automatically add all slew rate parameters while enabling the statistics.




(9) Slew Rate Measurement Results

dv/dt	The rate of change of voltage over time is analyzed during the switching process of a power switching device.
di/dt	The rate of change of current over time is analyzed during the switching process of a power switching device.

11.7. Safe Operating Area


The safe operating area (SOA) of a MOSFET defines the limiting conditions for voltage, current, and power consumption. Under these conditions, the MOSFET can operate without sustaining self-damage.

The oscilloscope can automatically generate the SOA based on parameters such as voltage limits, current limits, and power limits set in the configuration menu. It evaluates whether the voltage and current of the switching device during normal operation exceed this area. This feature helps designers quickly identify problems or potential risks in the circuit.



(1) Analysis Type

Click on the “Type” to select “SOA”.



(2) Function Switch

Click on the “Function” to toggle the power analysis ON/OFF.

(3) Wiring Diagram

Click on the “Wiring Diag” to display the wiring diagram of safe operating area. Follow the


instructions to make the wiring connections as shown in the figure below. Tap the icon in the top-right corner to close the wiring diagram.

a. Voltage Probe

- Connect D+ to the drain of the MOSFET.
- Connect D- to the source of the MOSFET.
- Select an appropriate probe attenuation ratio.

b. Current Probe

- Connect current probe to the source of the MOSFET. The arrow on the probe indicates the direction of the current.
- Configure "Input Voltage" and "Input Current" to assign the corresponding channels for the probe mentioned above.



(4) Input Voltage

Click on the "Input Voltage" to select the channel to collect voltage (C1 - C4), the voltage channel should set the unit and probe attenuation ratio according to the input voltage probe.

(5) Input Current

Click on the "Input Current" to select the channel to collect current (C1 - C4), the current channel should set the unit and probe attenuation ratio according to the input current probe.

(6) Auto Setting

After configuring the input voltage and input current sources, the "AutoSet" function will automatically open the voltage and current channels, set the channel units to V and A, and close the other channels.

(7) Failure Operation

When the template performs a failure operation, it can be configured to perform no operation, stop operation, and sound alarm.

- No operation: If the template test fails, no operation will be performed, and the template test will continue.
- Stop operation: If the template test fails, the template test will stop immediately.
- Sound alarm: If the template test fails, the beeper will sound, but the template test will

continue.

(8) SOA Gate Setting


Set the minimum and maximum values for SOA voltage and current axes, which configures the minimum voltage, maximum voltage, minimum current, and maximum current.

- Minimum voltage: Sets the display minimum value for SOA voltage axis, with a default value of 0 mV.
- Maximum voltage: Sets the display maximum value for SOA voltage axis, with a default value of 10 V.
- Minimum current: Sets the display minimum current for SOA voltage axis, with a default value of 0 mA.
- Maximum current: Sets the display maximum current for SOA voltage axis, with a default value of 10 A.

(9) Template Type

Set the generation type for SOA template, which configures the limit value and user-defined value. When the limit value is selected, the voltage limit, current limit, and power limit can be set. When the user-defined is selected, the operations of editing the template, importing the template, and saving the template can be performed.

- a. Limit value: Generates a template by configuring the voltage limit, current limit, and power limit.
 - Voltage limit: Sets the maximum VDS (Drain-Source Voltage), with a default value of 5 V.
 - Current limit: Sets the maximum IDM (Drain Current-Pulse), with a default value of 5 A.
 - Power limit: Sets the power limit of thermal resistance, with a default value of 25 W.
- b. User-defined: Generates a template by configuring user-defined operations, such as editing the template, importing the template, and saving the template.



- Edit template: Click on the "Edit Template" to open the template box. The default template contains 6 points. The user can edit the template by inserting points, deleting points, or editing points, and then save the template.
 - Insert point: Insert a point below the selected point.
 - Delete point: Delete the selected point.
 - Edit point: Double-click the selected point to set its axis by configuring the voltage value and current value.
 - Save: Save the user-defined template and refresh the template in SOA waveform.

Note: The template point requires a block area; otherwise, the template cannot be saved.

- Import template: When the SOA template type is set to user-defined, the user can load and retrieve template files stored in the instrument's internal memory or an external USB flash drive (only when the USB flash drive is detected) and apply them to the current SOA test. Click "Import Template" to enter the file loading interface. Select the specified template file (*.csv) from the "Loading Path" and apply it to the current SOA test function.
- Save template: After editing the user-defined template, the user can save it in the *.csv format to the instrument's internal memory or an external USB flash drive (only when the USB flash drive is detected). Click "Save Template" to enter the file saving interface. Enter the corresponding information in the "File Name" and "Save Path" fields to save the template file to internal or external memory. For detailed saving instructions, please refer to the [Save and Load](#) section.

(10) SOA Waveform


Click on the "SOA Waveform" to toggle the waveform display state ON/OFF.

(11) Reset

Click on the "Reset" to clear the template test results and restart the template test.


(12) Apply

Click on the "Apply" to enable the oscilloscope to perform the SOA function based on the user-defined input voltage, input current, failure operation, minimum voltage, maximum voltage, minimum current, maximum current, and template limit. It will automatically open the SOA waveform display.



11.8. Modulation Analysis

The feedback control loop stabilizes the output voltage, while modulation analysis specifically examines the characteristics of the control loop in the switching power supply. It measures the control pulse signal of the switching device (MOSFET) and observes the trends in pulse width, duty ratio, period, frequency, rise time, fall time, and other factors in response to various events.



(1) Analysis Type

Click on the "Type" to select "Modulation".

(2) Function Switch

Click on the "Function" to toggle the power analysis ON/OFF.

(3) Wiring Diagram


Click on the "Wiring Diag" to display the wiring diagram of modulation analysis. Follow the instructions to make the wiring connections as shown in the figure below. Tap the icon in the top-right corner to close the wiring diagram.

a. Voltage Probe

- Connect D+ to the drain of the MOSFET.
- Connect D- to the source of the MOSFET.
- Select an appropriate probe attenuation ratio.

b. Current Probe

- Connect current probe to the source of the MOSFET. The arrow on the probe indicates the direction of the current.
- Configure "Input Voltage" and "Input Current" to assign the corresponding channels for the probe mentioned above.



(4) Input Voltage

Click on the “Input Voltage” to select the channel to collect voltage (C1 - C4), the voltage channel should set the unit and probe attenuation ratio according to the input voltage probe.

(5) Input Current

Click on the “Input Current” to select the channel to collect current (C1 - C4), the current channel should set the unit and probe attenuation ratio according to the input current probe.

(6) Auto Setting

After configuring the input voltage and input current sources, the "AutoSet" function will automatically open the voltage and current channels, set the channel units to V and A, and close the other channels.

(7) Source Reference

Click on the “Source” to configure the measurement source as voltage or current for the modulation analysis.

(8) Parameter Type

Click on the “Param Type” to configure the measurement type, including period, frequency, rise time, fall time, positive pulse width, negative pulse width, positive duty ratio, and negative duty ratio.

(9) Time Trend

Click on the “Time Trend” to toggle the display state ON/OFF.

(10) Apply


Click on the "Apply" to enable the oscilloscope to perform the modulation analysis function based on the input voltage, input current, auto setting, source reference, parameter type, and time trend. The time trend chart will automatically display after the analysis is complete.



The time trend graph visualizes the measured changes in each cycle of the modulation waveform using a mathematical waveform.

11.9. Ripple Analysis

Ripple refers to voltage fluctuations that occur in a DC regulated power supply. Because a DC regulated power supply is typically created by rectifying and stabilizing an AC power source, it inevitably retains some AC components. These residual AC components, superimposed on the stable DC output, are known as ripple.



(1) Analysis Type

Click on the “Analysis Type” to select “Ripple”.

(2) Function Switch

Click on the “Function” to toggle the power analysis ON/OFF.

(3) Wiring Diagram

Click on the “Wiring Diag” to display the wiring diagram of the ripple analysis. Please follow the instructions to make the wiring connection, as shown in the following figure. To close the diagram, click the icon in the upper-right corner.


a. Voltage Probe

- Connect D+ to the power output terminal.
- Connect D- to the power ground.
- Select an appropriate probe attenuation ratio.

If the output voltage is low, a standard voltage probe can be used.

b. Current Probe

- Connect the current probe to the power output, ensuring that the arrow on the probe indicates the direction of current flow.
- Use "Input Voltage" and "Input Current" to assign the channels corresponding to the connected probes.



(4) Input Voltage

Click on the "Input Voltage" to select the channel to collect voltage (C1 - C4). The voltage channel should set the unit and probe attenuation ratio according to the input voltage probe.

(5) Input Current

Click on the "Input Current" to select the channel to collect current (C1 - C4). The current channel should set the unit and probe attenuation ratio according to the input current probe.

(6) Auto Setting

After configuring the input voltage and input current sources, the "AutoSet" function will automatically open the voltage and current channels, set the channel units to V and A, and close the other channels.

(7) Duration


Set the time span for the entire waveform display. The valid range is 10 ns to 20 s. The oscilloscope will automatically adjust the time base range using the formula: $\text{Time Base} = \text{Duration} / 10$

(8) Source Reference

Click on the "Source" to configure the measurement source as voltage or current for the modulation analysis.

(9) Apply

Click on the "Apply" to enable the oscilloscope to perform the ripple analysis function based on the input voltage, input current, duration, and source reference. The time trend chart will automatically display after the analysis is complete. This action will also automatically add all relevant ripple analysis parameters and enable statistics.



(10) Ripple Analysis Measurement Results

Peak-to-Peak Ripple Value	The difference between the maximum and minimum values of the ripple waveform.
Root Mean Square (RMS) Ripple Value	The RMS value calculated from the ripple waveform.


11.10. Startup/Shutdown Time

During startup analysis, the oscilloscope measures the time required for the power supply to rise to 90% of its steady-state output voltage after being powered on.

During shutdown analysis, it measures the time taken for the output voltage to drop to 10% of its maximum value after the power supply is turned off.

(1) Analysis Type

Click on the “Analysis Type” to select “Turn On/Off”.



(2) Function Switch

Click on the “Function” to toggle the power analysis ON/OFF.

(3) Wiring Diagram


Click on the “Wiring Diag” to display the wiring diagram of the SOA analysis. Follow the instructions to make the wiring connections as shown in the figure below. To close the diagram, click the icon in the upper-right corner.

a. Voltage Probe

- Connect D+ to the live wire of the AC input.
- Connect D- to the neutral wire of the AC input.
- Select an appropriate probe attenuation ratio.

b. Voltage Probe (Passive or differential probe)

- Connect the probe to the power output terminal.
- Use "Input Voltage" and "Output Voltage" to assign the appropriate channels corresponding to the connected probes.



(4) Input Voltage

Click on the "Input Voltage" to select the input voltage source (C1 - C4).

(5) Output Voltage

Click on the "Output Voltage" to select the output voltage source (C1 - C4).

(6) Test Type

Click the pull-down list under "Test Type" and select the desired test type to turn on or turn off.

(7) Input Type

Click the pull-down list under "Input Type" and select the appropriate input type to AC or DC.

(8) Maximum Input Voltage

Set the maximum input voltage. The valid range is 1 V to 1 kV. The oscilloscope will automatically adjust the voltage channel range based on this value using the formula: Channel Range = Maximum Input Voltage / 6.

(9) Steady Output Voltage


Set the steady-state output voltage. The valid range is -30 V to 30 V. The oscilloscope will automatically adjust the output voltage channel range based on this value using the formula: Channel Range = Steady Output Voltage / 6.

(10) Duration

Set the time span for the entire waveform display. The valid range is 10 ns to 20 s. The oscilloscope will automatically adjust the time base range using the formula: Time Base = Duration / 10.

(11) Apply

Click the "Apply" button and follow the on-screen instructions. Once the analysis is complete, the results will be displayed.



(12) Startup/Shutdown Time Measurement Results

Startup Time	The time it takes for the output voltage to rise to 90% of its steady-state value after the power supply is powered on.
Shutdown Time	The time it takes for the output voltage to fall to 10% of its maximum value after the power supply is turned off.





12. Cursor Measurement

- [Time Measurement](#)
- [Voltage Measurement](#)
- [Screen Measurement](#)

Use the cursor to measure X axis (time) and Y axis (voltage) of the waveform. The cursor measurement supports simultaneous measurement of multiple channels, as well as Math waves. The source, test type and mode can be set in the cursor measurement menu.


- (1) Source: set the source for the cursor measurement, C1 - C4 and M1-M4 can be selected.
- (2) Test type: Time, voltage, and screen measurements.
- (3) Synchronized move: Configure the cursor time signature tracking method. It can be set to on or off.
 - OFF: The two cursors can be adjusted independently.
 - ON: The two cursors move together in a synchronized manner.
- (4) Horizontal cursor: Set the horizontal cursor position relative to the time base. Two modes can be selected: position fixed and delay fixed.
 - Position fixed: The default display is at ± 2 divisions. When the time base is changed, the positions of the AX and BX cursors on the screen remain unchanged.
 - Delay fixed: The default display is at ± 2 divisions. When the time base is modified, the AX and BX cursor positions are stretched or compressed accordingly.
- (5) Cursor result window: Supports hover or fixed display modes.
 - Hover: Allows you to drag the window to display it anywhere on the screen.
 - Fixed: Drag the window to the left side of the screen to fix its position there.

The cursor measurement can be entered using the following steps.

- Press the Measure key on the front panel, click on the "Cursor measurement" in the "Measure" menu to open the cursor measurement.
- Click the Home  icon at the top-right of the screen and select the counter icon  to switch on the cursor measurement.
- If the cursor icon is added to the toolbar, click on the cursor icon  in the toolbar at the top-right of the screen to open the cursor measurement.
- If cursor measurement results appear, click on the icon  to open the cursor measurement.

12.1. Time Measurement

In the “Cursor” menu to switch on the cursor and click on the “Type” to select “Time” and then tick on the “Source” to be tested, as shown in the following figure.



Cursor results info box: “X” represents the results of channel time measurement, “Y” represents the results of voltage measurement at the intersection of the open channel and the cursor.

Math wave supports split screen display, so when the cursor is measuring Math wave, it can also be displayed in split screen, allowing the cursor of each Math channel to be adjusted individually without affecting each other.


The position of AX and BX cursors can be set using the following methods.

- Use the Multipurpose A rotary knob to move the selected cursor AX position, and use the Multipurpose B rotary knob to move the selected cursor BX position.
Clockwise: moves to the right; anticlockwise: moves to the left.
- Tap to select AX or BX. Drag the cursor to move to the correct position. For the use of drag gesture, refer to the section of [Touch Screen](#).

12.2. Voltage Measurement

The voltage measurement is the same as the time measurement, adjusting the vertical position of the cursor and measuring the voltage of each cursor.

In the “Cursor” menu to switch on the cursor and click on the “Type” to select “Voltage” and then tick on the “Source” to be tested, as shown in the following figure.



Cursor results info box in top left corner: “Y” represents the results of channel voltage measurement.

Math wave supports split screen display, so when the cursor is measuring Math wave, it can also be displayed in split screen, allowing the cursor of each Math channel to be adjusted individually without affecting each other.


The position of AY and BY cursors can be set using the following methods.

- Use the Multipurpose A rotary knob to move the selected cursor AX position, and use the Multipurpose B rotary knob to move the selected cursor BX position.
Clockwise: moves up; anticlockwise: moves down.
- Tap to select AX or BX to drag the cursor to move to the correct position. For the use of drag gesture, refer to the section of [Touch Screen](#).

12.3. Screen Measurement

The screen measurement supports setting the time cursor and voltage cursor, i.e. the time and voltage measurement can be performed at the same time.

In the “Cursor” menu to switch on the cursor and click on the “Type” to select “Screen” and then tick on the “Source” to be tested, as shown in the following figure.



Cursor results info box in top left corner: “X” represents the results of channel time measurement, “Y” represents the results of voltage measurement.

Math wave supports split screen display, so when the cursor is measuring Math wave, it can also be displayed in split screen, allowing the cursor of each Math channel to be adjusted individually without affecting each other.

The position of AX, BX, AY, and BY cursors can be set using the following methods.

- Use the Multipurpose A rotary knob to move the selected cursor AX and AY position, and use the Multipurpose B rotary knob to move the selected cursor BX and BY position.
Clockwise: moves to the right (moves up); anticlockwise: moves to the left (moves down).
Press the Multipurpose A rotary knob to switch between AX and AY.
Press the Multipurpose B rotary knob to switch between BX and BY.
- Tap to select AX, BX, AY, or BY to drag the cursor to move to the correct position. For the use of drag gesture, refer to the section of [Touch Screen](#).


13. Sampling System

- [Sampling Rate](#)
- [Acquisition Mode](#)
- [Memory Depth](#)
- [Interpolation Method](#)
- [Enhanced Resolution \(ERES\)](#)

Sampling is the conversion of the signal from an analog input channel, through an analog-to-digital converter (ADC), into a discrete point.

The sampling setting menu can be entered using the following steps.


- Click on the **A** sampling info label at the top of the screen (as shown in the following figure) to enter the “Sampling” setting menu.




13.1. Sampling Rate

(1) Sampling and Sampling Rate

Sampling indicates that the oscilloscope is to take a sample from the input an analog signal and convert the sample to digital data, and then gather the digital data to waveform records. The waveform records will be saved in the storage memory.



Analog Input Signal



Sampling Point


Sampling rate indicates the time interval between two sampling points. The maximum sampling

rate of MSO5000HD series high-resolution oscilloscopes is 5 GSa/s.


The sampling rate will change with the time base scale and memory depth. The real-time sampling rate is displayed in the **A** sampling label at the top of the screen, the horizontal time base can be adjusted by using the horizontal Scale or change the “Memory Depth”.

(2) Effect of Low Sampling Rate


- **Waveform distortion:** Due to low sampling rate, the details of the waveform might be missing, the sampled waveform might have large different than the actual signal, as shown in the following figure.



- **Waveform aliasing:** Since the sampling rate is 2 times lower than the actual signal frequency (Nyquist frequency), the waveform frequency is less than the frequency of actual signal when sampling data is reconstructing, as shown in the following figure.



- **Waveform missing:** Due to the low sampling rate, the waveform does not reflect all the actual signals, as shown in the following figure.



13.2. Acquisition Mode

The acquisition mode controls how the oscilloscope uses the sampling rate to create a waveform. In the “Sampling” menu, click on the “Acquisition Mode” to select the mode.

(1) Normal Sampling

The oscilloscope samples the signal and reconstructs the waveform with equal time interval in normal mode. For most of waveform, this mode can produce the optimal display effect.

(2) Peak Sampling

The oscilloscope finds the maximum and minimum of the input signal from every sampling interval and using this value to display the waveform. Thus, the oscilloscope can get and display the narrow pulse, otherwise, this narrow pulse will be missed in normal sampling. In this mode, the noise will also look larger

(3) High Resolution

The oscilloscope averages the adjacent point of sampling waveform, it can reduce the random noise of input signal and generate a smoother waveform on the screen.


(4) Average

The oscilloscope obtains several waveforms and calculates its averaged value, and then displays the final waveform. This mode can reduce the random noise.

To observe the waveform by changing the acquisition method. If the signal contains large noise, the waveform does not average and the waveform adopts 32 times averaged as shown in the following figure. The higher the average value, the lower the noise and the vertical resolution will be much higher, but the change in the waveform will also be slower.

The “Average Number” is enabled when the acquisition mode is average, and the range can be set from 2 to 8192, each increment is a power function of 2. The default averaging number of the oscilloscope is 2.

By changing the acquisition mode setting to observe the waveform changes. If the signal contains large noise, when the average mode is not adopted and when the 32 times average mode is adopted, the sampled waveform is shown in the following figure.



Not Averaged Waveform

Waveform of 32 Times Averaged

Note: Average and high resolution uses different average methods. The former is “multiple sampling averaged”, the latter is “single sampling averaged”.

(5) Enhanced Resolution

If the signal-to-noise ratio and the effective resolution of the oscilloscope need improvement, select the enhanced resolution acquisition method, then set the desired number of enhanced resolution bits. For more details, refer to the section of [13.5 Enhanced Resolution \(ERES\)](#).

13.3. Memory Depth

The memory depth is the number of waveforms that can be stored in the oscilloscope during a trigger acquisition. It reflects the memory storage capacity of the memorizer.

The relation of the memory depth, sampling rate and sampling time:

$$\text{Memory depth} = \text{Sampling rate (Sa/s)} \times \text{Sampling time (s/div} \times \text{div)}$$

In the “Sampling” menu, click on the “Memory Depth” to select the memory depth. The real-time memory depth is displayed in the **A** sampling label at the top of the screen.

MSO5000HD supports the memory depth as shown in the table below: Auto (10 Mpts), 25 kpts, 250 kpts, 500 kpts, 5 Mpts, 50 Mpts, 100 Mpts, and MAX (500 Mpts).

13.4. Interpolation Method

With real-time sampling, the oscilloscope acquires discrete samples of the displayed waveform. In general, waveforms displayed by dots are difficult to observe. The digital oscilloscope usually uses interpolation to improve the visualization of the signal. The interpolation is a method of “connect each sampling point” and using some points to calculate the waveform. With real-time sampling using interpolation, even if the oscilloscope only captures a small number of sampling points in a single pass, interpolation can be used to fill in the gaps between points and reconstruct an accurate waveform.


The interpolation is divided into Sinc interpolation ($\text{sinc}(x)$) and linear interpolation.

Linear interpolation: Straight lines are directly connected at adjacent sampling points. This method is limited to the reconstruction of pure edge signals, such as square waves.

Sinc interpolation ($\text{sinc}(x)$): Use a curve to connect the sampling points, this is more common.

Sinc interpolation uses mathematical processing to calculate the result in the actual sampling point interval. This method bends the signal waveform to produce a more realistic common shape than pure square waves and pulses. When the sampling rate is 3 to 5 times the system bandwidth. Sinc interpolation is recommended. The figure below shows a very different display using the two

interpolation methods.



13.5. Enhanced Resolution (ERES)

When the acquisition mode is set to Eres (Enhanced Resolution), the Eres setting can be configured to Off, 1 bit, 1.5 bits, 2 bits, 2.5 bits, 3 bits, or 4 bits.

In Enhanced Resolution mode, the oscilloscope digitally filters the sampling points, reducing broadband random noise on the input signal and improving the signal-to-noise ratio, thereby increasing the effective resolution (ENOB) of the oscilloscope. The MSO5000HD's Eres processing is implemented by a hardware engine, allowing the oscilloscope to maintain a high waveform refresh rate even when Eres is enabled.

Unlike other acquisition methods, Eres does not require the signal to be periodic or triggered stably. However, because it relies on digital filtering, enabling Eres reduces the oscilloscope's system bandwidth. The higher the number of enhanced resolution bits, the lower the bandwidth.




The table below shows the relationship between the number of Eres bits and the resulting bandwidth.


Eres Bit	- 3 dB Bandwidth
1 bit	$0.6 \times \text{Sampling rate}$
1.5 bits	$0.2 \times \text{Sampling rate}$
2 bits	$0.1 \times \text{Sampling rate}$
2.5 bits	$0.032 \times \text{Sampling rate}$
3 bits	$0.012 \times \text{Sampling rate}$
4 bits	$0.005 \times \text{Sampling rate}$

14. Display System

In the "Display" menu, set the waveform type, persistence, grid type, waveform brightness, backlight brightness, and window transparency.

The "Display" menu can be entered using the following steps.

- Click the Home icon  at the top-right of the screen and select the display icon  to switch on the display menu.
- If the display function is added to the toolbar, click the display icon  in the toolbar at the top-right of the screen to enter the display menu.



14.1. Display Type

In the "Display" setting menu, the display type can be set to vector or point. The default setting is vector display.

- Vector display: The sampling points are shown in the connecting line. This mode provides the most realistic waveform in most cases and makes it easy to view the steep edges of the waveform (e.g. square wave).
- Point display: Directly display the sampling point.

14.2. Persistence

Set the persistence in the “Display” menu, once the persistence is enabled, the oscilloscope uses the new acquired waveform to refresh the display but will not immediately delete the old acquired waveform. The old acquired waveform is displayed with the low brightness color, and the new acquired waveform is displayed with the normal color and brightness.

The persistence can set to auto, 50 ms, 100 ms, 200 ms, 500 ms, 1 s, 2s, 5 s, 10 s, 20 s, infinite, and off. The default is auto.

- Auto: When the trigger type is set to decoding type, the waveform is automatically displayed as a single amplitude.
- Adjustable persistence (50 ms...10 s, 20 s): In different persistence, the oscilloscope updates the display with the newly acquired waveforms, and the acquired waveforms are cleared after the appropriate time. Glitch with slower changes or lower probability of occurrence can be observed.
- Infinite: Once “Infinite” is selected, the oscilloscope never clears the acquired waveform. Use infinite persistence to measure noise and jitter, and to capture episodic events.
- OFF: Only a single amplitude waveform is displayed without persistence.
- Stop persistence: When the “Stop Persistence” is checked, the persistence effect remains on the screen after the oscilloscope is stopped. When “Stop Persistence” is unchecked, only a single waveform is displayed on the screen without the persistence effect.

14.3. Scale Display in Waveform View

In both stacking and overlay modes, the vertical and horizontal scales can be set to either movable or fixed. By default, the setting is movable.

- Movable: The scale moves along with the waveform, and the scale units are displayed.
- Fixed: When the vertical or horizontal position of the waveform is adjusted, the grid scale remains stationary and does not move with the waveform.

14.4. Grid Type

In the “Display” setting menu, four grid type can be set: grid display, full display, frame, and crosshair.

- Grid: Displays a grid with 8 rows and 14 columns.
- Full scale: Displays in crosshair and grid.
- Frame: No crosshair, no grid display.

- Crosshair: Divides the screen into 4 parts.

14.5. Grid Brightness

In the “Display” menu, rotate the Multipurpose A rotary knob or drag the scroll bar to set the grid brightness.

The brightness range: 0%-100%. The default is 50%.

14.6. Waveform Brightness

In the “Display” menu, rotate the Multipurpose A rotary knob or drag the scroll bar to set the waveform brightness.

The brightness range: 0%-100%. The default is 50%.

14.7. Backlight Brightness

In the “Display” menu, rotate the Multipurpose A rotary knob or drag the scroll bar to set the backlight brightness.

The brightness range: 0%-100%. The default is 50%.

14.8. Window Transparency

Set the window transparency for all pop-up info box (e.g. Cursor menu, Waveform view menu, etc.), set to the appropriate value for a better view of the measured data. Rotate the Multipurpose A rotary knob or drag the scroll bar to set the window transparency

The brightness range: 0%-100%, 0% represents non-transparent, 100% represents fully transparent, and the default is 50%.

Note: The auxiliary window is non-transparent by default.

14.9. Color Temperature

Switch on/off “color temperature” in the “Display” menu, the default setting is OFF.

Once the color temperature is displayed, the different color represents the number of data acquired or the probability on the screen.

15. Save and Load


- [Save Menu](#)
- [Save Waveform](#)
- [Save Setting](#)
- [Save Picture](#)
- [Load Setting](#)
- [File Browser](#)


Users can save the current oscilloscope settings, waveforms, screen images and parameters in various formats to internal memory or external USB storage devices (e.g. USB) and reload the saved settings or waveforms as required. It is also possible to load the updated version of the software into the system to upgrade the instrument. In addition, the user can copy, delete and rename files of specified types in internal memory or external USB memory using the Disk manager menu.

Note: This oscilloscope has 3 USB HOST ports (1 on the front panel, 2 on the rear panel) for connecting a USB flash drive to perform external storage.

15.1. Save Menu

The save setting menu can be entered using the following steps.


- Click the Home icon at the top-right of the screen and select the save icon to enter the save setting menu.
- If the save function is added to the toolbar, click the counter icon  in the toolbar at the top-right of the screen to enter the save setting menu. The save setting menu has two sub-menu “Save” and “Load”, please select the sub-menu to set.



The 'Storage' dialog box is shown with the 'Save' tab selected. The 'Type' section has 'Image' selected with a radio button. The 'Image Type' section has '*.png' selected. The 'Color' section has 'Color' selected. The 'Page Header' and 'Invert' sections both have 'On' selected. The 'Path' field contains 'Local:/picture'. The 'Name' field contains 'unit001'. The 'Suffix' section has 'Add' selected. A 'Save' button is visible on the right, and a '< Disk' button is at the bottom left.

15.2. Save Waveform

Enter the submenu of “Save” to select “Save Waveform” to enter the setting menu, the channel that has selected source (vertical scale, horizontal time base) can be saved to internal or external storage.



The 'Storage' dialog box is shown with the 'Save' tab selected. The 'Type' section has 'Waveform' selected with a radio button. The 'Data Source' dropdown menu is set to 'Screen(.dat)'. The 'Source' dropdown menu is set to 'C1'. The 'Path' field contains 'Local:/wave'. The 'Name' field contains 'unit001'. The 'Suffix' section has 'Disable' selected. A 'Save' button is visible on the right, and a '< Disk' button is at the bottom left.

Waveform setting menu: data type, source, save path, filename, and suffix.

(1) Data Type

Click on the “Data Type” to select the data type of the waveform to be saved, it has three kinds of screen (.dat), deep memory (.csv), and arbitrary wave (.bsv). Screen (.dat) and deep memory (.csv) files can be opened using the host software analyzer. Additionally, arbitrary waveforms (.bsv) can be loaded into either the signal source or the oscilloscope's generator.

(2) Source

Click on the “Source” to select the source of waveform to be saved. For waveform data storage, only open sources are supported. When saving .dat and .bsv, the source can select C1 - C4 and M1 - M4. When saving “.csv”, the source can select C1 - C4, M1 - M4, Digital, or analog channel (all active analog channels).

(3) Save Path

Double-click on “Save Path” input field to open the file browser menu, and select the save directory in the file browser menu, then click “Enter” key to set the save path. For the use of file browser, refer to the section of [File Browser](#). When a USB flash drive is not connected, the default save path is the local disk “Local:/wave”. When a USB flash drive is detected, “UDISK:” is selected as the default save path.

(4) Filename

Double-click on the “Filename” input field to open the numeric keypad to set the filename. For details on the use of the numeric keypad, refer to “Enter Character String” in the section of [5.8 Parameter Setting](#).

(5) Suffix

Tap to select the suffix to “Forbid”, “Time”, or “Accumulate”. The filename of the picture will be saved with the selected suffix to the internal or external storage.

- Forbid: Save the file using the filename only, without adding a suffix.
- Time: Add the current system time as the suffix for the filename to be saved.
- Accumulate: Add the accumulated number as the suffix for the filename to be saved, the number starting from 0001 to accumulate.

(6) Save Time Setting

Time saving means adding a time column to the saved CSV file, which can be set when choosing CSV as the data source (not supported by the Digital signal source). When the "Time Save" checkbox is checked, the saved CSV file will contain both time and voltage columns; when unchecked, the saved CSV file will contain only the voltage column.

(7) Disk Manager


Click on the “Disk Manager” to jump to the file browser. For the use of file browser, refer to the section of [File Browser](#).

(8) Save

Click on the “Save”, the system will save the waveform file according to the current setting and display a saving result hint.

15.3. Save Setting

Enter the submenu of “Save” to select “Save Setting” to enter the setting menu, the oscilloscope will save the setting with the format of “.set” to internal or external storage. The saved setting can be loaded as required.



Save setting menu: file type, source, save path, filename, and suffix.

(1) File Type

Click on the “Data Type” to select the data type of waveform to be saved, *.set can be selected.

(2) Save Path

Double-click on “Save Path” input field to open the file browser menu, and select the save directory in the file browser menu, then click “Enter” key to set the save path. For the use of file browser, refer to the section of [File Browser](#). When a USB flash drive is not connected, the default save path is the local disk “Local:/wave”. When a USB flash drive is detected, “UDISK:” is selected as the default save path.

(3) Filename

Double-click on the “Filename” input field to open the numeric keypad to set the filename. For details on the use of the numeric keypad, refer to “Enter Character String” in the section of [5.8](#)

[Parameter Setting.](#)

(4) Suffix

Tap to select the suffix to “Forbid”, “Time”, or “Accumulate”. The filename of the picture will be saved with the selected suffix to the internal or external storage.

- Forbid: Save the file using the filename only, without adding a suffix.
- Time: Add the current system time as the suffix for the filename to be saved.
- Accumulate: Add the accumulated number as the suffix for the filename to be saved, the number starting from 0001 to accumulate.

(5) Disk Manager


Click on the “Disk Manager” to jump to the file browser. For the use of file browser, refer to the section of [File Browser](#).

(6) Save

Click on the “Save”, the system will save the setting file according to the current setting and display a saving result hint.

15.4. Save Picture

Enter the submenu of “Save” to select “Save Picture” to enter the setting menu, the oscilloscope will save the picture according to the setting to internal or external storage.



Picture save setting menu: picture type, color, page header, inverse color, save path, filename, and suffix.

(1) Picture Type

Click on the “Picture Type” to select the format to “*.png”, “*.bmp”, or “*.jpg”. The screen image will be saved with the selected format to internal or external storage.

(2) Color

Click on the “Color” to select the picture color to be saved.

Color	The oscilloscope's screenshot will be saved with the displayed color.
Save ink	The oscilloscope's screenshot will change the dark background to light color and be saved, this is to save ink.
Grey	The oscilloscope's screenshot will change color to grey and be saved.
Grey & Save ink	The oscilloscope's screenshot will change the dark background to light color and change the color to grey and be saved.

(3) Page Header

Click on the “Page Header” to switch on/off the page header.

ON: The instrument model and image data will be displayed in the page header.

OFF: No information is displayed in the page header.

(4) Inverse Color

Click on the “Inverse Color” to switch on/off the inverse color function.

(5) Save Path

Double-click on “Save Path” input field to open the file browser menu and select the save directory in the file browser menu, then click “Enter” key to set the save path. For the use of file browser, refer to the section of [File Browser](#). When a USB flash drive is not connected, the default save path is the local disk “Local:/wave”. When a USB flash drive is detected, “UDISK:” is selected as the default save path

(6) Filename

Double-click on the “Filename” input field to open the numeric keypad to set the filename. For details on the use of the numeric keypad, refer to “Enter Character String” in the section of [5.8 Parameter Setting](#).

(7) Suffix

Tap to select the suffix to “Forbid”, “Time”, or “Accumulate”. The filename of the picture will be saved with the selected suffix to the internal or external storage.

- Forbid: Save the file using the filename only, without adding a suffix.
- Time: Add the current system time as the suffix for the filename to be saved.
- Accumulate: Add the accumulated number as the suffix for the filename to be saved, the number starting from 0001 to accumulate.

(8) Disk Manager


Click on the “Disk Manager” to jump to the file browser. For the use of file browser, refer to the section of [File Browser](#).

(9) Save

Click on the “Save”, the system will save the picture file according to the current setting and display a saving result hint.

15.5. Load Setting

Enter the submenu of “Save” to select “Load Setting” to enter the setting menu, to load the saved setting file to the oscilloscope.



(1) File Type

Select the type of loading setting file, the default type is“.set”, and cannot be changed.

(2) File

Click on the “Browse” to enter the file browser and select the setting file to be loaded. For the use of file browser, refer to the section of [File Browser](#).

(3) Load

Click on the “Load” to load the selected setting file.


(4) Disk Manager

Click on the “Disk Manager” to jump to the file browser. For the use of file browser, refer to the section of [File Browser](#).

15.6. File Browser

Enter the “Save” menu and to select “Disk Manager” at the bottom left corner to enter the disk

manager menu, as shown in the following figure.



(1) Select Disk

Before connecting an external storage, please make sure that USB (FAT32, Flash) is correctly connected. The save interface displays the contents of Local by default. If an external storage is connected, click the hardware icon in the top left in the “Save” menu to select “Local”, or “USB”. If “USB” is selected, the save interface will display the contents of USB.

After selecting a file path, press the key or in the upper left corner of the popup box to undo the path selection, or press the key to navigate to the previous directory.

Note: The USB name appears as the USB flash drive's name and cannot be modified.

(2) Preview

To preview locally saved images, select an image and click 'Preview.' If you have more than one image, the user can click '<' on the left side and '>' on the right side to switch between them.

(3) New File

Click on the icon to open the numeric keypad to add a new file and enter the new filename. For details on the use of the numeric keypad, refer to “Enter Character String” in the section of [5.8 Parameter Setting](#).

(4) Rename File or Directory

Click on the icon to open the numeric keypad to rename the file or directory.


(5) Copy File to the Specified Directory

Select the specified file or file folder, click on the copy icon and enter the specified file folder and then click the paste to complete this setting.


(6) Paste

Select the specified file or file folder, click on the paste icon to copy the file or file folder to the specified file folder.




(7) Delete

In the current directory, tick on the file or directory to be deleted, and click on the delete icon , and then click on the “Enter” to complete this setting, click on the “Cancel” to cancel this setting.

(8) Delete All

Delete all files and file folders in the current directory. Click on the delete icon  and then click on the “Enter” to complete this setting, click on the “Cancel” to cancel this setting.

(9) Multiple Choice

This oscilloscope supports selecting multiple files or file folders at the same time. Click the multiple-choice icon , click the check box to the right of the file, and it will be displayed in the selected state  when the selection is complete, and then deselect it by clicking the check box again, and the check box will return to its original state . The user can also select all files and directories under the current disc by clicking the check box at the top-right of the screen of the menu. Clicking the check box again will cancel the Select All operation.




(10) Suffix Type

Click on the “File browser” at the top-right of the screen and select the suffix type, *.*, .png, .bmp, .jpg, .csv, .bsv, .dat, .set, .pdf, .html, *.* represents all file types.


16. Reference Waveform

During the actual test, the user can compare the signal waveform with the reference waveform to determine the cause of the fault.

The reference waveform can be entered using the following steps.

- Press the **Ref** key on the front panel to enter the reference waveform setting menu.
- Click the Home icon  at the top-right of the screen and select the reference icon  to enter the reference waveform.
- If the reference waveform is added to the toolbar, click the reference icon  to enter the reference waveform.

This oscilloscope provides 4 reference waveforms (RefA - RefD), the setting of each reference waveform is the same. This chapter describes how to set the reference waveform using RefA as an example.



16.1. Display

Click on the “Display” to switch on/off the display of reference waveform.

16.2. Source

Click on the “Source” to select the source of waveform to be saved. Only the opened sources are supported to save waveform data, C1 - C4, M1 - M4 can be selected.

16.3. Save

(1) File Path

Double-click on the “File Path” input field to open the file browser menu, and select the save catalogue in the file browser menu, then click “Enter” key to set the save path. For the use of

file browser, refer to the section of [File Browser](#). When a USB flash drive is not connected, the default save path is the local disk “Local:/wave”. When a USB flash drive is detected, “UDISK:” is selected as the default save path.

(2) Filename

Double-click on the “Filename” input field to open the numeric keypad to set the filename. For details on the use of the numeric keypad, refer to “Enter Character String” in the section of [5.8 Parameter Setting](#).

(3) Waveform Type

The default waveform type is *.dat, and cannot be changed.

16.4. Load



Click on the “Browse” to open the file browser menu and click the waveform file to be loaded. Click on the “Import” to load the selected waveform file. Tap on the “Import” menu, the recently 5 load file records will be displayed, the record can also be selected to load.

16.5. Quick Reference

Click on the “Quick reference” to load the currently selected source for reference but will not save the waveform file.dat. The Quick Reference function is only available for the current source, it should be re-selected after deletion.

16.6. Vertical Scale



Set the vertical scale of Ref wave in the display window, it can be set using the following steps.

- In “Ref” menu, click on the “Vertical scale” input field, rotate the [Multipurpose A](#) rotary knob on the front panel to change the vertical scale.
- Tap the vertical scale icon ,  on the right to increase or decrease the vertical scale.
- Click on the number input field to open the numeric keypad to enter the specified numeric value.

16.7. Vertical Position


Set the vertical offset of Ref wave in the display window, it can be set using the following steps.

- In “Ref” menu, click on the “Vertical position” input field, rotate the [Multipurpose A](#) rotary knob on the front panel to change the vertical position.

- Tap the arrow key ,  on the right of the vertical position to increase or decrease the vertical position.
- Click on the number input field to open the numeric keypad to enter the specified numeric value.

16.8. Label

Click on the “Label” to switch on/off the channel label. The label can be customized, double-click on the “Label” input field to open the numeric keypad to enter the character string.






16.9. Channel Color


Set the color for the Ref waveform and label. Click on the “Channel Color” to enter the setting menu.

- Source: Click on the “Source” to select the source to set the color, the source can select M1, M2, M3, M4, R1, R2, R3, or R4.
- Color: Tap the color plate and drag to select the color.

17. Utility Function

Set the system function in the “Utility” menu. The utility menu can be entered using the following steps.

- Click the Home icon  at the top-right of the screen and select the utility icon  to enter the utility setting menu.
- If the utility function is added to the toolbar, click the utility icon  in the toolbar at the top-right of the screen to enter the utility setting menu.



17.1. Basic Information

The basic information includes language, restore setting, sound, power-on state, and vertical extension.

(1) Language

Click on the “Language” to set the system language to English, simplified Chinese, or traditional Chinese, Italian, Spanish, French, German or Polish.

(2) Restore Setting

Click on the “Factory Setting”, the oscilloscope will restore to the factory settings and all local files will be deleted.

(3) Sound

Click on the “Sound” to switch on/off the beep. When the sound is on, a buzzer sounds when the following operations or actions are performed.

- Press the key on the front panel or menu key
- Use the touch screen function
- Prompt a message

(4) Power-on State

Set the power-on mode of the oscilloscope, it can set always off, always on and last status.

- Always off: When the power switch on the rear panel is turned on, the oscilloscope can only be opened by manually pressing the power soft key on the front panel.
- Always on: The oscilloscope can be opened directly when the power switch on the rear panel is switched on.
- Last status: When the rear panel power switch is switched on, the oscilloscope restarts according to the last shutdown state; if the last shutdown was via the power soft key, the oscilloscope should switch on via the power soft key; if the last shutdown was via direct power down, the oscilloscope can be opened directly.

(5) Vertical Extension

Click the vertical extension for the waveform.

- Screen center: When changing the vertical scale, the waveform will be extended or compressed around the screen center.
- Channel's zero position: When changing the vertical scale, the waveform will be extended or compressed around the channel's zero position.

17.2. Network Setting

When the device is connected with available internet, IP setting is used to set the IP, subnet mask, gateway, and DNS address of the oscilloscope.

(1) IP Mode

Set the IP acquire mode, it can be set to manual or auto (DHCP).

- Manual: Manually set IP address, subnet mask, gateway address, and DNS address.
- Auto (DHCP): Only for checking IP address, subnet mask, gateway address, and DNS address.
 - a. IP Address: IP address format is nnn.nnn.nnn.nnn. The first nnn range is from 1 to 233, and the second nnn range is from 0 to 255. It is recommended that users can consult network administrators for an available IP address.
 - b. Subnet mask: The format is nnn.nnn.nnn.nnn. The nnn range is from 0 to 255. It is

recommended that users can consult network administrators for an available subnet mask.

- c. Gateway address: The format is nnn.nnn.nnn.nnn. The first nnn range is from 1 to 255, and the second nnn range is from 0 to 255. It is recommended that users can consult network administrators for an available gateway address.
- d. DNS address: The format is nnn.nnn.nnn.nnn. The first nnn range is from 1 to 255, and the second nnn range is from 0 to 255. It is recommended that users can consult network administrators for an available DNS address.

(2) Apply

After manually editing the IP address, subnet mask, gateway address and DNS address information, click on the "Apply" to complete the setting.

(3) LAN Reset

If you want to clear the IP address, subnet mask, gateway address and DNS address, click on the "LAN Reset" to clear the edited IP address, subnet mask, gateway address, and DNS address.

17.3. Frp Setting

To configure external network access, click "Apply" after entering the settings. The user can then continue to access the network using the new FRP proxy IP address information that you modified (assuming the configuration is correct).

(1) Frp

Set the FRP status to either On or Off. When the status is set to "On", the oscilloscope can be connected via FRP.

(2) IP Setting

- a. Frp_ip address: IP address format is nnn.nnn.nnn.nnn. The first nnn range is from 1 to 233, and the other three nnn range is from 0 to 255. It is recommended that users can consult network administrators for an available IP address.
- b. Web port range: 1000 – 65535, default: 9005.
- c. Control port range: 1000 – 65535, default: 9006.
- d. Picture port range: 1000 – 65535, default: 9007.

(3) Apply

After manually editing the IP address, port, control port, and picture port information, click "Apply" to complete the settings.

Note: This machine uses frp intranet penetration to enable extranet access. It utilizes version 0.34.0

of frp, with this machine operating as a client. To function properly, the client must connect to a server that has frp server running. The client connects the frp server via port 7000, so the server needs to be configured with `bind_port = 7000`. If multiple oscilloscopes are connected to the same frp server, the web port, picture port, and control port for each oscilloscope must be unique; otherwise, the frp proxy will fail and become inaccessible. If the frp proxy settings are modified, it will not be possible to access the device through LAN at ip:9000. To restore normal LAN access, press the **Default** button on the oscilloscope panel to reset the configuration, after which access via port 9000 can resume.

17.4. Square Selection

This oscilloscope has two square output ports: Port 1 and Port 2, corresponding to Probe Comp1 and Probe Comp2 on the front panel. The ports support frequency selection as shown in the table below. The default frequency is 1 kHz.

Port	Frequency
Port 1	10 Hz, 100 Hz, 1 kHz, 10 kHz, 100 kHz, 3V_REF
Port 2	10 Hz, 100 Hz, 1 kHz, 10 kHz, 100 kHz

17.5. Rear Panel

In the auxiliary menu, click on the “Rear panel” or drag the content to enter the rear panel setting

(1) 10MHz Sync

- Idle: The [10MHz REF In&Out] connector on the rear panel is not used as an input or output port for the reference clock.
- Input: The [10MHz REF In&Out] connector on the rear panel is used as an input port for the reference clock.
- Output: The [10MHz REF In&Out] connector on the rear panel is used as an output port for the reference clock.

(2) AUX Output

AUX output is used to select the output signal for the [AUX Out] connector on the rear panel.


- Output: Every time the oscilloscope generates a trigger, a signal reflecting the current capture signal of the oscilloscope is output from the [AUX Out] connector on the rear panel. When this signal is connected to the waveform display and device and measure the frequency of this signal, the measured result is the same as the current capture signal.
- Pass/Fail: In a pass/fail test, a positive or negative pulse is output from the rear panel [AUX Out] connector when the oscilloscope detects a pass or fail event.

- DVM: During a DVM test, when a DVM alarm signal is detected, either a positive or negative pulse is output through the [AUX OUT] connector on the rear panel.

17.6. Self-inspection

(1) Keyboard Self-inspection

Keypad detection is mainly used to detect when the front panel keys or knobs of the oscilloscope are not responding or are not responding sensitively. Press the self-inspection key, the oscilloscope will enter the following figure.




Rotary knob test: Rotate and press each rotary knob from up to down, left to right, observing the rotary whether the rotary knob indicator is lit on the display interface.

Key test: Rotate and press each key from up to down, left to right, observing the rotary whether the key indicator is lit in real time on the display interface.

When all rotary knobs and keys have been tested, press the "Run/Stop" keys three times to exit the keyboard test in accordance with the on-screen instructions.

(2) LED Detection

LED detection is mainly used to check whether the key indicator on the front of the oscilloscope can be lit or not, and whether the brightness is poor. When the LED test is pressed, the oscilloscope enters the interface is shown in the following figure.




Rotary knob test: Enter the LED test, rotate the Multipurpose A rotary knob, the first LED on the front panel is light and the corresponding position of the key will be illuminated on the screen, continue rotating the Multipurpose A rotary knob to switch to the next LED. Using this method to detect all the key indicators one by one, observing whether all indicators on the front panel are illuminated.

Key test: Touch the white key on the screen, observing whether LED is lit in real time on the front panel.

When all rotary knobs and keys have been tested, press the Run/Stop keys three times to exit LED test in accordance with the on-screen instructions.

(3) Touch Screen Detection

Touch screen detection is mainly used to check whether the touch screen is invalid or not responding in time. Press the touch screen detection, the oscilloscope enters the interface is shown in the following figure.



Touch each grid on the touch screen to observe if the grid turns blue.

When all rotary knobs and keys have been tested, press the Run/Stop keys three times to exit the touch screen test in accordance with the on-screen instructions.

(4) Screen Detection

Screen detection is used to check whether the oscilloscope screen has color offset, bad dots, or screen scratches. Press the screen detection, the oscilloscope enters the interface is shown in the following figure. The interface displays pure red.



Press any key on the right panel to switch to the red, green, blue, black, and white according to the on-screen instruction. Observe the screen under the appropriate surface of each color to see if there are any serious problems such as color differences, stains or scratches.

When the color test has been tested, press the "Run/Stop" keys three times to exit the touch screen test in accordance with the on-screen instructions.

17.7. Auto-calibration

The auto-calibration function allows the oscilloscope to reach the optimum working condition for the most accurate measurement. The auto-calibration function is divided into analog channel calibration and Digital calibration. This function can be performed at any time, especially when the ambient temperature range varies within 5°C or more. Before performing the auto-calibration operation, please make sure that the oscilloscope has been turned on and running for more than 20 minutes.

- (1) Analog channel calibration: The calibration is only for analog channel and the calibration time is 3-5 min.
- (2) Digital calibration: The calibration is for digital channel and the calibration time is 3-5 min.

17.8. About Oscilloscope

Click on "About" in the auxiliary menu to check the oscilloscope information.

- Model: Product model
- Serial number, which is the unique identification
- Firmware version number
- Logic version number
- Hardware version number

17.9. Option

Click on the "Option" in the auxiliary menu to check all options.

Select any one of the options to enable it or click on the "All activate" to enable all the options, as shown in the following figure.

All options support a 540-hour trial period. After the trial period is over, users need to purchase the option and get the option license.

The procedure for obtaining a software license for the option is as follows:

1. Purchase the option key from a distributor.
2. Go to the UNI-T official website and navigate to Test Instrument > Service and Support > License Activation to access the software license activation page.
3. On the software license activation page, enter the purchased key, device serial number, and verification code as prompted. The software license will be generated immediately.

The steps for installing the software license for the option are as follows:

1. Download the software license from the License Information list, save it to the USB root directory, and insert the USB drive into the device.
2. Go to Utility > Options, and click "Activate" or "Activate All" to activate the option using the software license.
3. To verify that the license has been installed, open Utility > Options. In the option trial table, the Activation Status field will display "Activated", and the Trial Duration field will display "Permanent."

Note: If you have registered and logged in to the UNI-T official website and provided your email address during registration, the generated software license will be sent to your email as an attachment. The user can also view and download the software license again from the license activation page after logging in to the UNI-T official website.

MSO5000HD series supports the following optional functions, as shown in the table below:

Model	Option
MSO5000HD Series	CAN-FD, FlexRay, SNET, Audio, 1553B, Manchester, ARINC429, 1-WIRE, I3C, CAN-XL, PWR, AWG, timing analysis, bandwidth upgrade

17.10. Auto Setting

Click on the "Auto setting" in the auxiliary menu to enter the auto setting menu.

(1) Channel Setting

- In hold mode, the bandwidth limit, inverse phase, impedance, unit, probe attenuation ratio, label state remains the same, and coupling (ground), Vertical scale, offset and fine-tuning are reset to the default.
- In auto mode, the impedance, unit, probe attenuation ratio, and label state remain the same; other settings are reset to the default.

(2) Acquisition Setting

- In current mode, all settings remain the same.
- In auto mode, the acquisition mode reset to the default; other settings remain the same.

(3) Trigger Source

- In current mode, the source, trigger coupling remains the same; other settings are reset to “edge trigger, auto, rising edge”.
- In auto mode, all parameters are reset to the default.

(4) Activate Channel

- In current mode, the switch state remains the same when the channel is automatically set.
- In auto mode, only channels with a signal input will be activated.

17.11. Quick Operation




In the auxiliary menu, press the **Quick** button on the front panel to configure the operations of screenshot, save waveform, and save settings.


- Screenshot: Press the **Quick** button to save the screenshot to the specified path. The picture format, color, and suffix will follow the settings in the save interface.
- Save waveform: Press the **Quick** button to save the channel waveform to the specified path. The waveform format, source, and suffix will follow the settings in the save interface.
- Save settings: Press the **Quick** button to save the setting file to the specified path. The suffix will follow the settings in the save interface.

18. Waveform Recording

The Waveform Record and Playback function allows you to playback recorded waveforms, enabling convenient analysis.

The Waveform Recording Menu can access using the following methods.

- Press the **Analyze** on the front panel to open the “Analyze” menu to click “Recording” to access the “Waveform Recording” menu.
- Click the Home icon  at the top-right of the screen and select the waveform recording icon  to enter the waveform recording menu.
- If the waveform recording function is added to the toolbar, click waveform recording icon  in the toolbar at the top-right of the screen to enter the waveform recording menu.






(1) Turn on/off Recording




Click on the “Recording” switch to toggle the waveform recording to ON or OFF. Before using this function, refer to the [Recording Setting](#) section.

(2) Recording

Click “Recording” to start recording.




- Click on the “Recording” key  to start recording. The recording icon  will change to , indicating that recording is in progress.
- The data displayed on the right side of the recording progress bar represents the current


number of frames out of the total number of recorded frames. During the recording process, the current recording information is shown on the screen in real time, with the current number of frames continuously updating.

- After recording, the recording icon  will change to  , indicating that recording has stopped.
- During recording, click the icon  can pause the recording,



(3) Playback

Click on the “Playback” icon  to play back the recorded waveform. When playback starts, the icon  changes to , indicating that the waveform is being played back. For more details about playback, refer to the [Playback Setting](#) section.

During playback, “Current Frame” will change in real time. The user can click pause key  to stop the playback.

18.1. Recording Setting

During waveform recording, the oscilloscope records the waveforms of all currently opened channels at specified intervals until the user manually stops the recording operation or the number of recorded frames reaches the set limit.

Before waveform recording, the following recording option parameters can be configured.

(1) Sequential Acquisition

Sequential acquisition, which allows for continuous and uninterrupted recording, improves the waveform capture rate. During sequential acquisition, the waveform is not displayed on the screen and can only be played back after the recording is completed. It can be set to on or off.

(2) Recording Frame

The number of recording frames refers to the total number of frames that can be recorded. After starting the recording operation, the oscilloscope will automatically stop recording when the number of recorded frames reaches the specified limit. Double-click on the “Recording Frame” input field to open the numeric keypad to set the recording frame. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the [Multipurpose A](#) rotary knob to adjust the recording frame. The setting range can be set from 1 to the maximum frame.

(3) Maximum Frame

Maximum frames input box displays the highest number of frames that can be recorded.

Since the waveform memory size is fixed, a higher number of points per waveform frame results in fewer frames being recorded. Therefore, the maximum number of frames is directly related to the currently selected Memory Depth (see Memory Depth). The number of points per frame equals the current memory depth, which is calculated as $\geq \text{sampling rate} \times \text{horizontal time base} \times \text{the number of frames displayed horizontally on the screen}$. Consequently, the maximum value for waveform recording is also influenced by the “Sample Rate” and “Horizontal Time Base”.

(4) Recording Interval

The recording interval is the time interval between frames during the recording process.

Double-click on the “Recording Interval” input field to open the numeric keypad to set the recording interval. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the recording interval. The setting range can be set from 0 s to 10 s

(5) End Recording




The beeper sounds like a beep when recording ends.



The beeper does not sound when recording ends.

18.2. Playback Setting

Before waveform recording, the following recording option parameters can be configured.



(1) Playback Mode

The playback mode is divided into two modes: single playback and cycle playback . Click the icon at the bottom left corner of the screen to switch between modes.





Playback starts from the start frame and ends at the end frame, stopping automatically.



Playback starts from the start frame and ends at the end frame, repeating until manually

stopped.

(2) Playback Order

The playback order consists of two types: sequential playback  and reverse playback . Click the icon at the bottom right corner of the screen to switch between them.





: Playback starts from the start frame to the end frame.



: Playback starts from the end frame to the start frame.

(3) Minimize

Minimize the playback window as needed. Click the minimize icon  to reduce the size of the playback window, simplifying the interface for a more intuitive and user-friendly experience; click the restore icon  to revert the window to its original size and exit the minimized view.

(4) Current Frame

When the playback is stop, double click on the “Current Frame” input field to open the numeric keypad to set the current frame. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the current frame. The maximum value that can be set is equal to the number of recorded frames.

(5) Playback Interval

The playback interval refers to the time interval between frames during playback. Double click on the “Playback Interval” input field to open the numeric keypad to set the playback interval. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the playback interval. The setting range can be set from 0 s to 10 s.

(6) Start Frame

The start frame is the frame from which playback begins. Double click on the “Start Frame” input field to open the numeric keypad to set the start frame. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the start frame. The default is 1. The maximum value that can be set is equal to the number of recorded frames.





(7) Stop Frame


The end frame is the frame at which playback stops automatically. Double click on the “Stop Frame” input field to open the numeric keypad to set the stop frame. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the stop frame. The default is the total number of frames in the recorded waveform.

19. Pass/Fail Test

In product design and production, monitoring signal changes and determining product qualification is often necessary. The standard pass/fail test function of this series of oscilloscopes effectively fulfills this need. Users can establish test rules based on known 'standard' waveforms, compare the signal under test with these standards, and display statistical information about the results. When the oscilloscope identifies a pass or failure, the user can choose to stop monitoring immediately, activate a buzzer alarm, and save the current screenshot.

The Pass/Fail Test menu can access using the following method.

- Press the **Analyze** on the front panel to open the “Analyze” menu to click “Pass/Fail” to access the “Pass/Fail” menu.
- Click the Home icon  at the top-right of the screen and select the pass/fail test icon  to enter the pass/fail test menu.
- If the pass/fail test function is added to the toolbar, click pass/fail test icon  in the toolbar at the top-right of the screen to enter the pass/fail test menu.
- If pass/fail test results appear, click on the icon  to open the pass/fail test menu.



19.1. Turn on/off Pass/Fail Test

Click on the “Pass/Fail” switch to toggle the pass/fail test to ON or OFF.

19.2. Source

Click on the “Source” to select C1 - C4.

19.3. Template Setting

(1) Template Source

Click on the “Template Source” to select the source for creating a template. The source can choose from C1 - C4 and Ref.

(2) Adjusting Vertical

Double-click on the “Adjusting Vertical” input field, use the Multipurpose A rotary knob to adjust the vertical tolerance. The setting range can be set from 1 to 100.

(3) Adjusting Horizontal

Double-click on the “Adjusting Horizontal” input field, use the Multipurpose A rotary knob to adjust the horizontal tolerance. The setting range can be set from 1 to 50.

(4) Creating Test Rule

After setting the “Template Source”, “Adjusting Vertical”, and “Adjusting Horizontal”, click on the “Creating Rule” to define the test rule (the blue area are not covered on the screen).

(5) Load Test Rule

When the pass/fail test function is enabled, the user can load and recall test rule files stored in the instrument's internal memory or an external USB flash drive (if the USB flash drive is detected) and apply them to the current pass/fail test. Click “Load Rule” to access the file loading interface. Select the specified test rule file (*.tmp) from the “File Path” and apply it to the current pass/fail test.

(6) Save Test Rule

When the pass/fail test function is enabled, the user can save the current test rule range to the instrument's internal memory or an external USB flash drive in *.tmp format (if the USB flash drive is detected). Click “Save Rule” to open the file-saving interface. Enter the necessary information in the “File Name” and “Save Path” fields to save the test rule file to either internal or external memory. For details on the saving process, refer to the [Storage and Load](#) section.

19.4. Output Setting

(1) Aux Output

Click on the “Aux Output” switch to toggle the Aux Output function to ON or OFF.

- ON: When the Aux Output function is enabled, the AUX Output menu will automatically

switch to “Pass/Fail”, indicating that during a pass or failure event, the Aux Output connector on the rear panel will output a pulse.

- When the Aux Output function is disabled, the AUX Output menu will automatically switch to “Trigger Output”, indicating that the Aux Output connector on the rear panel is not linked to the pass/fail test.

(2) Output Condition

Configure the signal output from the Aux Output connector. The output can be set to two signal conditions: Pass or Fail.

- Fail: A pulse will be output when the AUX port on the rear panel of the oscilloscope detects a "Fail" signal, and the beeper will sound.
- Pass: A pulse will be output when the AUX port on the rear panel of the oscilloscope detects a "Pass" signal, and the beeper will sound.

(3) Output Pulse Width

Set the pulse width for the pass/fail test. Double-click on the “Output Pulse Width” input field to open the numeric keypad to set the output pulse width. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the output pulse width. The setting range can be set from 200 ns to 1.5 s.

(4) Output Polarity

Click on the “Output Polarity” set the polarity of the output pulse to “Positive” or “Negative”.

19.5. Stop Setting

(1) Stop Type

Stop type refers to the condition under which the pass/fail test will cease operation upon detecting a specific signal. This can be set to Fail or Pass.

- Fail: When a “Fail” is detected, the count of failed frames increases by 1. The test will automatically stop once the number of failures reaches the predefined threshold.
- Pass: When a “Pass” is detected, the count of successes increases by 1. The test will stop once the number of successes reaches the specified threshold.

(2) Stop Condition

Click on the “Stop Condition” to configure the condition for ceasing the test. This can be set to \geq or \leq .

- \geq : The test will automatically stop when the number of frames of the stop type is greater than or equal to the specified condition.

- ≤: The test will automatically stop when the number of frames of the stop type is less than or equal to the specified condition.

(3) Condition Time

Double-click on the “Condition Time” input field to open the numeric keypad to set the condition time. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the condition time. The setting range can be set from 1 to 60000.

(4) Screenshot

Click on the “Screenshot” switch to toggle the screenshot function to ON or OFF.

- ON: Automatically captures and saves a screenshot to local or external USB storage when the pass test is stopped upon meeting the test conditions.
- OFF: No screenshot will be captured when the test is stopped.

19.6. Operation and Reset


(1) Operation

After configuring all the options mentioned above, click on the “Operation” to configure the pass/fail test.

- Start: Initiates the pass/fail test.
- Stop: Terminates the pass/fail test.

(2) Reset

During the pass/fail test, click on the “Reset” can clear the test results and restart the pass/fail test.



Blue area is mask area

Test result

Test the waveform

If it intersects with the masked area, the test will be considered a failure.

Note: Pass/fail tests can only be started or stopped when the pass/fail test function is enabled, and the test rule ranges are saved and loaded. Source channel changes and test rule adjustments are not permitted while the test is in progress.

19.7. Pass/Fail Test Result

When the “Pass/Fail” function is enabled, the test results window will be displayed on the screen. Test results window: Displays fail frames, pass frames, total frames, and 6σ , as shown in the following figure.

Pass/Fail	
Total:	130398 wfm
Pass:	130398 wfm
Fail:	0 wfm
6σ:	0.0000000

- Total: Total tested frames
- Pass: Pass frames
- Fail: Fail frames
- 6σ: The ratio of fail frames to total tested frames

The 6σ criterion indicates that, out of one million operations, only 3.4 failures are expected.

20. System Upgrade

This series allows program updates via USB, providing convenience and flexibility.

There are two methods for updating using a USB flash drive:

Method 1: Turn on the oscilloscope, which will automatically detect the USB flash drive for updates.

Method 2: U Navigate to Home > Utility > Update to detect and select the update file on the USB flash drive.

To access the upgrade menu, enter the submenu "Upgrade" in the auxiliary menu. The oscilloscope supports three upgrade methods: Boot-up upgrade, local upgrade, and online upgrade. The specific steps are as follows.

(1) Boot-up Upgrade

- ① Press Utility key to enter the auxiliary function menu, click on the "About" to check the system information: model name, software and hardware version.
- ② Download the update file from UNI-T official website or ask UNI-T distributor to provide the upgrade file. The upgrade file is the same as the model and hardware version of the instrument, the software version is higher than the version of the instrument. Save the upgrade file in the root directory of the USB.
- ③ When the instrument is powered off, insert the USB drive and turn on the instrument by pressing the power soft key. The instrument will automatically detect and update.
- ④ The upgrade process takes 5 minutes. After the upgrade is finished, shut down the instrument and plug out USB.
- ⑤ Reboot the instrument to check that the system information is the same as the version supplied. If it is the same, the update is successful.

(2) Local Upgrade

Save the upgrade file to USB and connect USB to the instrument. The upgrade can be processed when the instrument detects USB.

① Upgrade File

Click on the "Upgrade File" in the root directory of USB or click on the "Browse" to enter the file browser to select the upgrade file, and then click on the "Enter" to process the upgrade setting.

② Upgrade

Click on the "Upgrade" to open the upgrade confirmation box to choose whether "Enter" or "Cancel" the upgrade.

- Enter: Process the upgrade according to the currently selected upgrade file.

- Cancel: Cancel the current upgrade or click the icon (⊗) on the right to cancel.

③ Refresh

Click on the "Refresh" to update and display the upgrade file.

(3) Online Upgrade

First, make sure that the LAN port on the rear panel of the instrument is connected to the network (if there is any restriction on the privileges, please open the network privileges).

Click on the "Online upgrade" to open the upgrade confirmation box to choose whether "Enter" or "Cancel" the upgrade.


- Enter: Process the upgrade according to the currently selected upgrade file.
- Cancel: Cancel the current upgrade or click the icon (⊗) on the right to cancel.

Note: Please ensure that the power is not shut down during the entire upgrade process, it is to avoid failure to reboot due to incomplete system upgrade content.

21. Bode Plot

The Bode plot function provides a frequency response curve for the Device Under Test (DUT).


During the scan, the oscilloscope configures the function/arbitrary waveform generator to output a signal to the DUT. It then compares the DUT's input and output signals, measuring the gain (G) and phase (P) at each frequency, which are plotted on the frequency response Bode plot. When the loop response analysis is complete, the user can move the cursor on the chart to view the measured gain and phase values at various frequency points. The user can also adjust the scale and offset settings for the amplitude and phase plots.



21.1. Sweep Configuration

(1) Wiring Diagram

Before using the Bode plot (Power Supply Rejection Ratio) function, set up the loop connections as shown in the diagram below. The user can open the wiring instructions to view the circuit connection diagram for using the Bode plot (Power Supply Rejection Ratio) function in the pop-up window.



(2) Operation

Click on the "Operation" to set the Bode plot to on or off.

(3) Mode

Click on the "Mode" to set the operating mode to Bode plot or power supply rejection ratio (PSRR).

- **Bode Plot:** Conducts a Bode plot scan, displaying both gain and phase curves simultaneously.
- **Power Supply Rejection Ratio (PSRR):** Performs a PSRR scan, displaying only the gain curve. The PSRR test determines how well a voltage regulator suppresses ripple noise across different frequency ranges. This analysis uses a waveform generator from the oscilloscope to provide a signal with varying frequencies, introducing ripple into the DC voltage supplied to the regulator. The AC RMS ratio of input to output is measured and plotted against the frequency range. Multiple methods can be used to measure PSRR. Due to higher background noise and lower sensitivity compared to a network analyzer, the oscilloscope PSRR measurement typically does not exceed -60 dB. However, PSRR testing with an oscilloscope is generally acceptable for a quick assessment of the overall PSRR behavior of the power supply under test.

(4) Sweep Mode

Click on the "Sweep Mode" menu to select the scanning mode: single scan and continuous scan.

- **Single sweep:** The sweep proceeds from the start frequency to the end frequency and then stops automatically.
- **Continuous sweep:** The sweep continuously cycles from the start frequency to the end frequency without automatically stopping.

(5) Sweep Settings

Set the sweep setting: Start frequency, stop frequency, sweep points, amplitude mode, amplitude setting, DC offset, and source impedance.

- a. **Start frequency:** Set the start frequency for the scan. Range: 50 Hz - 50 MHz.
- b. **Stop frequency:** Set the stop frequency for the scan. Range: 60 Hz - 50 MHz.
- c. **Sweep points:** Set the number of scan points; a higher number provides better scan resolution. Range: 1 - 1000.
- d. **Amplitude mode:** Set the amplitude of the scan signal, allowing for either fixed amplitude or variable amplitude.
 - **Fixed amplitude:** When the amplitude mode is set to fixed amplitude, the signal amplitude remains at a constant value. The adjustable range is 10 mV to 3 V (for a 50 Ω impedance) and 20 mV - 6 V (for a high-impedance setting).
 - **Variable amplitude:** When the amplitude mode is set to a variable amplitude, the input

signal can be set to different amplitudes at various frequency stages. The adjustable range is 10 mV - 3 V (for a 50 Ω impedance) and 20 mV - 6 V (for a high-impedance setting).

- e. DC Offset: Set the offset of the sweeping signal. The adjustable range is -1 V to 1 V.
- f. Source impedance: Set the source load to 50 Ω or high impedance.

(6) Channel Settings

Set the input and output signal channels for the device under test.

a. Input Source

Click on the "Input Source" menu to select the input signal channel for the Bode plot (Power Supply Rejection Ratio). C1 - C4 can be set.

b. Output Source

Click on the "Output Source" menu to select the output signal channel for the Bode plot (PSRR). C1 - C4 can be set.

Note: The input source and output source cannot be the same channel.

21.2. Display Setting

(1) Bode Plot Display Settings

Set the display parameters: Automatic settings, gain range, gain offset, phase range, phase offset, start frequency, stop frequency, gain display, and phase display.

- a. Automatic settings: Based on the amplitude and phase curves of the output signal, the oscilloscope automatically sets parameters such as gain range, gain offset, phase range, phase offset, start frequency, and stop frequency.
- b. Gain display: Set whether to display gain data and related information in the waveform window. The gain display can be toggled on or off.
- c. Phase display: Set whether to display phase data and related information in the waveform window. The phase display can be toggled on or off.
- d. Gain range: Set the gain range displayed in the waveform window. Range: 1 dB - 500 dB.
- e. Gain offset: Set the gain offset displayed in the waveform window. Range: -250 dB to 250 dB.
- f. Phase range: Set the phase range displayed in the waveform window. Range: 1° - 180°.
- g. Phase offset: Set the phase offset displayed in the waveform window. Range: -180° to 180°.
- h. Start frequency: Set the start frequency displayed on the horizontal axis of the waveform window. Range: 50 Hz - 50 MHz.
- i. Stop frequency: Set the stop frequency displayed on the horizontal axis of the waveform

window. Range: 60 Hz - 50 MHz.

21.3. Result Analysis and Export

(1) Result Analysis

The sweeping results are shown in the figure below. Using the data list and cursor measurement functions, the user can conduct a detailed analysis of the Bode plot curves. The data list provides information for each scan point, and the cursor line allows for flexible measurement of changes at various positions on the curve.



1. Gain scale: Displays the gain based on the configured gain range and offset.
2. GM (Gain Margin): The difference between the gain measurement at the frequency point where the gain is 0 dB and the phase is 0°, calculated as $GM = 0 \text{ dB} - \text{Gain Measurement}$.
3. PM (Phase Margin): The difference between the phase measurement at the frequency point corresponding to 0 dB gain and 0°.
4. Cursor: A movable cursor that measures the gain, phase, and frequency values at the intersection points of the gain result curve and phase result curve.
5. Two Cursor Lines: Displays the gain values, phase values, and frequency values at the intersection points with the gain and phase curves.
6. Swept phase result curve
7. Swept gain result curve
8. Frequency scale: Displays the configured start frequency and stop frequency for the sweep.
9. Phase scale: Displays the phase based on the configured phase range and offset.
10. The intersection points of the phase margin curve and the origin of the coordinate system.

11. The intersection points of the margin curve and the origin of the coordinate system.

(2) Table

The table provides information for each sweep point. By checking the "Table" option, the sweep point information will be displayed in tabular form. The displayed content includes the sweep point, frequency, amplitude, gain, and phase.



21.4. Result Analysis and Load

(1) Save Results Table

After opening the result table, click the "Save Event Table" to pop up the export setting menu, the data can be saved as *.csv to internal storage or external USB disk drive (when a USB is detected). For the setting steps, refer to the section of [Save and Load](#).

(2) Load Results Table

When Bode plot or PSRR (Power Supply Rejection Ratio) data is saved to the internal storage or an external USB flash drive (only when a USB drive is detected), load the table to the oscilloscope and display the corresponding Bode plot or PSRR graph. Check on the "Table" option and click the "Load" to open the load setting window. Double-click the "File" input field to open a file browser. In the file browser, select the file to load and click the "Load" to display Bode plot or PSRR data.


22. Web Access

22.1. Access Local Area Network

The computer and spectrum analyzer should share the same LAN. Check the local IP address through the UTILITY menu of spectrum analyzer, and then the browser accesses the spectrum analyzer using http://ip:9000 port.

Example:

- Computer IP: 192.168.42.3
- Oscilloscope IP: 192.168.42.12
- PC browser using 192.168.42.12 to access the oscilloscope can check the basic information, as shown in the following figure.



When you click on the "SCPI Command", "Instrument Control", "Network Settings", or "Password Settings" tab, you will need to log in. Please refer to the "Login Web" section for detailed login instructions.

22.2. Login Web

Many operations require logging into the web system. The login credentials are as follows:

- **Username:** admin
- **Password:** The initial password is the serial number of the oscilloscope after Base64 encoding. Once you have successfully logged in, the user can set up a customized password according to your needs. After creating the customized password, the user can use it for future logins.

22.3. Access Outer Network


To access the oscilloscope from an external network, where the access terminal and the oscilloscope are not on the same network segment, follow these procedures:

- Ensure the network cable is plugged into the oscilloscope and that internet access is available.
- Turn on the frp proxy service on the server.
- Configure the frp proxy service and IP port of the oscilloscope.
- Accessing the port http://IP:web_port via browser, which is to visit the oscilloscope, the access interface is same as above mentioned

Note: This instrument uses a way of frp (Fast Reverse Proxy) intranet penetration to access the outer network. The frp version is 0.34.0. The instrument carries an FRP-0.34.0 client port, required with a server to run, with frp sever opened. The client connects to the FRP server port 7000, so the server configuration must include “bind_port = 7000”.

22.4. Home Page

The home page of the web system displays the basic information of the currently connected instruments, along with network information and an option list.



UNI-T Login

Home SCPI Command Instrument Control Password Set LAN Config Service & Support Help

Basic Info LAN Info Option List

Device Identify

Manufacturer	UNI-T
Model	MSO5000HD
Serial Number	def1234
Firmware Version	V1.00.0015
Device Description	UNI-T MSO5000HD def1234

LAN Info

IP Address	192.168.20.209
Mask	255.255.254.0
Gateway	192.168.20.1
MAC	52:CB:E7:B3:92:A4
Auto MDIX Capable	false

22.5. SCPI

On the Web System SCPI Command page, the user can send SCPI commands to the currently connected oscilloscope.

- Input command: Click “Input Command” to expand the drop-down list of SCPI commands. This list displays all the SCPI commands supported by the oscilloscope. Select the desired command and edit the parameters (channel, etc.) as needed. Click “Perform” to send the SCPI command.


- SCPI output: Displays the results of the SCPI commands. When a command is performed, the SCPI output box will show detailed results of both the command sent and the response received.
- Open SCPI programming manual: Click “SCPI” to access the SCPI programming manual for this oscilloscope.
- Clear: Click to clear the contents of the SCPI output box.

The screenshot shows the 'SCPI Command' interface of the UNI-T web system. At the top, there is a navigation bar with the UNI-T logo and several menu items: Home, SCPI Command (which is highlighted), Instrument Control, Password Set, LAN Config, Service & Support, and Help. A 'Sign Out' button is located in the top right corner. Below the navigation bar, the main content area is titled 'SCPI Command'. It features an 'Input' text field for entering commands. Below the input field are two buttons: 'Execute' and 'Open SCPI Reference Manual'. Underneath these buttons is a large 'Output' text area for displaying the results of the commands. At the bottom of the output area is a 'Clear' button.

22.6. Instrument Control

On the Web System Instrument Control page, the user can operate the functions of the oscilloscope using a touch screen or a mouse. All operations can be completed using the mouse within the webpage, such as:













- Waveform manipulation: Click and drag the waveform to move it vertically and horizontally. The user can also adjust the trigger level position and reposition pop-up boxes by dragging.
- Webpage: On the webpage, the user can use the mouse wheel to interact with the knobs or click them to adjust the waveform's horizontal and vertical positions, modify the time base scale, change the volts-per-division scale, perform coarse and fine tuning, and set the trigger level position, among other functions.
- Menu interactions: Mouse clicks on the screen can open and close drop-down menus, pop-up boxes, and switch between menu options.
- Input keyboard: Double-click on the screen to open the numeric keypad, alphabetical keypad, or other input options.





(1) Key Area

- Menu: Click the "Menu" key to open the auxiliary menu dialog box.
- Auto: Click the "Auto" key to perform the Autoset operation.
- Run/Stop: Click the "Run/Stop" key to change the oscilloscope's operating state.
- Reset: Click to restore the settings to factory defaults.

(2) Rotary Knob


- Multi-function Knob: Supports multi-functional operations through a dialog box. Clicking the buttons  ,  on either side of the knob to modify the numeric values. Clicking the buttons  ,  at the bottom switches the numeric digits. When certain input fields have a default reset option available, clicking the knob can restore them to their default settings, such as the decoder line position.
- Horizontal-Position: Clicking the buttons  ,  on either side of the knob or scrolling the rotary knob moves the waveform's horizontal position. Clicking the knob sets the horizontal position to center.
- Horizontal-Scale: Clicking the buttons  ,  on either side of the knob or scrolling the rotary knob moves the waveform's time base. Clicking the knob switch the fine tuning or coarse tuning.
- Vertical-Position: Clicking the buttons  ,  on either side of the knob or scrolling the rotary knob moves the waveform's vertical position. Clicking the knob switches between fine tuning and coarse tuning.
- Vertical-Scale: Clicking the buttons  ,  on either side of the knob or scrolling the rotary knob moves the waveform's volts/div scale. Clicking the knob switches between fine

tuning and coarse tuning.

- **Trigger-Position:** Clicking the buttons  ,  on either side of the knob or scrolling the rotary knob moves the waveform's trigger position. Clicking the knob sets the level to center.

(3) Configuration

Click on “Configuration” to open the save configuration window, where the user can save trigger or waveform settings, set up video recording, and print screenshots.



① Save Waveform

Save the screen waveform in .dat and .csv formats. Once the saving is complete, download the files to a local PC. The downloaded .dat and .csv files are compatible with waveform analysis software on the host computer.

- Save mode:** Set the save mode for waveform saving and video recording. Screen waveform and deep memory waveform can be set.
 - **Screen waveform:** Saves or records only the waveforms displayed in the oscilloscope screen area, with the saved file format being .dat.
 - **Deep memory waveform:** Saves or records all data based on the oscilloscope's set memory depth, which includes waveforms outside the visible screen. The saved file format is .csv.
- Channel selection:** Select the channel for waveform saving. The available options are CH1, CH2, CH3, CH4, and ALL (only for screen waveforms). If the channel is not enabled, its data cannot be saved.
- Save method:** Select the method to single save or continuous trigger for saving waveforms. Both methods can be selected.
 - **Single save:** Saves only the .dat data from a single trigger of the selected channel.

- Continuous trigger: Builds upon the single save by performing a Single operation and then saving the waveform data after detecting a STOP state. This process continues in a loop.
- d. Recording operation: Click on the "Save Waveform" key to start saving the screen ".dat" file. During the saving process, click "Stop Saving" to cease the operation, which will automatically download the ".dat" file to local storage.
Note: During deep storage saving, if you click "Stop Saving", the incomplete file will not be saved or downloaded.
- e. Number of saved files: Displays the number of files that have been saved and downloaded to local storage during this operation.

② Video Recording

Clicking "Screen Recording" allows you to record the current instrument interface on the web. During the recording, clicking "Stop Recording" will end the recording process. Once the recording stops, a video in .mp4 format will be generated, displaying the recording duration. After completion, the video will be automatically downloaded to local storage.

- a. Save mode: Select the mode to normal recording or trigger recording for recording the video.
 - Normal recording: This records the operations on the oscilloscope screen, directly generating a video in .mp4 format without changing the oscilloscope's state.
 - Trigger recording: This captures the current triggered screen, saves it as an image, and downloads it to local storage while adding it to the video data. It automatically sends the :KEY:Single command and checks for the STOP status; if the status is true, the current triggered screen is saved as an image and added to the video data. This process repeats until the amount of video data is greater than or equal to the specified segment size, after which it saves and continues accumulating the next segment of video data.
- b. Segment size: Choose the size of the recorded video. When the recorded data exceeds the specified size, the recording will automatically stop and download the video, after which it will automatically start recording the next video. The video size can be set to 5M, 20M, 100M, or 500M.
- c. Recording operation: Click the "Start Recording" button to begin saving video data according to the selected save method. During the recording, clicking "Stop Recording" will stop the recording and directly save the current video data from memory as a video file, which will be downloaded to local storage.
- d. Number of files saved: Displays the number of files that have been saved and

downloaded to local storage during the current operation.

③ PrintScr

Click on the "PrintScr" key to save the oscilloscope screen as a .png file. Click "Download Image" to download the image to local storage.

22.7. Network Setting

Network configuration allows users to set the oscilloscope's network details, including LAN settings and external network proxy configurations.

a. Oscilloscope Network Information Settings

Item	Value
IP	192.168.20.220
Mask	255.255.254.0
Gateway	192.168.20.1

Click the "Modify Oscilloscope Configuration" key to set the oscilloscope's local network information. The network settings include the IP address acquisition method (DHCP/STATIC), local IP address, subnet mask, and gateway settings.

- DHCP: If you select DHCP as the IP setting method, there is no need to enter the IP address, subnet mask, or gateway information. Simply click "Confirm", and the oscilloscope will automatically obtain the IP address.
- STATIC: If you choose STATIC as the IP setting method, you must enter the correct IP address, subnet mask, and gateway information before clicking "Confirm".

After modifying the oscilloscope's network configuration, the user can access it using the new IP address information (provided the configuration is correct).

b. FRP Agent Network Information Settings

Item	Value
Frp IP	121.37.220.55
Web Port	9005
Pic Port	9007
Ctrl Port	9006

- Modify FRP Proxy Configuration: This option allows you to set the current oscilloscope's

FRP proxy information, including the FRP proxy server IP address, port, picture port, and control port.

- **Get FRP Used Ports:** This feature displays the ports currently in use by the specified proxy IP. When configuring proxy ports, ensure that you avoid using these occupied ports.

Frp Port Usage ×

TCP	9000	online
TCP	9001	online
TCP	9002	online
TCP	9005	online
TCP	9006	online
TCP	9007	online
TCP	9605	online

After entering the information, click OK to update the IP and port settings of the oscilloscope's Frp synchronously. Once the oscilloscope's Frp is open, you can modify the IP address and continue accessing it (assuming the configuration is correct).

Note: If each oscilloscope is connected to the same FRP server, the web_port, pic_port, and ctrl_port for each oscilloscope must be unique. Otherwise, the FRP proxy will fail, resulting in inaccessible connections.

After modifying the FRP proxy settings, access via LAN using ip:9000 may not work. To restore normal LAN access, press the **Default** key on the oscilloscope panel to reset the configuration information. After resetting, you will be able to access the oscilloscope using port 9000 again.

22.8. Password Setting

The password setting allows users to configure their login credentials. After logging into the web system for the first time, users can create a customized password based on their serial number encoded in Base64. Once the password is set, users can log in with the new password in subsequent sessions.

If you forget your password and need to reset it, press the **Default** key on the oscilloscope panel.

Note: After resetting the oscilloscope to its default settings, you will need to log in to the web system again using the serial number encoded in Base64.

Modify Password

Item	Value
Old Password	<input type="password"/>
New Password	<input type="password"/>
Confirm New Password	<input type="password"/>

Confirm

Cancel

22.9. Help

Click on the Help page to enter the Web usage help page, which provides basic instructions for each tab of the oscilloscope Web access.

22.10. Service and Support





Click on the Service and Support page to be directed to the UNI-T official website of <https://www.uni-trend.com/>.


23. Mathematical Operation

- [Basic Operation](#)
- [Digital Filter](#)
- [Advanced Operation](#)

MSO5000HD series high-resolution oscilloscope carries a variety of mathematical operations, including Math, digital filter and advanced operation.

The “Math” menu can be entered using the following steps.

- Press the **Math** key on the front panel to enter the math setting menu.
- Click the Home icon  at the top-right of the screen and select the math icon  to enter the math setting menu.
- If the math function is added to the toolbar, click the math icon  in the toolbar at the top-right of the screen to enter the math setting menu.
- When M1-M4 is opened, click on the M1-M4 label at the bottom of screen, or click the icon  at the top-right of the screen to enter the math setting menu.




This oscilloscope supports 4 mathematical operations: Math1, Math2, Math3, and Math4, and supports the result of Math wave displayed in a separate window, and the label and channel color can be set. In the Math menu, press M1-M4 to select and set. In this chapter, Math1 is used as an



example to introduce the math function.

(1) Operation

In the Math menu, click on the “Operation” to switch on/off the operation result of Math wave. The default is “OFF”. Once M1-M4 is set to “ON”, the operation result of Math wave will be displayed on the screen, as shown in the following figure.



(2) Separate Window

The operation result of Math wave can be displayed in a separate window. Click on , 4 Math waves and the channel wave are displayed in a separate window. Click on , 4 Math waves and the channel wave are displayed in the same window.

When the operation result of Math wave is displayed in a separate window, drag the label bar above the window to change the window position, or click on the icon “x” on top right corner to close the window.

(3) Label

Set the wave label for the Math wave operation result display window, see the section of [6.10 Label](#) for setting.


(4) Channel Color

Set the color for Math channel and Ref waveform and its label.

- Source: Click on the “Source” to select the source to set the color, the source can select M1, M2, M3, M4, R1, R2, R3, or R4.
- Color: Tap the color plate and drag to select the color.

23.1. Basic Operation


In the Math menu, click on the “Math type” to select “Basic operation” to enter the setting.



(1) Operation

- **A+B:** The waveform of source A and waveform of source B are added point by point and the results are displayed.
- **A-B:** The waveform of source A and waveform of source B are subtracted point by point and the results are displayed.
- **A×B:** The waveform of source A and waveform of source B are multiplied point by point and the results are displayed.
- **A÷B:** The waveform of source A and waveform of source B are divided point by point and the results are displayed. It is used to analyze the multiple relation between two channel waveforms.

Note: When the voltage of source B is 0, the divide result is 0.





(2) Source

Click on the “Source A” or “Source B” to select C1 - C4 separately.



(3) Vertical Scale

Set the vertical scale of Math wave in the display window, it can be set using the following steps.

- In “Math” menu, click on the “Vertical Scale” input field, rotate the Multipurpose A rotary knob on the front panel to change the vertical scale.
- Tap the vertical scale icon ,  on the right to increase or decrease the vertical scale.
- Double-click on “Vertical Scale” input field to open the numeric keypad to enter the specified numeric value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).


(4) Vertical Position

Set the vertical offset of Math wave in the display window, it can be set using the following steps.

- In “Math” menu, click on the “Vertical Position” input field, rotate the Multipurpose A rotary knob on the front panel to change the vertical position.
- Tap the vertical position icon ,  on the right to increase or decrease the vertical scale.
- Double-click on “Vertical Position” input field to open the numeric keypad to enter the specified numeric value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

23.2. Digital Filter

In the “Math” menu, click on the “Math type” to select “Filter” to enter the setting.



(1) Source

Click on the “Source” to select C1 - C4.

(2) Filter Type

- Low pass: Only signals with the source frequency lower than the upper limit of the current frequency are allowed to pass.
- High pass: Only signals with the frequency higher than the lower limit of the current frequency are allowed to pass.
- Band pass: Only signal with the frequency higher than the lower limit of current frequency and lower than upper limit of the current frequency is allowed to pass.
- Band Limited: Only signal with the frequency lower than the lower limit of the current frequency or higher than the upper limit of the current frequency is allowed to pass.

(3) Lower Limit of Frequency

Click on the “Lower Limit of Frequency” input field, and rotate the Multipurpose A rotary knob on the front panel to change the lower limit of frequency; or double-click on “Lower Limit of Frequency” input field to open the numeric keypad to directly enter the lower limit of frequency. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). In low-pass mode, the lower frequency limit setting is invalid, and the menu is hidden.



(4) Upper Limit of Frequency

Click on the “Upper Limit of Frequency” input field, and rotate the Multipurpose A rotary knob on the front panel to change the upper limit of frequency; or double-click on “Upper Limit of Frequency” input field to open the numeric keypad to directly enter the upper limit of frequency. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). In high-pass mode, the upper frequency limit setting is invalid, and the menu is hidden.

Note: The range of upper/lower limit of frequency is related to the current horizontal time base.



(5) Vertical Scale

Set the vertical scale of Math wave in the operation result display window, it can be set using the following steps.

- In “Math” menu, click on the “Vertical Scale” input field, rotate the Multipurpose A rotary knob on the front panel to change the vertical scale.
- Tap the vertical scale icon ,  on the right to increase or decrease the vertical scale.
- Double-click on “Vertical Scale” input field to open the numeric keypad to enter the specified numeric value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).


(6) Vertical Position

Set the vertical offset of Math wave in the operation result display window, it can be set using the following steps.

- In “Math” menu, click on the “Vertical Position” input field, rotate the Multipurpose A rotary knob on the front panel to change the vertical position.
- Tap the vertical scale icon ,  on the right to increase or decrease the vertical position.
- Double-click on “Vertical Position” input field to open the numeric keypad to enter the specified numeric value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).


23.3. Advanced Operation

In the “Math” menu, click on the “Math type” to select “Advanced” to enter the setting. Advanced operations allow the user to freely define the relevant operations for each signal input channel to obtain Math waveforms with different operation results.



(1) Expression

Double-click on “Expression” input field or click the “Edit” on the right to enter the setting. The function operation can be edited in the expression window, as shown in the following figure.



(2) Edit Expression

- a. Expression: It represents the formula consisting of channel, function, variation, and operator. The length of expression cannot be over 13 characters.
- b. Channel: C1 - C4, M1 - M4
- c. Function options: The functional description of each function option is shown in the following table.



Function Name	Description
Sin	Calculating the sine of the selected source.
Cos	Calculating the cosine of the selected source.
Sinc	Calculating the normalization value of the selected source.
Tan	Calculating the tangent of the selected source.
abs	The selected source takes the absolute value (integer absolute value).
fabs	The selected source takes the absolute value (floating number absolute value).
exp	Calculating the exponent of the selected source.
Lg	Calculating the logarithm of the selected source.
ln	Calculating the logarithm of the selected source.
floor	The selected source is round down to an integer.
ceil	The selected source is round up to an integer.
sinh	Calculating the hyperbolic sine of the selected source.
cosh	Calculating the hyperbolic cosine of the selected source.
tanh	Calculating the hyperbolic tangent of the selected source.
Sinc	Calculating the normalization value of the selected source.
acos	Calculating the arccosine of the selected source.
asin	Calculating the arcsine of the selected source.
atan	Calculating the inverse tangent of the selected source.
intg	Calculating the integral of the selected source.
diff	Calculating the differential of the selected source.
sign	Calculate the polarity of the selected source.

- d. Operator: The functional description of each operator is shown in the following table.

Operator	Description
+ - * / ^	Mathematical operator: add, subtract, multiply, divide, exponent
()	Parentheses are used to raise the priority of operations in parentheses.
< > == !=	Relation operator: greater than, less than, equal to, unequal to
, &&	Logical operator: or, and
0-9	Perform digit operation



(3) Vertical Scale

Set the vertical scale of Math wave in the operation result display window, it can be set using the following steps.

- In “Math” menu, click on the “Vertical Scale” input field, rotate the Multipurpose A rotary knob on the front panel to change the vertical scale.
- Tap the vertical scale icon ,  on the right to increase or decrease the vertical scale.
- Double-click on “Vertical Scale” input field to open the numeric keypad to enter the specified numeric value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

(4) Vertical Position

Set the vertical offset of Math wave in the operation result display window, it can be set using the following steps.

- In “Math” menu, click on the “Vertical Position” input field, rotate the Multipurpose A rotary knob on the front panel to change the vertical position.
- Tap the vertical scale icon ,  on the right to increase or decrease the vertical position.
- Double-click on the “Vertical Position” input field to open the numeric keypad to enter the specified numeric value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

(5) Unit

Set the result unit of mathematical advanced operations. Double-click on the “Unit” input field to open the numeric keypad to enter the specified numeric value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

(6) Operation Area

Advanced math operations can be performed within the specified threshold area, with settings available for the screen or cursor area.





- Screen: Perform operations on the entire screen area.
- Cursor area: Set the threshold by moving Cursor AX and Cursor BX, and perform operations within the defined area. The threshold cursor setup is similar to that of a standard cursor; please refer to the [Time Measurement](#) section for details.

24. FFT

Using FFT (Fast Fourier Transform) mathematical operations, the time domain signal (YT) can be converted into frequency domain signal. This oscilloscope has an FFT function. This allows the user to view the frequency spectrum of the signal while viewing the waveform in the time domain. The following types of signals can be easily observed by using FFT.


- Harmonic component and distortion in measurement system
- Perform the noise feature in DC power supply
- Vibration analysis

FFT menu can be entered using the following steps.

- Click the Home icon  at the top-right of the screen and select the FFT icon  to open the FFT function.
- If the FFT function is added to the toolbar, click the FFT icon  in the toolbar at the top-right of the screen to open the FFT function.
- When FFT1-FFT4 is opened, click on the FFT1-FFT4 label at the bottom of the screen, click on the icon  at the top-right of the screen to open the FFT function.


The oscilloscope supports four FFT operations: FFT1, FFT2, FFT3, and FFT4, and the operation results are displayed in an independent window. In the "Math FFT" menu, press FFT1-FFT4 to select and set. In this chapter, FFT1 is used as an example to introduce the FFT function.

FFT setting menu has two submenus, "Normal" and "Trace". Click on the "Normal" or "Trace" to set or slide the menu to select and set.



(1) Operation

Click on the "Operation" to open the FFT operation window.



(2) Autoset

Click on the "Autoset" key to automatically adjust the vertical range and position, ensuring the FFT waveform is displayed in the center of the screen.

(3) Source

Click on the "Source" to select C1 - C4.

(4) FFT Count

The number of points processed by the FFT spectrum, it can be set to 8 k, 16 k, 32 k, 64 k, 128 k, 256 k, 512 k, 1 M, 2 M, or 4 M.

(5) Frequency Mode

a. Range

- Start frequency: Click the "Start Frequency" input field on the left of the window to open the numeric keypad to set the start frequency; or select the "Start Frequency" and rotate the Multipurpose A rotary knob to set the start frequency, turn clockwise to increase and anticlockwise to decrease.
- Stop frequency: Click the "Stop Frequency" input field on the right of the window to open the numeric keypad to set the stop frequency. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the "Stop Frequency" input field, use the Multipurpose A to adjust the stop frequency, turn clockwise to increase and anticlockwise to decrease.

b. Bandwidth

- Center frequency: The frequency is corresponding to the center of window. Click the "Center Frequency" input field on the right of the window to open the numeric keypad to set the center frequency. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the "Center Frequency" input field, use the Multipurpose A to adjust the center frequency, turn clockwise to increase and anticlockwise to decrease. The center frequency range can be set from 0 Hz to bandwidth $\div 2$.
- Bandwidth: The frequency range of frequency domain waveform, set the bandwidth for FFT sweep. Click the "Bandwidth" input field on the right of the window to open the numeric keypad to set the bandwidth. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the "Bandwidth" input field, use the Multipurpose A to adjust the bandwidth, turn clockwise to increase and anticlockwise to decrease. The center frequency range can be set from 0 Hz to 2.5 GHz.

(6) Vertical Unit

FFT operation result unit can be set to Vrms or dB. Vrms and dBm display the vertical amplitude size in linear and decibel volts respectively. If the FFT spectrum needs to be displayed in a large dynamic range, dBm is recommended.

(7) Window Function



The window function is used to reduce the problem of spectral leakage. This oscilloscope provides 4 FFT window functions, each window function is for different waveforms, as shown in the following table, and the selection is based on the measured waveform and its features.

Window Function Table

Window function	Feature	Waveform
Rectangle	It has the best frequency resolution and the worst amplitude resolution, which is like the one with no window.	Transient or short pulse, the signal level is almost equal to before and after Equal amplitude sine wave with very similar frequency Wide-band random noise in a slowly changing spectrum
Hanning	Compared with the rectangle window, it has better frequency resolution, but poorer amplitude resolution.	Sine wave, period and narrow-band random noise
Hamming	The frequency resolution is slightly better than that of Hanning window.	Transient or short pulse, the signal level is very different before and after
Blackman	It has the best amplitude resolution, and the worst frequency resolution.	Single frequency signal, seeking for higher harmonic



(8) Vertical Scale

Set the vertical scale of FFT wave in the display window, it can be set using the following steps

- In “Math” menu, click on the “Vertical Scale” input field, rotate the Multipurpose A rotary knob on the front panel to change the vertical scale.
- Tap the vertical scale icon ,  on the right to increase or decrease the vertical scale.
- Double-click on the “Vertical Scale” input field to open the numeric keypad to enter the specified numeric value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

(9) Vertical Position

Set the vertical offset of FFT wave in the display window, it can be set using the following steps.

- In “Math” menu, click on the “Vertical Position” input field, rotate the Multipurpose A rotary knob on the front panel to change the vertical position.
- Tap the vertical position icon ,  on the right to increase or decrease the vertical

scale.

- Double-click on the “Vertical Position” input field to open the numeric keypad to enter the specified numeric value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

(10) Waterfall Curve

Click on the “Waterfall Curve” to switch on/off whether the waterfall curve is opened in FFT wave.

- ON: The spectrum and waterfall curve are split to upper and lower part for display, the waterfall curve reflects the change in dB value over time in the spectrum and has record function. The waterfall plot can only be selected when the Enhanced FFT is enabled. The record is up to 200 (the spectrum with respect to the waterfall curve).
- OFF: Displays FFT wave and its coordinates.



(11) Segment Selection

After opening the waterfall chart, the “Segment selection” can be configured while the oscilloscope is in the STOP state. By adjusting the segment selection, the spectrum waveform corresponding to a specific time point on the waterfall diagram can be viewed. Click on the “Segment selection” input field, use the Multipurpose A rotary knob on the front panel to adjust the segment selection. Alternatively, double-click on the “Segment selection” input box to open the numeric keypad to enter the specified numeric value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). The setting range is from 1 to 300.

(12) Trace

In FFT setting menu, click on the “Trace” or slide the menu to left and right to enter the trace setting menu. The trace is used to display the graph of the points drawn on the raw data after the FFT operation.

a. Trace

- Normal: The spectrum waveform graph shows all the sampled values in real time, the spectrum waveform displays in red.
- Average: The spectrum waveform graph shows the average value of several points taken during the sampling interval; the spectrum waveform displays in blue.
 - Average time: Set the number of average calculation, double-click on the “Average time” input field to open the numeric keypad to set the average time. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the average time. The setting range is from 2 to 8192. The greater the number, the smoother the average spectrum.
- Maximum hold: The spectrum waveform graph shows the maximum value of the data from multiple samples, and the spectrum waveform display in yellow.
- Minimum hold: The spectrum waveform graph shows the minimum value of the data from multiple samples, and the spectrum waveform display in grey.

b. Sampling Mode

- OFF: Turn off the current detection waveform.
- + Peak: It takes and displays the maximum value in each sample interval.
- - Peak: It takes and displays the minimum value in each sample interval.
- Average: It takes and displays the average value in each sample interval.
- Sampling: It takes and displays the first value in each sample interval.

(13) Marker

The spectrum marker is used to mark the point in the spectrum and display the frequency and voltage.

a. Auto

- Mark trace: Select the spectrum waveform as the marker source, i.e. the spectrum waveform generated by different types of detector mode. Click on the “Mark trace” to select normal, average, maximum hold, or minimum hold.
- Marker count: Set the maximum number of points that can be marked, double-click on the “Marker count” input field to open the numeric keypad to set the marker count. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob adjust the

marker count. The setting range is from 1 to 10.

- Marker list: Click on the “Marker list” to switch on/off the marker list.

ON: Displays the marker list, count number, frequency, and voltage.

OFF: Not display the marker list.

b. Threshold

- Marker trace: Select the spectrum waveform as the marker source, i.e. the spectrum waveform generated by different types of detector mode. Click on the “Marker trace” to select normal, average, maximum hold, or minimum hold.

- Marker count: Set the maximum marker count. Double-click on the “Marker Count” input field to open the numeric keypad to set the marker count. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob adjust the marker count. The setting range is from 1 to 10.

- Marker threshold: Set the compare condition, the marker will be displayed when the peak is greater than the set threshold; otherwise, the marker will not be displayed. Double-click on the “Marker threshold” input field to open the numeric keypad to set the marker threshold. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob adjust the marker threshold.

Marker list: Click on the “Marker list” to switch on/off the marker list.

ON: Displays the marker list, count number, frequency, and voltage.

OFF: Not display the marker list.

c. Manual: Move the marker cursor to any point on the trace by rotating the Multipurpose A rotary knob.

- Marker trace: Select the spectrum waveform as the marker source, i.e. the spectrum waveform generated by different types of detector mode. Click on the “Marker trace” to select normal, average, maximum hold, or minimum hold.

- Peak: Click on the “Peak” to automatically place the marker cursor line at the peak value of the trace.

Note: If the selected marker trace is not displayed, there is no marker point, and the trace can be marked until the trace is displayed.

25. Digital Channel


- [Basic](#)
- [Group](#)
- [Threshold](#)
- [Bus](#)
- [Label](#)

MSO5000HD series has 4 analog channels and 16 digital channels. For digital channel, the oscilloscope will compare the sampled voltage of each time to the preset logical threshold. If the voltage of sampling point is greater than threshold, it will save as logic 1. Otherwise, it will save as logic 0. The oscilloscope can intuitively display logic 1 and logic 0 in figure. It's convenient for users to detect and analysis the error in circuit design (hardware and software design).

This chapter introduces how to use the digital channel of MSO5000HD series high-resolution oscilloscopes.


Before using the digital channel, use the accessory UT-M15 logical probe to connect to the oscilloscope and the device under test. For the use of logical probe, refer to <<UT-M15 Logical Probe User Manual>>.

The digital channel menu can be entered using the following steps.

- Press the Digital key on the front panel to enter the digital channel menu.
- Click the digital icon  at the bottom of the screen to enter the digital channel menu.

25.1. Basic



- (1) Display: Click on the “Display” to switch on/off the digital channel.
 ON: When the channel is selected, the digital channel will be displayed on the screen.
 OFF: The digital channel will not be displayed on the screen even if the channel is selected.
 - (2) Channel: Select a channel to be the current channel, and display it in blue to distinguish from other channels.
 - (3) Channel selection: D0 - D15 can be opened by pressing any one of channel. The selected channel is displayed in blur. When the display is opened, the selected channel will be displayed on the screen.
 - Select all: Quick select all the digital channels.
 - Delete: Quick delete the state of all the digital channels.
 - (4) Click on the “D15 - D8, D7 - D0” to quickly set the channel display state.
 ON: Select the digital channel of D15 - D8, D7 - D0.
 OFF: No digital channel is selected.
 - (5) Open/close group: the selected group is displayed in . If the group has a digital channel, the digital channel will be displayed on the screen (refer to Group for more details).
 - (6) Waveform size: Click on the “Waveform size” to set the waveform size to display in S (small), M (middle), or L (large). The default is S.
- Note:** L (large) can only be used when the open channel is not more than 8.
- (7) Waveform rank: Click on the “Waveform rank” to set the digital channel sequence, from up to

down. it can be set to “D0 - D15” or “D15-D0” . The default is “D0 - D15”.

- (8) Delay time: When using an oscilloscope for actual measurements, the transmission delay of the probe cable can introduce a large error (zero offset).

Zero offset is defined as the offset of the intersection of the waveform and trigger level line from the trigger position.

Double-click on the “Delay Time” input field to open the numeric keypad to set the delay time.


For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

Alternatively, select the parameter, use the Multipurpose A to change the delay time. The range can be set from -100 ns to 100 ns.

25.2. Group

The group setting can group or ungroup any of the 16 digital channels into 4 groups, a channel can be added to more than one group, and the background of the channel added to the current group is displayed in blue.

- (1) Group: Click on the “Group” to select group 1, group 2, group 3, or group 4
- (2) Select all: Add D0 - D15 to the current group. And all the digital channels are displayed in blue.
- (3) Reset: Reset the digital channel in the current group to the default 4 digital channels.
- (4) Clear: Clear all the digital channels in the current group.




25.3. Threshold

The threshold levels for the "D7 - D0" and "D15 - D8" channels can be set independently, and the thresholds for CH1 and CH2 can also be configured independently as needed. If the input signal voltage exceeds the set threshold, it is recognized as logic 1; otherwise, it is recognized as logic 0. Click on the "D7 - D0 Threshold" or "D15 - D8 Threshold" to select the preset or custom value.

- (1) Preset threshold: TTL (1.4 V), CMOS5.0 (2.5 V), CMOS3.3 (1.65 V), CMOS2.5 (1.25 V), CMOS1.8 (0.9 V), ECL (-1.3 V), PECL (3.7 V), CLDS (1.2 V), and 0 V. Once the threshold is selected, it will apply to the group.
- (2) Custom: Click on the "Custom" to open the numeric keypad to set the custom threshold. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, rotate the Multipurpose B rotary knob to select the cursor, and then rotate the Multipurpose A rotary knob to adjust the threshold. Turn the knob clockwise to increase the value and turn it anticlockwise to decrease the value. The range can be set from -20.0 V to +20.0 V.
- (3) Set the threshold for CH1 and CH2: Double click on the "CH1 Threshold / CH2 Threshold" input field to open the numeric keypad to set the delay time. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to change the threshold. CH1 and CH2 thresholds are related to their volt/div.

25.4. Bus

Digital channels can be combined and displayed as bus, with each bus value displayed at the bottom of the screen as binary, decimal, hexadecimal, ASCII. The figure is displayed at the bottom of the screen. Up to two buses can be created.




- (1) Bus: Click on the “Bus” to select the bus, “BUS1” or “BUS2”.
- (2) Bus state: Click on the “Bus state” to switch on/off the bus display state.
- (3) Quick selection: Click on the “Quick Selection” to select the channel group which correspond to BUS1 or BUS2, it can be select to D0-D7, D8-D15 , D0 - D15, group 1, group 2, group 3, group 4, or None.
- (4) Bit selection: Manually select the channel bit that corresponds to the bus, it can be select to D0 - D15, CH1, CH2, the selected digital channel is displayed in blue.
- (5) Bit sequence: Click on the “Bit Sequence” to select “LSB (low to high)” (D0 is at the low bit) or “MSB (high to low)” (D0 is at the high bit).
- (6) Clock: Click on the “Clock” to select any one of channel (D0 - D15, CH1, CH2) to the reference clock for bus. The reference clock will not be set if “Null” is selected.
- (7) Edge type: Click on the “Edge type” to select “Rising/falling edge”. The edge type of the currently selected channel can be the reference, to judge other channel is logic 1 or logic 0.
- (8) Display type: Click on the “Display Type” to set the bus format to binary, decimal, hexadecimal, or ASCII. The oscilloscope will display the bus data as the level of the corresponding value in a specific way in the graphics mode, making it easy to observe the trend of the bus value, as shown in the following figure.
- (9) Jitter proof: Click on the “Jitter Proof” to switch on/off the jitter proof function.
 Jitter: It indicates the short-term deviation of a signal at a particular moment relative to its ideal time position. If the bus does not select the reference clock, the hopping state of each channel

will cause the change of the bus data. When bus data changes, unnecessary data will occur due to the shaking. When shake proof is opened, the bus will not display the change in bus data caused by a certain shake time, but still maintain the valid data.

- (10) Jitter time: Double-click on “Jitter Time” input field to open the numeric keypad to set the jitter time. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to change the delay time. The range can be set from 0 ns to 50 μ s.

Note: Jitter proof and Jitter time can only be set when data bus has no reference clock.



25.5. Label

Label setting is used to set the label for the specified digital channel.

(1) Preset Label

Select a digital channel (D0-D7, D8-D15) and then select a preset label for it.

Preset label: ACK, AD0, ADDR, BIT, CAS, CLK, CS, DATA, HALT, INT, LOAD, NIMI, OUT, RAS, PIN, RDY, RST, RX, TX, WR, MISO, and MOSI.

(2) Custom Label

Select a digital channel (D0-D7, D8-D15) and then set a custom label for it.

Double-click on the “Label” input field to open the numeric keypad to set the custom label. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

(3) Clear label

Click on the “Clear” key to remove all labels set for the digital channels.

(4) Add

Click on the “Add” key to add custom labels that will display after the preset labels. The added labels can remain visible, with a maximum of 10 labels allowed. If you perform a default operation or click the "Restore Defaults" button, the added labels will be removed.

(5) Reset

Click on the “Reset” key to delete the added labels.




26. Timing Analysis

Timing analysis is a technique used to verify whether a circuit or system operates as expected under a specific clock signal. It involves analyzing factors such as signal propagation delay, clock frequency, and timing-critical paths to ensure the circuit or system meets timing requirements and functions stably and reliably under various operating conditions. Timing analysis can be performed during both the design phase and the bus validation phase.

During the design phase, timing analysis mainly focuses on identifying critical paths in sequential circuits. Static timing analysis tools, such as PrimeTime and Design Compiler, are commonly used to detect these paths and perform optimizations to ensure the timing constraints are met.

During the bus phase, timing analysis involves using tools like logic analyzers, oscilloscopes, and protocol analyzers to capture bus signal waveforms and analyze timing characteristics. The timing analysis function of an oscilloscope typically measures key signal timing parameters based on decoded data, including input voltage, clock frequency, rise and fall times, high and low level durations, data setup time, and hold time.

The "Timing Analysis" menu can be entered using the following steps.

- If the timing analysis is added to the toolbar, click the timing analysis icon  in the toolbar at the top-right of the screen to enter the timing analysis menu.
- Press the Analyze key on the front panel and click the timing analysis to enter the timing analysis menu.
- Click the Home icon  at the top-right of the screen and select the timing analysis icon  to enter the timing analysis menu.

26.1. General Setting

(1) Analysis

Click on the "Analysis" to turn the timing analysis on or off. When timing analysis is enabled and decoding is not already active, the decoding type and corresponding decoding bus for BUS1 will be automatically configured and enabled.

(2) Pause

When analysis is active, statistical analysis starts automatically. Press the "Pause" button to temporarily stop the analysis, and click "Continue" to resume.

(3) Reset

Click on the "Reset" to clear all current statistical test results. This action does not affect the ongoing analysis process.

(4) Protocol Type

Click the pull-down list under "Protocol Type" and select I2C, SPI, or CAN. Each protocol requires specific configuration of related parameters.

(5) Stop Condition

For long-term stability testing of some devices, the statistical function can be used to monitor many bus frames (e.g., 10,000 or more) to evaluate reliability over time.

The timing analysis will stop automatically once the selected stop condition is met. Click the pull-down list under "Stop Condition" and set the condition for stopping the analysis.

- None: The analysis runs continuously and must be stopped manually.
- Number of failures: The analysis stops once the number of failures reaches the specified limit.
- Total number: The analysis stops when the total number of actual runs reaches the set total number.

(6) Number of Failures

When the stop condition is set to number of failures, the number of failures can be customized. Double-click on the "Failure Number" input field to open the numeric keypad to set the number of failures. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to change the number of failures. The range can be set from 1 to 100,000,00.

(7) Total Number

When the stop condition is set to total number, the total count can be customized. Double-click on the "Total Number" input field to open the numeric keypad to set the total number. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A to change the total number. The range can be set from 1 to 100,000,00.

(8) Decoding Menu

Click on the "Decoding" to directly jump to the decoding menu.

(9) Copy Decoding Setting

After the decoding type and parameters have been configured, click on the "Copy Decoding" on the timing analysis page to copy the decoding parameter settings into the timing analysis menu.

(10) Result Table

Click the switch on the right side of the "Result Table" to turn the analysis result table ON or OFF.

(11) Save

Click on the "Save" to enter the export settings menu. Users can export the analysis data list

in .csv or .pdf format to internal memory or to an external USB flash drive (only when a USB drive is detected).

(12) Export Parameter

Click on the “Export Parameter” to enter the export parameter settings menu. Enter the desired file name and save path, then export the current parameter settings in .csv format to internal memory or a USB flash drive (only when a USB drive is detected). This enables convenient re-import of the settings later.

(13) Import Parameter

Click the “Import Parameter” to enter the import parameter settings menu. Double-click on the “File Path” field to select the appropriate parameter file (.csv) from internal memory or a USB flash drive (only when a USB drive is detected) to import and apply the settings.

(14) Default

Click on the “Default” to restore all parameter configuration values to their default settings.

26.2. I2C Timing Analysis

I²C timing analysis relies on I²C decoding. Therefore, I²C decoding must be configured before performing I²C timing analysis. For detailed instructions, refer to the [I²C Decoding](#) section.

26.3. Analysis Setting

(1) SCL Source

Click the pull-down list under “SCL Source” to select C1 - C4 as the I²C clock source.

(2) SDA Source

Click the pull-down list under “SDA Source” to select C1 - C4 as the I²C data source.

(3) Transmission Rate

Click on the pull-down list under “Transmission Rate” to set the data rate of the I²C signal to standard, fast, or high speed. Changing the rate will adjust the corresponding parameter standards accordingly.

(4) Filtering Conditions

Click on the pull-down list under “Filtering Conditions” to configure the filtering condition for I²C data. This determines whether to analyze transmission frames based on fixed read/write addresses.

- None: No filtering; all data will be tested and analyzed.
- Address: Only data associated with the specified address will be analyzed.

- Address Read: Only read operations for the specified address will be analyzed.
- Address Write: Only write operations for the specified address will be analyzed.

(5) Address

Set the filtering address, double-click on the "Address" input field to open the numeric keypad to set the address. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the address. The data range can be set from 00 to 7F and from 000 to 3FF.

26.4. Parameter Setting

(1) Bus Level Setting

- Bus level: Set the bus level for timing analysis, which refers to the input voltage (V_{CC}) of the signal. Typically, the input voltage for I²C is 3.30 V. If the input voltage is 1.8 V or another value, it can be adjusted by using Knob A. Adjusting the bus level (V_{CC}) will affect the values of V_{IH} and V_{IL} . The relationship between V_{CC} , V_{IH} , and V_{IL} is shown in the table below.
- Input high-level/Low-level voltage (V_{IH} , V_{IL}): These input values are determined by V_{CC} and follow the relationship specified in the table. They can also be manually adjusted by using Knob A; however, modifying V_{IH} or V_{IL} will not affect the value of V_{CC} .
- Each of the remaining parameters has its own specific standard. Refer to the table below for standard parameter settings. If the user's standard differs from the one shown in the table, double-click the parameter input field to open the numeric keypad to enter a specific standard. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the standard value. Click the "Default" to restore the default settings.

Symbol	Name	Minimum	Maximum	Unit
V_{IH}	Input high-level voltage	$0.7 \times V_{CC}$	$V_{CC} + 0.5$	V
V_{IL}	Input low-level voltage	-0.5	$0.3 \times V_{CC}$	V

(2) I²C Bus AC, DC Characteristic Parameter Table

Symbol	Name	Standard Mode		Fast Mode		High Speed		Unit
		Minimum	Maximum	Minimum	Maximum	Minimum	Maximum	
Level	Bus level							
V_{IH}	Input	$0.7 \times$	$V_{CC} + 0.5$	$0.7 \times$	$V_{CC} + 0.5$	$0.7 \times$	$V_{CC} + 0.5$	V


	high-level voltage	Vcc		Vcc		Vcc		
VIL	Input low-level voltage	-0.5	0.3×Vcc	-0.5	0.3×Vcc	-0.5	0.3×Vcc	V
F _{SCL}	Clock frequency		100		400		3400	kHz
t _{HIGH}	Clock high-level time	4	-	0.6		0.06	-	μs
t _{LOW}	Clock low-level time	4.7	-	1.3		0.16	-	μs
t _R	Clock/data rise time	0	1000	20	300	10	40	ns
t _F	Clock/data fall time	0	300	20	300	10	40	ns
t _{SU.STA}	Start signal setup time	4.7	-	0.6		0.16	-	μs
t _{HD.STA}	Start signal hold time	4	-	0.6		0.16	-	μs
t _{SU.DAT}	Data signal setup time	250	-	100		10		ns
t _{HD.DAT}	Data signal hold time	0	3.45	0	0.9	0	0.07	μs
t _{SU.STO}	End signal setup time	4		0.6		0.16		μs
t _{BUF}	Bus idle time	4.7		1.3		0.1		μs
Freq Deviation	Frequency offset	This is an optional item for signal timing analysis and testing. It is not a standard definition, and users can customize the allowable test range based on the actual situation.						kHz
ThresholdH	High threshold	This is an optional item for signal timing analysis and testing. It is not a standard definition, and users can						V
ThresholdL	Low							

	threshold	customize the allowable test range based on the actual situation.	
Overshoot	Overshoot		
Monot	Monotonicity		


Note: All parameter values are referenced to the VIHmin (0.7Vcc) and the VILmax (0.3Vcc). If these parameters differ from those specified in the user manual, they can be manually adjusted.

(3) Signal Position

The specific signal positions corresponding to each I²C test item are shown below.



All time-related test items of I²C are based on VIHmin (0.7Vcc) and VILmax (0.3Vcc) levels, illustrated in the figure below.




Test Item: Reference Level

The calculation principles for voltage-related test items in I²C, VIH (high threshold) and VIL (low threshold) are illustrated in the figure below.

- VIH: The voltage measured from the flat top of the waveform to ground, representing the top value.

- VIL: The voltage measured from the flat bottom of the waveform to ground, representing the bottom value.



Calculation of Top and Bottom Value

(4) I²C Test Item Table

Signal Line	Test Item	Description
SCL	VIL.SCL	Low-level voltage of the SCL signal line. See Note 1.
	VIH.SCL	High-level voltage of the SCL signal line. See Note 1.
	Glitch.SCL	Glitch detection item for the SCL signal line. This parameter will be displayed only when glitches are detected; otherwise, it remains hidden. See Note 2.
	Over+.SCL	Positive overshoot test for the SCL signal line. If the measured overshoot voltage exceeds the preset threshold, the result will be marked as Fail. See Note 1.
	Over-.SCL	Negative overshoot test for the SCL signal line. If the measured undershoot voltage exceeds the preset threshold, the result will be marked as Fail. See Note 1.
	Monot.SCL	Monotonicity test for the SCL signal line. If the voltage exceeds the allowable limit, the result will be marked as Fail. See Note 2.
	Freq.SCL(First)	<p>Frequency measured during the first cycle of the SCL clock signal.</p> <p>Although standard specifications define maximum clock frequencies (Standard/Fast/High-speed: 100 kHz / 400 kHz / 3.4 MHz), practical applications may allow extended tolerances.</p> <p>This allowable error can be configured via the "Frequency Deviation" parameter.</p> <p>For example, if a deviation of 1 kHz is set under</p>

		Standard mode, a frequency less than 101 kHz will result in Pass. See Note 2.
	Freq.SCL(Average)	Weighted average frequency of the SCL clock signal. This value is computed by averaging most samples with consistent periods, excluding outliers. All other conditions are the same as Freq.SCL (First). See Note 2.
SCL	tR.SCL(MAX)	Maximum rise time (tR) of the SCL clock signal.
		The system automatically evaluates all rise-time samples of the clock signal displayed on the screen (based on the main time base) and selects the maximum value (i.e., the worst-case timing) as the result. See Note 2.
	tF.SCL(MAX)	Maximum fall time (tF) of the SCL clock signal. The measurement method is the same as for tR.SCL (MAX). See Note 2.
	tLOW(MIN)	Minimum low/high-level period of the SCL clock signal.
	tHIGH(MIN)	The system automatically analyzes all low-level or high-level period samples of the SCL signal within the current screen (main time base) and selects the minimum value (i.e., the worst-case timing) as the result. See Note 2.
SDA	Glitch.SDA	Glitch test for the SDA signal line. See Note 2.
	Over+.SDA	Positive/negative overshoot test for the SDA signal line.
	Over-.SDA	If the measured overshoot voltage exceeds the preset threshold, the software flags the result as Fail. See Note 1.

	tR.SDA(MAX)	Maximum rise time and fall time of the SDA data signal.
	tF.SDA(MAX)	During test, the system automatically analyzes all rise/fall time samples of the SDA signal within the current screen (main time base) and selects the maximum value (i.e., the worst-case timing) as the result. See Note 3.
	tSU.STA(MIN)	Setup time (tSU) of the start signal (tested only under restart conditions). The system automatically counts all setup-time samples for the start condition visible on the screen (main time base) and selects the minimum value (the waveform with the worst timing) as the measurement result. See Note 2.
	tHD.STA(MIN)	Hold time (tHD) of the start signal. The system automatically counts all hold-time samples for the start condition visible on the screen (main time base) and selects the minimum value (the waveform with the worst timing) as the measurement result. See Note 2.
	tSU.DAT(MIN)	Setup time of the data signal. The system automatically counts all data setup-time samples on the screen (main time base) and selects the minimum value (the waveform with the worst timing) as the measurement result. See Note 3.
	tHD.DAT(MIN)(MIN, MAX)	Hold time of the data signal. The system automatically counts all data hold-time samples on the screen (main time base) and selects both the minimum and maximum values as the measurement results. (There are upper-limit restrictions under certain

		<p>special conditions.)</p> <p>If the filtering function is enabled, only the samples that meet the filtering conditions will be counted.</p> <p>See Note 2.</p>
	tSU.STO(MIN)	<p>Setup time of the stop signal.</p> <p>The system automatically counts all setup-time samples for the stop condition on the screen (main time base) and selects the minimum value (the waveform with the worst timing) as the measurement result.</p> <p>The condition for tSU.STO is to continuously record the latest rise time of the SCL signal until the stop condition occurs.</p> <p>See Note 3.</p>
	tBUF(MIN)	<p>Bus idle time between the previous stop and the current start condition.</p> <p>The system automatically counts all bus idle-time samples on the screen (main time base) and selects the minimum value (the waveform with the worst timing) as the measurement result.</p> <p>If there is only one frame of data on the screen, the test condition for tBUF cannot be met. In this case, the idle time before the Start signal will be output as the test result. If this value meets the requirement, it will be displayed as Pass.</p> <p>It is recommended to have more than two frames of data on the screen for more accurate results.</p> <p>See Note 1.</p>

Note 1: Even if the filtering function is enabled, the measurement samples will still be processed based on the data from the entire screen (main time base) and are not affected by the filtering range.

Note 2: If the filtering function is enabled, the samples will be statistically analyzed with ADDR as the filtering condition, without distinguishing between R/W (whether reading or writing, only the samples corresponding to the address are considered).

Note 3: If the filtering function is enabled, the samples will be statistically analyzed with ADDR (including both reading and writing samples), ADDR+R (only considering the reading samples of the address), or ADDR+W (only considering the writing samples of the address) as the filtering conditions, with R/W distinguished.


(5) Signal Quality Items

Signal quality testing includes glitch, overshoot, and monotonicity detection.

■ SCL Signal Glitch Detection

When the SCL clock signal changes state, if the signal only crosses one threshold level (either high or low), it is identified as a glitch, as illustrated in the figure below.


Note: If a signal crosses both threshold levels in a single transition, it will be treated as a normal edge by the master controller. However, this may cause errors in other timing-related test items.



■ SDA Signal Glitch Detection


For the SDA data signal line, glitch detection is only valid when SCL is at a high level. Any glitch that appears while the SCL is high—regardless of whether it crosses one or two threshold levels—is determined to be a glitch, as shown in the figure below.

Note: During the period when SCL is low, glitches on the SDA line are ignored, since they have no effect on bus operation.



■ SDA Signal Glitch

Glitches excluded from rise and fall time statistics: When measuring the rise or fall time of the SDA signal, the software automatically filters out and ignores any glitches to prevent measurement errors. However, glitches can still affect the accuracy of setup and hold time measurements. As illustrated in the figure below, the system uses the last transition (from 0 to 1 or from 1 to 0) of the SDA line before the SCL signal goes high as the valid rise or fall time.




■ Overshoot Determination Principle

Classification of Overshoots: Overshoots are categorized into positive and negative types. Their respective positions on the waveform are shown in the figure below. The maximum overshoot value is recorded and compared with a preset threshold (default is 0.7V in the oscilloscope, but it can be manually adjusted). If the measured overshoot exceeds the threshold, the result is marked as "Fail"; otherwise, it is "Pass. Overshoot Calculation

Formulas:


Positive Overshoot = Local Maximum Value – Top Value

Negative Overshoot = Bottom Value – Local Minimum Value



■ Monotonicity Determination Principle

A monotonicity failure refers to the non-monotonic behavior of a signal during its rising or falling edge, often caused by interference such as glitches. Such interference results in a temporary deviation from the expected smooth transition.



(6) I2C Timing Analysis Parameter Configuration Table

Parameter	Name	Description
Level	Bus level	The unit is volts (V). If the bus voltage is Vcc, then: $V_{cc} < V_{ih(max)} \leq 1010$ $0.5 \times V_{cc} \leq V_{ih(min)} < V_{cc}$ $0.01 \leq V_{il(max)} < 0.5 \times V_{cc}$ $-10 \leq V_{il(min)} \leq -0.01$
V _{IH} (max)	Maximum input high - level voltage	
V _{IH} (min)	Minimum input high - level voltage	
V _{IL} (max)	Maximum input low - level voltage	
V _{IL} (min)	Minimum input low - level voltage	
Freq(max)	Maximum frequency limit	The unit is kHz. The value equals the default rate plus the frequency deviation.
t _{HIGH} (min)	Minimum time of clock high - level	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
t _{LOW} (min)	Minimum time of clock low - level	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
t _R (max)	Maximum rise time of clock/data	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
t _R (min)	Minimum rise time of clock/data	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000, and it must satisfy the condition: $t_R(min) < t_R(max)$.
t _F (max)	Maximum fall time of clock/data	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
t _F (min)	Minimum fall time of clock/data	The unit is nanoseconds (ns), with a range from 0 to 999,000,000, and it must satisfy the condition: $t_F(min) < t_F(max)$.
t _{SU.STA} (min)	Minimum setup time	The unit is nanoseconds (ns), with a range from 1

	of start signal	to 1,000,000,000.
tHD.STA(min)	Minimum hold time of start signal	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tSU.DAT(min)	Minimum setup time of data signal	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tHD.DAT(min)	Minimum hold time of data signal	The unit is nanoseconds (ns), with a range from 1 to 999,000,000, and it must satisfy the condition: tHD.DAT(min) < tHD.DAT(max).
tHD.DAT(max)	Maximum hold time of data signal	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tSU.STO(min)	Minimum setup time of end signal	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tBUF(min)	Minimum time of bus idle	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
Frequency Offset	Clock frequency offset	The unit is Hertz (Hz), with a range from -10,000 to 10,000.
ThresholdH	High threshold	The unit is percentage (%), with a range from 20 to 90.
ThresholdL	Low threshold	The unit is percentage (%), with a range from 10 to 80, and it must satisfy the condition: Low Thresh<=High Thresh-10
Overshoot	Default overshoot value	The unit is volts (V), with a range from 0.01 to 1000.
Monot	Default monotonicity value	

26.5. SPI Timing Analysis

SPI timing analysis relies on SPI decoding. Therefore, SPI decoding must be configured before using SPI timing analysis. For detailed instructions, refer to the [SPI Decoding](#) section.

26.6. Analysis Setting

(1) Clock Signal Source

Click the pull-down list under “Clock Source” to select C1 - C4 as the SPI clock source.

(2) Chip Select Signal Source

Click the pull-down list under “CS Source” to select None or C1 - C4 as the SPI CS source. If set to None, parameters related to the chip select signal will not be tested.

(3) Input Signal Source

Click the pull-down list under “Input Source” to select None or C1 - C4 as the SPI input source. If set to None, SDI-related test items will be skipped during this test.

(4) Output Signal Source

Click the pull-down list under “Output Source” to select None or C1 - C4 as the SPI output source. This output can be routed to other devices. If set to None, SDO-related test items will be skipped during this test.

(5) Sampling Edge

Set the sampling edge of the SPI clock.

Rising Edge: Corresponds to positive clock polarity in decoding.

Falling Edge: Corresponds to negative clock polarity in decoding.

26.7. Parameter Setting

(1) Bus Level Setting

- Bus level: Set the bus level for timing analysis, which refers to the input voltage (V_{CC}) of the signal. Typically, the input voltage for SPI is 3.30 V. If the input voltage is 1.8 V or another value, it can be adjusted by using Knob A. Adjusting the bus level (V_{CC}) will affect the values of V_{IH} and V_{IL} . The relationship between V_{CC} , V_{IH} , and V_{IL} is shown in the table below.
- Input high-level/Low-level voltage (V_{IH} , V_{IL}): These input values are determined by V_{CC} and follow the relationship specified in the table. They can also be manually adjusted by using Knob A; however, modifying V_{IH} or V_{IL} will not affect the value of V_{CC} .

Symbol	Name	Minimum	Maximum	Unit
V_{IH}	Input high-level voltage	$0.7 \times V_{CC}$	$V_{CC} + 0.5$	V
V_{IL}	Input low-level voltage	-0.5	$0.3 \times V_{CC}$	V

- Each of the remaining parameters has its own specific standard. Refer to the table below for standard parameter settings. If the users' standard differs from the one shown in the table, double-click the parameter input field to open the numeric keypad to enter a specific standard. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose A rotary knob to adjust the standard value. Click the Default to restore the default settings.

(2) SPI Bus AC, DC Characteristic Parameter Table


Symbol	Name	Minimum	Maximum	Unit
Level	Bus level			
V_{IH}	Input high-level voltage	$0.7 \times V_{CC}$	$V_{CC} + 0.5$	V

VIL	Input low-level voltage	-0.5	0.3×Vcc	V
Freq (min)	Minimum frequency filter	10		kHz
Freq (max)	Maximum frequency filter	1		MHZ
tR	Clock rise time		2.0	μs
tF	Clock fall time		2.0	μs
t _{HIGH}	Clock high-level time	5.0	-	ns
t _{LOW}	Clock low-level time	5.0	-	ns
t _{SU,CS}	CS signal setup time	5.0		ns
t _{SU,SDI}	Data input signal setup time	2.0	-	ns
t _{HD,CS}	CS signal hold time	2.0		ns
t _{HD,SDI}	Data input signal hold time	0		ns
t _{HD,SDO}	Data output signal hold time	0		ns
t _{V,SDO}	Maximum data output signal valid time	1.0		μs
t _{DIS,SDO}	Minimum time from CS inactive to data off	This item is optional and not defined in standard specifications. Users can customize the acceptable test range based on actual application requirements.		
Over ₊	Positive overshoot	This item is part of optional signal quality testing and is not defined in standard specifications. Users may define the acceptable test range according to their specific needs.		
Over ₋	Negative overshoot			
Glitch	Glitch			

Note: All parameter values are referenced to the VIHmin (0.7Vcc) and the VILmax (0.3Vcc). If these parameters differ from those specified in the user manual, they can be manually adjusted.

(3) Signal Position


The specific signal positions corresponding to each SPI test item are shown below.



All time-related test items of SPI are based on V_{IHmin} (0.7Vcc) and V_{ILmax} (0.3Vcc) levels. The 0.7Vcc and 0.3Vcc levels serve as the high and low threshold values in the parameter settings, and they are configurable.

The calculation principles for voltage-related test items in SPI, V_{IH} (high threshold) and V_{IL} (low threshold) are illustrated in the figure below.

- V_{IH} : The voltage measured from the flat top of the waveform to ground, representing the top value.
- V_{IL} : The voltage measured from the flat bottom of the waveform to ground, representing the bottom value.



Calculation of Top and Bottom Value

(4) SPI Timing Analysis Test Item Table

Signal	Test Item	Description
SCK	VIL.SCK	Low-level voltage of the SCK signal line, as shown in the bottom value of the figure.
	VIH.SCK	High-level voltage of the SCK signal line, as shown in the top value of the figure.

	Glitch.SCK	Glitch test item for the SCK signal line.
	Over+.SCK	Positive overshoot test item for the SCK signal line. If the overshoot voltage exceeds the preset value, the software will judge this item as Fail.
	Over-.SCK	Negative overshoot test item for the SCK signal line. If the overshoot voltage exceeds the preset value, the software will judge this item as Fail.
	Freq.SCK	Frequency measurement based on a threshold of 0.7V _{cc} (configurable). The displayed measurement value is for the first clock cycle, where $\text{Freq.SCK} = 1/\text{tSCK}$.
	tR.SCL(MAX)	The rise time (tR) and fall time (tF) of the clock. During measurement, the system will automatically count all the rise-time and fall-time samples on the screen (main time base) and select the maximum value (the worst timing waveform) as the measurement result.
	tF.SCL(MAX)	
	tLOW(MIN)	The low-level period (tLOW) and high-level period (tHIGH) of the SCK clock signal. During measurement, the system will automatically count all the low-level or high-level period samples on the screen (main time base) and select the minimum value (the worst timing waveform) as the measurement result.
	tHIGH(MIN)	
CS	VIL.CS	Low-level voltage of the chip select (CS) signal line, as shown in the bottom value of the figure.
	VIH.CS	High-level voltage of the chip select (CS) signal line, as shown in the top value of the figure.
	Glitch.CS	Glitch test item for the CS signal line.
	tSU.CS(MIN)	Setup time for the chip select signal. The system will automatically count all the setup-time samples for the CS signal on the screen (main time base) and select the minimum value as the measurement result.
	tHD.CS(MIN)	Hold time for the chip select signal. The system will automatically count all the hold-time samples for the CS signal on the screen (main time base) and select the minimum value as the measurement result.
SDI	VIL.SDI	Low-level voltage of the SDI signal line, as shown in the bottom value of the figure.
	VIH.SDI	High-level voltage of the SDI signal line, as shown in the top value of the figure.

	Glitch.SDI	Glitch test item for the SDI signal line.
	tSU.SDI(MIN)	Setup time for the data input signal. The system will automatically count all the setup-time samples for the data signal on the screen (main time base) and select the minimum value as the measurement result.
	tHD.SDI(MIN)	Hold time for the data input signal. The system will automatically count all the hold-time samples for the data signal on the screen (main time base) and select the minimum value as the measurement result.
SDO	VIL.SDO	Low-level voltage of the SDO signal line, as shown in the bottom value of the figure.
	VIH.SDO	High-level voltage of the SDO signal line, as shown in the top value of the figure.
	Glitch.SDO	Glitch test item for the SDO signal line.
	tV.SDO(MIN)	Data output valid time. The system will automatically count all the output valid time samples for the data signal on the screen (main time base) and select the minimum value as the measurement result.
	tHD.SDO(MIN)	Hold time for the data output signal. The system will automatically count all the hold-time samples for the data signal on the screen (main time base) and select the minimum value as the measurement result.
	tDIS.SDO(MIN)	Minimum time from CS invalid to data being turned off. The system will automatically count all the CS invalid to data turn-off time samples on the screen (main time base) and select the minimum value as the measurement result.

(5) Signal Quality Items


Signal quality testing includes glitch and overshoot detection.

■ Glitch Determination Principle

a. SCK/CS Signal Glitch Detection

When the SCK/CS clock signal changes state, if the signal only crosses one threshold level, it is identified as a glitch, as illustrated in the figure below.


Note: If a signal crosses both threshold levels in a single transition, it will be treated as a normal edge by the master controller. However, this may cause errors in other timing-related test items.



SCK/CS waveform only crosses one threshold level

b. SDI/SDO Signal Glitch Detection


Glitches that appear on the SDI or SDO data signal lines, whether during the high or low level of the SCK clock always affect the bus and are therefore treated as error-causing glitches. As shown in the figure below, these glitches will be reported as errors.



SDI/SDO Signal Glitch Detection

c. SDI/SDO Signal Glitch

Glitches excluded from rise and fall time statistics: When measuring rise or fall times, the software will automatically filter out and ignore glitches to prevent measurement errors. However, glitches can affect the measurement of setup and hold times. As shown in the figure below, the system will use the most recent transition (from 0 to 1 or from 1 to 0) on the SDI/SDO line before the SCK clock goes high as the rise or fall time.




■ Overshoot Determination Principle

Classification of Overshoots: Overshoots are categorized into positive and negative types. Their respective positions on the waveform are shown in the figure below. The maximum overshoot value is recorded and compared with a preset threshold (default is 0.7V in the oscilloscope, but it can be manually adjusted). If the measured overshoot exceeds the threshold, the result is marked as "Fail"; otherwise, it is "Pass".

Overshoot Calculation Formulas:

Positive Overshoot = Local Maximum Value – Top Value

Negative Overshoot = Bottom Value – Local Minimum Value



(6) SPI Timing Analysis Parameter Configuration Table

Parameter	Name	Description
Level	Bus level	The unit is volts (V). If the bus voltage is Vcc, then: $V_{cc} < V_{IH(max)} \leq 1010$ $0.5 \times V_{cc} \leq V_{IH(min)} < V_{cc}$ $0.01 \leq V_{IL(max)} < 0.5 \times V_{cc}$ $-10 \leq V_{IL(min)} \leq -0.01$
VIH(max)	Maximum input high - level voltage	
VIH(min)	Minimum input high - level voltage	
VIL(max)	Maximum input low - level voltage	
VIL(min)	Minimum input low - level voltage	

tHIGH(min)	Minimum time of clock high - level	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tLOW(min)	Minimum time of clock low - level	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tR(max)	Maximum rise time of clock	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tF(max)	Maximum fall time of clock	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tSU.CS(min)	Minimum setup time of CS signal	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tHD.CS(min)	Minimum hold time of CS signal	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tSU.SDI(min)	Minimum setup time of data input signal	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tHD.SDI(min)	Minimum hold time of data input signal	The unit is nanoseconds (ns), with a range from 0 to 999,000,000.
tV.SDO(min)	Maximum data output valid time	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tHD.SDO(min)	Minimum data output valid time	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tDIS.SDO	tDIS.SDO switch	ON, OFF
tDIS.SDO(min)	Minimum time from CS inactive to data disable	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
Speed Filter	Speed filter switch	ON, OFF
Freq(min)	Minimum frequency filter	The unit is Hertz (Hz), with a range from 1 to 1,990,000,000, and it must satisfy the condition: $\text{Freq}(\text{min}) < \text{Freq}(\text{max})$.
Freq(max)	Maximum frequency filter	The unit is Hertz (Hz), with a range from 2 to 2,000,000,000.
Hith Thresh	High threshold	The unit is percentage (%), with a range from 20 to 90.
Low Thresh	Low threshold	The unit is percentage (%), with a range from 10 to 80, and it must satisfy the condition: $\text{Low Thresh} \leq \text{High Thresh} - 10$
Over	Default overshoot value	The unit is volts (V), with a range from 0.01 to 1000.

26.8. CAN Timing Analysis

CAN timing analysis software is a plugin designed to automatically test the electrical characteristics of the CAN bus. It is suitable for hardware testing of all CAN bus products.

CAN timing analysis relies on CAN decoding; therefore, CAN decoding must be configured before using the timing analysis function. For detailed instructions, refer to the [CAN Decoding](#) section.

26.9. Analysis Setting

(1) Source

Click on the "Source" to select C1 - C4 as CAN signal source.

(2) Signal Type

Click on the "Signal Type" list to select from CAN_L, CAN_H, or CAN_DIFF. The default voltage measurement range varies depending on the selected signal type.

(3) Baudrate

Select the baudrate for CAN serial bus data, click on the "Baudrate" to select 10 kbps, 19.2 kbps, 20 kbps, 33.3 kbps, 38.4 kbps, 50 kbps, 57.6 kbps, 62.5 kbps, 83.3 kbps, 100 kbps, 115.2 kbps, 125 kbps, 230.4 kbps, 250 kbps, 490.8 kbps, 500 kbps, 800 kbps, 921.6 kbps, 1 Mbps, 2 Mbps, 3 Mbps, 4 Mbps, 5 Mbps, or a custom baudrate.

If "Custom" is selected, a custom baudrate can be entered.

(4) Filter Conditions

Click on the "Filter Conditions" to set the CAN signal frame ID filter. Different filter conditions correspond to different configurable ranges for the frame ID.

- None: All CAN frames will be tested.
- Standard frame: Only the bit time of the specified standard frame ID will be tested.
- Extended frame: Only the bit time of the specified extended frame ID will be tested.

(5) Frame ID

- When the filter condition is set to standard frame or extended frame, the frame ID can be configured. Double-click on the "Frame ID" input field to open the numeric keypad to set the identifier. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the [Multipurpose B](#) rotary knob to move the selected cursor, and use the [Multipurpose A](#) rotary knob to adjust the identifier. The setting range is 000 to 7FF for standard frames and 00000000 to 1FFFFFFF for extended frames.

(6) Bit Time Error

Bit time error refers to the deviation between the calculated bit time based on the signal edge and the configured Btrate.

Click on the “Bit Time Error” to select the error threshold. Available options are: 0.35%, 0.45%, and 0.5%.

26.10. Parameter Setting

(1) Test Item


Dominant and recessive bit timing analysis test items in the CAN timing analysis software.

Measurement Item	Description
Dominant.x	Dominant bit voltage test (see Note 1)
Recessive.x	Recessive bit voltage test (see Note 1)
Bit Time (MIN,MAX)	Bit time test, outputs the minimum and maximum values observed during statistics

Note 1: “x” can be CAN_DIFF, CAN_L, or CAN_H, representing differential or single-ended line voltages, respectively.

(2) Dominant and Recessive Voltage Configuration

The dominant and recessive voltage levels on the CAN bus are determined by analyzing the voltage histogram in the specified direction. Depending on the selected test mode (CAN Differential, CAN_H single-ended, or CAN_L single-ended), the dominant and recessive test results correspond to either the top or bottom values in the waveform, as illustrated in the figure below.



Calculation of Top and Bottom Value

According to Section 4.1 of the GMW14241 standard, the acceptable voltage ranges for dominant bits and recessive bits are specified in Table 1 and Table 2, respectively.

If the measured voltage exceeds the specified range, the software will analyze the result and report it as Fail.

Table 1 Dominant Bit Voltage Range

Notation	Value		
	Minimum	Nominal	Maximum
CAN_L	0.5 V (preferred: 0.8 V)	1.5 V	2.25 V (preferred: 2.0 V)
CAN_H	2.75 V (preferred: 3.0 V)	3.5 V	4.5 V (preferred: 4.25 V)
CAN_DIFF	1.5 V	2.0 V	3.0 V

Table 2 Recessive Bit Voltage Range

Notation	Value		
	Minimum	Nominal	Maximum
CAN_L	2.0V	2.5V	3.0V
CAN_H	2.0V	2.5V	3.0V
CAN_DIFF	-120 mV	0	+12 mV

(3) Parameter Table

Parameter	Description
Dominant(max)	The upper limit of the allowable voltage value for the dominant bit (logic 0). When the measured value exceeds this value, the result will be judged as "Fail". Under normal circumstances, the default value can be used.
Dominant(min)	The lower limit of the allowable voltage value for the dominant bit (logic 0). When the measured value is less than this value, the result will be judged as "Fail". Under normal circumstances, the default value can be used.
Recessive(max)	The upper limit of the allowable voltage value for the recessive bit (logic 1). When the measured value exceeds this value, the result will be judged as "Fail". Under normal circumstances, the default value can be used.
Recessive(min)	The lower limit of the allowable voltage value for the recessive bit (logic 1). When the measured value is less than this value, the result will be judged as "Fail". Under normal circumstances, the default value can be used.
Threshold	This parameter is valid when the bus type is set to CAN_DIFF. When the bus type is CAN_L or CAN_H, this parameter cannot be set, and the threshold is automatically the midpoint between the dominant

	and recessive voltage levels (i.e., 50%).
Bit_time	<p>This refers to the allowable error in the bit time reference value.</p> <p>There are three options: 0.35%, 0.45%, and 0.50%.</p> <p>When the CAN bus is single-wire, select 0.35%.</p> <p>When the CAN bus is a high-speed differential, select 0.45%.</p> <p>When the CAN bus is a medium-speed differential, select 0.50%.</p> <p>These choices are based on the specifications in sections 4.3.10, 4.1.10, and 4.2.10 of the GMW14241 standard.</p>

26.11. I²S Timing Analysis

It is a plugin capable of automatically testing the electrical characteristics of the I²S bus. It can complete the DC and AC characteristic analysis of the bus signals in a very short time, comparing them with the nominal parameters in the device manual, and directly output the test results (Pass/Fail). It also supports report export. This plugin is suitable for hardware testing of all I²S buses, especially for hardware testing of mass-produced products. It can complete the workload that traditionally takes 30 to 60 minutes within just a few minutes.

I²S Timing Analysis depends on Audio decoding. Therefore, when using I²S timing analysis, it is necessary to first configure the audio decoding. For the detailed configuration process of audio decoding, please refer to the [Audio Decoding](#) section.

26.12. Analysis Setting

(1) Clock Source

Click the pull-down list under "Clock Source" to select C1 - C4 as the I²S clock source.

(2) Chip Select Signal Source

Click the pull-down list under "CS Source" to select C1 - C4 as the I²S CS source.

(3) Data Source

Click the pull-down list under "Data Source" to select C1 - C4 as the I²S data signal source.

(4) Sender

Click the pull-down list under "Sender" and select Master or Slave, indicating whether the data sender or data receiver is the command sender.

26.13. Parameter Setting

(1) Bus Level Setting

- Bus level: Set the bus level for timing analysis, which refers to the input voltage (V_{cc}) of the signal. Typically, the input voltage for I²S is 3.30 V. If the input voltage is 1.8 V or another value, it can be adjusted by using Knob A. Adjusting the bus level (V_{cc}) will affect the values of V_{IH} and V_{IL} . The relationship between V_{cc} , V_{IH} , and V_{IL} is shown in the table below.
- Input high-level/Low-level voltage (V_{IH} , V_{IL}): These input values are determined by V_{cc} and follow the relationship specified in the table. They can also be manually adjusted by using Knob A; however, modifying V_{IH} or V_{IL} will not affect the value of V_{cc} .

Symbol	Name	Minimum	Maximum	Unit
V_{IH}	Input high-level voltage	$0.7 \times V_{cc}$	$V_{cc} + 0.5$	V
V_{IL}	Input low-level voltage	-0.5	$0.3 \times V_{cc}$	V

- Each of the remaining parameters has its own specific standard. Refer to the table below for standard parameter settings. If the user's standard differs from the one shown in the table, double-click the parameter input field to open the numeric keypad to enter a specific standard. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the [Multipurpose A](#) rotary knob to adjust the standard value. Click the Default to restore the default settings.


(2) I²S Bus AC, DC Characteristic Parameter Table

Symbol	Name	Minimum	Maximum	Unit
Level	Bus level			
V_{IH}	Input high-level voltage	$0.7 \times V_{cc}$	$V_{cc} + 0.5$	V
V_{IL}	Input low-level voltage	-0.5	$0.3 \times V_{cc}$	V
tJitter	Clock jitter	-	100	μs
tR	Clock rise time	-	100	μs
tF	Clock fall time	-	100	μs
t_{HIGH}	Clock high-level time	160	-	ns
t_{LOW}	Clock low-level time	160	-	ns
t_{SU}	Signal setup time	60	-	ns
t_{HD}	Signal hold time	0	-	ns
t_{HDelay}	Hold delay time	-	500	μs
t_{Delay}	Transmission delay time	-80	80	μs
Over ₊	Positive overshoot	This item is part of optional signal quality testing and is not defined in standard specifications. Users may define the acceptable test range according to their specific needs.		
Over ₋	Negative overshoot			
Monot	Monotonicity			
Glitch	Glitch			


Note: All parameter values are referenced to the V_{IHmin} (0.7Vcc) and the V_{ILmax} (0.3Vcc). If these parameters differ from those specified in the user manual, they can be manually adjusted.

(3) Signal Position I²S

The specific signal positions corresponding to each I²S test item are shown below.




The analysis of the clock jitter test item in I²S is shown in the figure below.



The calculation principles for voltage-related test items in I²S, V_{IH} (high threshold) and V_{IL} (low threshold) are illustrated in the figure below.

- V_{IH} : The voltage measured from the flat top of the waveform to ground, representing the top value.
- V_{IL} : The voltage measured from the flat bottom of the waveform to ground, representing the bottom value.



Calculation of Top and Bottom Value

(4) I²S Timing Analysis Test Item Table

Signal	Test Item	Description
SCK	VIL.SCK	Low-level voltage of the SCK signal line, as shown in the bottom value of the figure.
	VIH.SCK	High-level voltage of the SCK signal line, as shown in the top value of the figure.
	Glitch.SCK	Glitch test item for the SCK signal line. This item is only displayed when a glitch is detected during analysis.
	Over+.SCK	Positive overshoot test item for the SCK signal line. If the overshoot voltage exceeds the preset value, the software will judge this item as Fail.
	Over-.SCK	Negative overshoot test item for the SCK signal line. If the overshoot voltage exceeds the preset value, the software will judge this item as Fail.
	Monot.SCK	Monotonicity (i.e., dip) test item for the SCK signal line. If the dip voltage exceeds the preset threshold, the software will mark this item as "Fail".
	Freq.SCK(Avg)	The frequency of the SCK clock signal is measured at a threshold of 0.5Vcc. The average frequency is calculated using a weighted algorithm based on many samples with similar periods (excluding outlier cycles that are too long or too short).
	Jitter.SCK	The jitter value is calculated as the difference between the maximum and minimum of the measured clock periods. It is compared against a preset threshold. If the value exceeds the threshold, the result is "Fail", otherwise "Pass". Since this item is not strictly required, the default threshold is set relatively large, and it usually passes under normal conditions. Set it manually only if specific requirements exist.
	tR.SCL(MAX)	tR and tF represent the rise and fall times of the clock signal. The system automatically analyzes all clock rise time and fall time samples on the screen (main time base), and outputs the
	tF.SCL(MAX)	

		maximum value among the samples (the worst timing waveform) as the result.
	tLOW.SCK(MIN)	tLOW and tHIGH represent the low-level and high-level durations of the SCK clock signal. The system automatically analyzes all low-level or high-level duration samples on the screen (main time base), and outputs the minimum value (the worst timing waveform) as the result.
	tHIGH.SCK(MIN)	
WS	VIL.WS	The low-level (VIL) voltage of the WS signal line, as shown in the bottom value of the figure.
	VIH.WS	The high-level (VIL) voltage of the WS signal line, as shown in the top value of the figure.
	Glitch.WS	Glitch test item for the WS signal line.
	Over+.WS	Positive and negative overshoot test items for the WS signal line. If the overshoot voltage exceeds the preset value, the result is "Fail".
	Over-.WS	
	Monot.WS	Monotonicity (glitch) test item for the WS signal line. If the glitch voltage exceeds the preset threshold, the result is "Fail".
	Freq.WS(Avg)	The frequency of the WS clock signal is measured at a threshold of 0.5Vcc. The average frequency is calculated using a weighted algorithm based on many samples with similar periods.
	Jitter.WS	Jitter value = Maximum - Minimum. Compared with the preset threshold: if greater, the result is "Fail"; otherwise, "Pass". Default values are loose since this item is not mandatory. Normally it passes under standard conditions. Adjust manually for stricter needs.
	tSU.WS(MIN) LOW	Setup and hold times for the low level of the word select signal. The system automatically analyzes all relevant samples and outputs the minimum value (the worst timing waveform) as the result.
	tHD.WS(MIN) LOW	Hold time for the low-level of the word select signal. The system automatically analyzes all relevant low-level hold time samples on the screen (main time base), and outputs the minimum value (the worst timing waveform) as the result.
	tSU.WS(MIN) HIGH	Setup time for the high-level of the word select signal. The system automatically analyzes all relevant high-level setup time samples on the screen (main time base), and outputs the minimum value (the worst timing waveform) as the result.
	tHD.WS(MIN) HIGH	Hold time for the high-level of the word select signal. The

		system automatically analyzes all relevant high-level hold time samples on the screen (main time base), and outputs the minimum value (the worst timing waveform) as the result.
	tHDelay.WS(MAX)	Hold delay time of the word select signal from the beginning to the end of a single sampling. The system automatically analyzes all relevant word select hold delay samples on the screen (main time base) and outputs the maximum value as the result.
SD	VIL.SD	Low-level voltage of the SDI signal line, as shown in the bottom value of the figure.
	VIH.SD	High-level voltage of the SDI signal line, as shown in the top value of the figure.
	tSU.SD(MIN) LOW	Setup time for the low-level of the data signal. The system automatically analyzes all relevant low-level setup time samples on the screen (main time base) and outputs the minimum value (the worst timing waveform) as the result.
	tHD.SD(MIN) LOW	Hold time for the low-level of the data signal. The system automatically analyzes all relevant low-level hold time samples on the screen (main time base) and outputs the minimum value (the worst timing waveform) as the result.
	tSU.SD(MIN) HIGH	Setup time for the high-level of the data signal. The system automatically analyzes all relevant high-level setup time samples on the screen (main time base) and outputs the minimum value (the worst timing waveform) as the result.
	tHD.SD(MIN) HIGH	Hold time for the high-level of the data signal. The system automatically analyzes all relevant high-level hold time samples on the screen (main time base) and outputs the minimum value (the worst timing waveform) as the result.
	tHDelay.SD(MAX)	Hold delay time of the data signal from the beginning to the end of a single sampling. The system automatically analyzes all relevant data hold delay samples on the screen (main time base) and outputs the maximum value as the result.
WS-SCK	tDELAY(WS-SCK)(MIN,MAX)	Transmission delay between the word select and clock signals. The system automatically analyzes all relevant delay samples between WS and SCK on the screen (main time base), and outputs the minimum and maximum values as the result.
SD-SCK	tDELAY(SD-SCK)(MIN,MAX)	Transmission delay between the data and clock signals. The system automatically analyzes all relevant delay samples between SD and SCK on the screen (main time base), and


		outputs the minimum and maximum values as the result.
SD-WS	tDELAY(SD-WS) (MIN,MAX)	Transmission delay between the data and word select signals. The system automatically analyzes all relevant delay samples between SD and WS on the screen (main time base), and outputs the minimum and maximum values as the result.

(5) Glitch Determination Principle

■ SCK Signal Glitch Detection

When the SCK clock signal changes state, if the signal only crosses one threshold level, it is identified as a glitch, as illustrated in the figure below.


Note: If a signal crosses both threshold levels in a single transition, it will be treated as a normal edge by the master controller. However, this may cause errors in other timing-related test items.



SCK waveform only crosses one threshold level

■ WS/SD Signal Glitch Detection


Glitches occurring on the WS or SD signal lines, whether during the high or low level period of the SCK signal, will always affect the bus operation. Therefore, any detected glitch on WS or SD is considered as error-causing glitch, as illustrated in the figure below.



WS/SD Signal Glitch Detection

■ WS/SD Signal Glitch Detection


Glitches excluded from rise and fall time statistics: When measuring rise or fall times, the software will automatically filter out and ignore glitches to prevent measurement errors. However, glitches can affect the measurement of setup and hold times. As shown in the figure below, the system will use the most recent transition (from 0 to 1 or from 1 to 0) on the WS/SD line before the SCK clock goes high as the rise or fall time.



Calculate Rise and Fall Time

■ Monotonicity Determination Principle

A monotonicity failure refers to the non-monotonic behavior of a signal during its rising or falling edge, often caused by interference such as glitches. Such interference results in a temporary deviation from the expected smooth transition.



Glitch on Waveform Rising Edge

(6) I²S Timing Analysis Parameter Configuration Table

Parameter	Name	Description
Level	Bus level	The unit is volts (V). If the bus voltage is V _{cc} , then: $V_{cc} < V_{IH(max)} \leq 1010$ $0.5 \times V_{cc} \leq V_{IH(min)} < V_{cc}$ $0.01 \leq V_{IL(max)} < 0.5 \times V_{cc}$ $-10 \leq V_{IL(min)} \leq -0.01$
V _{IH} (max)	Maximum input high - level voltage	
V _{IH} (min)	Minimum input high - level voltage	
V _{IL} (max)	Maximum input low - level voltage	




VIL(min)	Minimum input low - level voltage	
tJitter(max)	Maximum jitter time of clock	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tHIGH(min)	Minimum time of clock high - level	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tLOW(min)	Minimum time of clock low - level	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tR(max)	Maximum rise time of clock	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tF(max)	Maximum fall time of clock	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tSU(min)	Minimum setup time	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tHD(min)	Minimum hold time	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tHDelay(max)	Maximum hold delay time	The unit is nanoseconds (ns), with a range from 1 to 1,000,000,000.
tDelay(min)	Minimum transmission delay time	The unit is nanoseconds (ns), with a range from -1000,000,000 to 999,000,000
tDelay(max)	Maximum transmission delay time	The unit is nanoseconds (ns), with a range from -999,000,000 to 1,000,000,000
Over(V)	Default overshoot value	The unit is volts (V), with a range from 0.01 to 1000.
Monot(V)	Default monotonicity value	
High Thresh	High threshold	The unit is percentage (%), with a range from 30 to 90.
Mid Thresh	Middle threshold	The unit is percentage (%), with a range from 20 to 90.
Low Thresh	Low threshold	The unit is percentage (%), with a range from 10 to 70, and it must satisfy the condition: Low Thresh ≤ High Thresh – 20.


27. Search and Navigation



The search function allows the user to quickly find and highlight the events of interest, and then use the event navigation to quickly find the highlighted signals to view. Waveform search criteria can be set to edge, pulse width, slope, runt, window, delay, timeout, duration, setup & hold, Nth edge and code pattern. Navigation allows the user to quickly view and locate waveforms. Navigation includes time navigation, event navigation and frame segment navigation.


27.1. Search and Navigation

The search function can be opened by the following steps.

- Click the Home icon , select the search icon  to open the search function.
- If the search icon is added to the toolbar, click on the search icon  in the toolbar at the top-right of the screen to open the search function.

The search function looks for waveform specific edge and pulse width events and marks them with small, inverted triangles () along the top of the waveform scale.

Click the Home icon  at the top-right of the screen and select the search icon  to open the search function, as shown in the following figure.



1. Turn on/off search function

Click on the “Search” to switch on/off search function.

2. Search Type

Click on the “Search Type” to select edge, pulse width, slope, runt, over-amplitude, delay, timeout, duration, setup & hold, Nth edge, and code pattern.




- Edge search: Click on the “Search Type” and select “Edge”. For the edge type setting (source, trigger coupling, edge type, trigger level), refer to the section of [“Edge Trigger”](#).
- Pulse width search: Click on the “Search Type” and select “Pulse width”. For the pulse width setting (source, polarity, upper limit, lower limit), refer to the section of refer to the section of [“Pulse Width Tigger”](#).
- Slope search: Click on the “Search Type” and select “Slope”. For the slope setting (source, edge type, condition, upper limit of time, lower limit of time), refer to the section of refer to the section of [“Slope Trigger”](#).
- Runt search: Click on the “Search Type” and select “Runt”. For the runt setting (source, polarity, runt condition, upper limit of time, lower limit of time), refer to the section of refer to the section of [“Runt Trigger”](#).
- Over-amplitude search: Click on the “Search Type” and select “Over-amplitude”. For the Over-amplitude setting (source, edge type, search position, over-amplitude time), refer to the section of refer to the section of [“Over-amplitude Trigger”](#).
- Delay search: Click on the “Search Type” and select “Delay”. For the delay setting (source, edge type, delay condition, upper limit of time, lower limit of time), refer to the section of refer to the section of [“Delay Trigger”](#).
- Timeout search: Click on the “Search Type” and select “Timeout”. For the timeout setting (source, edge type, timeout type), refer to the section of refer to the section of [“Timeout Trigger”](#).
- Duration search: Click on the “Search Type” and select “Duration”. For the timeout setting (source, code pattern, upper limit of time, lower limit of time), refer to the section of refer to the section of [“Duration Trigger”](#).
- Setup & Hold search: Click on the “Search Type” and select “Setup & Hold”. For the setup & hold setting (data source, clock source, edge type, data type, trigger condition, time), refer to the section of refer to the section of [“Setup & Hold Trigger”](#).
- Nth edge search: Click on the “Search Type” and select “Nth edge”. For the Nth edge setting (source, edge type, search position, time), refer to the section of refer to the section of [“Nth Edge Trigger”](#).


- Code pattern search: Click on the “Search Type” and select “Code pattern”. For the code pattern setting (source, code patter), refer to the section of refer to the section of “[Code Pattern Trigger](#)”.

3. Event Table

Toggle the switch next to the event table option to turn the event table display ON or OFF.

When enabled, the interface will appear as shown below. The event table lists the search points detected in the currently displayed waveform view. Zooming or adjusting the waveform will update the search results shown in the event table accordingly.

- When there are many search results, the search points will be displayed in expandable blocks. Expand a block to view detailed information about the corresponding search points.
- In STOP mode, double-click any row in the event table to select the corresponding event. This action opens an expanded view and zooms in on the selected event, centering it on the screen. The inverted triangle marker for the selected event will turn red.
- Click the icon  in the top-right corner of the event table to open the search menu.
- Press and hold the gray title bar above the event table to drag and reposition the window.
- Click the icon  in the top-right corner of the event table to open the Help document.
- Click the icon  in the top-right corner of the event table to close the event table.



4. Copy to trigger

Click on the “Copy to Trigger” to copy the settings of the selected search type to its corresponding trigger type. For example, if the current search type is “Edge”, clicking “Copy to

Trigger” will apply the edge search settings to the “Edge Trigger” settings.

5. Trigger Self-Copy

Click on the “Trigger Self-Copy” to copy the trigger settings of the selected trigger type to the search settings. For example, if the current trigger type is “Edge Trigger”, clicking “Trigger Self-Copy” will copy the edge trigger settings to the “Edge” search settings.

To use the “Trigger Self-Copy” function, the search type should set first. Then, copy the corresponding trigger settings from the trigger menu.

6. Save Event Table

When the operating state is RUN/STOP, the time and decoding data in the current event list can be exported.

Click the “Save Event Table” key in the decoding menu to pop up the export setting menu, the data can be saved as *.csv, *.html, and *.pdf to internal storage or external USB disk drive (when a USB is detected).

For the setting steps, refer to the section of [Save and Load](#).

When there is a large amount of search data and the volume of data to be saved is substantial, the saving process may take longer.

Note: When the operating state is RUN, the decoding data may be unstable, the user can manually stop the oscilloscope to export a stable decoding signal.




7. Navigation


Click on the “Navigation”key to jump to the navigation module.


27.2. Navigation


The navigation function includes time navigation and search event navigation.

The navigation menu can be accessed by the following methods.

- Click the Home icon , select the navigation icon  to open the navigation function.
- If the navigation icon is added to the toolbar, click on the navigation icon  in the toolbar at the top-right of the screen to open the navigation function.
- Click the “Navigation”key in search module to open the navigation function.



The navigation menu is shown in the figure above. Click the icon  in the menu to minimize the navigation menu and simplify the interface, as shown in the figure below.






Note: The navigation function is only available when the operation status is STOP (acquisition stopped).



(1) Time Navigation


The time navigation mode is only available in the “YT” time base mode.

■ Playback

After selecting time navigation, click the key  in the menu to start or stop playback. Use the previous  or next key  to move the waveform. Playback will stop automatically when it reaches either end of the waveform.



■ Playback Mode


The playback mode is divided into two modes: single playback  and cycle playback . Click the icon in the lower left corner of the menu to switch the playback order.

: Playback starts from the start frame and ends at the end frame, stopping automatically.


: Click the icon at the bottom left corner of the screen to switch between modes.

■ Playback Order

The playback order can be set to sequential playback  or reverse playback . Click the icon in the lower right corner of the menu to switch the playback order.


: The waveform plays to the right of the center point of the screen, moving from the

center to the left.

: The waveform plays to the left of the center point of the screen, moving from the center to the right.

(2) Search Event Navigation




After completing an event search using the Search function, the user can use the Search Event Navigation to quickly view the search events. The Search Event Navigator screen is shown below.





■ Search


After selecting the Search Event Navigation in the navigation interface, the user can click “Search” to open the “Search” menu and set the search conditions. Please refer to the Search Function for the relevant search settings.


■ Playback

After selecting the search navigation, click the key  in the menu to start or stop playback. The user can use the previous key  (left search point) or the next key  (right search point) to display the search points in the center of the screen. Playback will automatically stop when it reaches the leftmost or rightmost mark point.



■ Playback Mode


The playback mode is divided into two modes: single playback  and cycle playback . Click the icon in the lower left corner of the menu to switch the playback order.


: Playback automatically stops after playing from the first search point to the last search point.

: Playback repeats from the first to the last search point until the operation is stopped manually.

■ Playback Order

The playback order can be set to sequential playback  or reverse playback . Click the icon in the lower right corner of the menu to switch the playback order.




: Play from the leftmost search point to the rightmost search point.


: Play from the rightmost search point to the leftmost search point.







27.3. Marker Navigation

The marker function enables users to manually add markers and navigate to specific points.

The navigation menu can be accessed by the following methods.

- Click the Home icon , select the marker navigation icon  to enter the marker navigation function.
- If the navigation icon is added to the toolbar, click on the navigation icon  in the toolbar at the top-right of the screen to open the marker navigation function.



- (1) Marker: Click to open the marker list.
- (2) Index: For the current navigation marker point, double-click the "Index" input field to open the numeric keypad to set this value. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, use the [Multipurpose A](#) rotary knob to adjust this value.
- (3) : Mark the midpoint of the current waveform area with the marking symbol , the number of points in the marker list will increase by one.
- (4) Clear: Clear the midpoint marker in the waveform area.
- (5) Clear all: Clear all markers.
- (6) Click the previous  key to navigate to the previous marker point (decreasing the marker index number), or click the next  key to navigate to the next marker point (increasing the marker index number). Click the  key to navigate to the first marker point or click the  key to navigate to the last marker point.




28. Function/Arbitrary Waveform Generator (Gen)


- [Open Function/Arbitrary Waveform Generator](#)
- [Carrier Waveform Output](#)
- [Advanced Application](#)

MSO5000HD has a built-in function/arbitrary waveform generator. It uses direct digital synthesis (DDS) technology to generate accurate and stable waveform outputs with a resolution as low as 1 μHz . MSO5000HD is an economical function/arbitrary waveform generator.

28.1. Open Function/Arbitrary Waveform Generator

The “Gen” menu can be entered using the following steps.

- Press the **G1** or **G2** key on the front panel to enter the “Gen” menu.
- Click the Home icon  at the top-right of the screen and select the Gen icon  to enter the “Gen” menu.
- If the Gen function is added to the toolbar, click the counter icon  in the toolbar at the top-right of the screen to enter the “Gen” menu.



The oscilloscope supports two Gen signal outputs: G1, G2, click on the “Gen” to select G1, G2 tabs,

the selected tabs will be highlighted. This chapter uses G1 as an example to introduce Gen.

(1) Output Switch

Click on the “Output Switch” to set the G1 output state.

ON: Outputs the current G1 signal.

OFF: Does not output the G1 signal.

(2) Output Type

Click on the “Output Type” to select the output signal type to continuous waveform, AM waveform, or FM waveform, amplitude shift keying (ASK), frequency shift keying (FSK), and sweep.

(3) Output Impedance

Double-click on the “Output Impedance” input field to open the numeric keypad to set the impedance. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). The selected output impedance must match with the impedance of the connected oscilloscope, otherwise, the amplitude and offset level of waveform on the screen will be incorrect.

(4) Copy

Click on the “G1->G2” or “G1<-G2”, copy the signal setting from G1/G2 to G2/G1.

(5) Reversed Output

Click on the “Reversed Output” to switch on/off the reversed output.

ON: Reverses the AC output signal.

OFF: The AC output signal will not be reversed.

(6) Waveform Parameter

Double-click on the parameter input field to open the numeric keypad to set the parameter. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

Alternatively, select the parameter, use the [Multipurpose B](#) rotary knob to move the selected cursor, and use the [Multipurpose A](#) rotary knob to adjust the parameter setting.

(7) Waveform figure: Displays the waveform of G1 signal.

28.2. Carrier Waveform Output

Gen can output waveforms from G1, G2 individually or simultaneously. By default, when Gen is switched on, the instrument outputs a sine wave with a frequency of 1 kHz and an amplitude of 100 mVpp. This section uses G1 as an example to introduce how to configure the instrument to output different types of waveforms.

(1) Waveform Type

Click on the “Carrier Wave” to select the waveform to sine, square, ramp, pulse wave, arbitrary, noise, or DC wave. For details on the parameters associated with each waveform, refer to the following table.

Continuous wave	Parameter	Frequency range	Amplitude range	Offset range
Sine wave	Frequency/cycle, amplitude/high level, DC offset/low level, phase ($\pm 360^\circ$)	1 μ Hz-50 MHz	20 mVpp-6 Vpp (high impedance); 10 mVpp-3 Vpp (50 Ω)	± 3 V (high impedance); ± 1.5 V (50 Ω)
Square wave	Frequency/cycle, amplitude/high level, DC offset/low level, phase ($\pm 360^\circ$), duty ratio (1%-99%)	1 μ Hz-15 MHz	20 mVpp-6 Vpp (high impedance); 10 mVpp-3 Vpp (50 Ω)	± 3 V (high impedance); ± 1.5 V (50 Ω)
Ramp wave	Frequency/cycle, amplitude/high level, DC offset/low level, phase ($\pm 360^\circ$), symmetry (0.1%-99.9%)/pulse width	1 μ Hz-400 kHz	20 mVpp-6 Vpp (high impedance); 10 mVpp-3 Vpp (50 Ω)	± 3 V (high impedance); ± 1.5 V (50 Ω)
Pulse wave	Frequency/cycle, amplitude/high level, DC offset/low level, phase ($\pm 360^\circ$), pulse width/ duty ratio (1%-99%), rising, falling edge	1 μ Hz-15 MHz	20 mVpp-6 Vpp (high impedance); 10 mVpp-3 Vpp (50 Ω)	± 3 V (high impedance); ± 1.5 V (50 Ω)
Arbitrary wave	Frequency/cycle, amplitude/high level, DC offset/low level, phase ($\pm 360^\circ$)	1 μ Hz-5 MHz	20 mVpp-6 Vpp (high impedance); 10 mVpp-3 Vpp (50 Ω)	± 3 V (high impedance); ± 1.5 V (50 Ω)
Noise	Amplitude/high level, DC offset/low level		20 mVpp-6 Vpp (high impedance); 10 mVpp-3 Vpp (50 Ω)	± 3 V (high impedance); ± 1.5 V (50 Ω)
DC	DC			± 3 V (high impedance); ± 1.5 V (50 Ω)

(2) Frequency

When Gen is switched on, the instrument will configure a default sine wave with a frequency of 1 kHz and an amplitude of 100 mVpp. Double-click on the “Frequency” input field to open the

numeric keypad to set the frequency. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the frequency.

(3) Amplitude

The default waveform is a sine wave with an amplitude of 100 mVpp. Double-click on the “Amplitude” to open the numeric keypad to set the amplitude. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the amplitude.

(4) DC Offset

The default DC offset of waveform is 0 V. Double-click on the “DC Offset” to open the numeric keypad to set the DC offset. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the DC offset.

(5) Phase

The default phase of waveform is 0°. Double-click on the “Phase” to open the numeric keypad to set the phase. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the phase.

(6) Duty Ratio of Pulse Wave

The default frequency is 1 kHz, and the duty ratio is 50% of the pulse wave. Double-click on the “Duty Ratio” to open the numeric keypad to set the duty ratio. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the duty ratio.

(7) Rising/Falling Time

The default rising/falling time is 12 of the pulse waves. Double-click on the “Rising/Falling time” to open the numeric keypad to set the rising/falling time. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the rising/falling time.

(8) Ramp Symmetry

The default symmetry of ramp wave is 50%. Double-click on the “Symmetry” to open the

numeric keypad to set the symmetry. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the symmetry.

28.3. Advanced Application


Gen can output amplitude modulation (AM), frequency modulation (FM), amplitude shift keying (ASK), frequency shift keying (FSK), and sweep. Press the Gen on the front panel to open the function/arbitrary waveform generator, and enter the Gen setting menu to set decode, and select the modulation type through the "Output type". Take G1 as an example to introduce.

(1) Amplitude Modulation (AM)

In AM, the modulation waveform consists of carrier wave and modulation wave. The amplitude of carrier waves will change with the amplitude of modulation waves.

a. Enable AM

In G1 menu, select "Output Type" to "AM". Configure the parameters for the carrier wave and AM as shown in the following figure.



b. Select Carrier Wave

Click on the "Carrier Wave" to select sine, square, ramp, or arbitrary wave.

■ Carrier Wave Setting

Once the carrier wave for AM is selected, each parameter can be configured. For the

carrier wave setting, refer to the section of [Carrier Waveform](#).

c. Modulation Wave Setting

Modulation wave: sine, square, square, rising ramp, falling ramp, arbitrary, and noise wave. The default is sine wave. Once AM is enabled, the modulation wave displays the sine wave. Click on the “Modulation Wave” to change the modulation wave type. For details on the modulation wave, refer to the following table.

Modulation Wave	Description
Square wave	Duty ratio is 50%.
Rising ramp	Symmetry is 100%.
Falling ramp	Symmetry is 0%.
Arbitrary wave	Use automatic sampling to limit the arbitrary wavelength at 4 kpts.
Noise	White Gaussian noise

■ Modulation Frequency

The modulation frequency range is 2 MHz - 50 kHz (default 100 Hz). Once AM is enabled, the default modulation frequency will be displayed. Double-click on the “Modulation Frequency” input field to open the numeric keypad to set the modulation frequency. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the [Multipurpose B](#) rotary knob to move the selected cursor, and use the [Multipurpose A](#) rotary knob to adjust the modulation frequency.

■ Modulation Depth

The modulation depth indicates the change of amplitude, expressed in percentage. AM modulation depth is from 0% to 120%. The default is range is 100%. Double-click on the “Modulation Depth” input field to open the numeric keypad to set the modulation depth. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the [Multipurpose B](#) rotary knob to move the selected cursor, and use the [Multipurpose A](#) rotary knob to adjust the modulation depth.

- When the modulation depth is 0%, it outputs a constant amplitude (half the amplitude of the carrier wave amplitude).
- When the modulation depth is 100%, the output amplitude is change with the modulation wave.
- When the modulation depth is greater than 100%, the output amplitude will not over


than 10 V_{pp} (the load is 50 Ω).

(2) Frequency Modulation (FM)

In FM, the modulation waveform consists of carrier wave and modulation wave. The frequency of carrier waves will change with the amplitude of modulation waves.

a. Enable FM

In G1 menu, select “Output Type” to “FM”. Configure the parameters for the carrier wave and FM as shown in the following figure.



b. Select Carrier Wave

Click on the “Carrier Wave” to select sine, square, ramp, or arbitrary wave.

■ Carrier Wave Setting

Once the carrier wave for FM is selected, each parameter can be configured. For the carrier wave setting, refer to the section of [Carrier Waveform](#).

c. Modulation Wave Setting

Modulation wave: sine, square, square, rising ramp, falling ramp, arbitrary, and noise wave. The default is sine wave. Once FM is enabled, the modulation wave displays the sine wave. Click on the “Modulation Wave” to change the modulation wave type. For details on the modulation wave, refer to the following table.

Modulation Wave	Description
Square wave	Duty ratio is 50%.
Rising ramp	Symmetry is 100%.

Falling ramp	Symmetry is 0%.
Arbitrary wave	Use automatic sampling to limit the arbitrary wavelength at 4 kpts.
Noise	White Gaussian noise

■ Modulation Frequency

The modulation frequency range is 2 mHz-50 kHz (default 100 Hz). Once FM is enabled, the default modulation frequency 100 Hz will be displayed. Double-click on the “Modulation Frequency” input field to open the numeric keypad to set the modulation frequency. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the modulation frequency.

■ Frequency Offset

The frequency offset indicates the offset of the frequency of the FM-modulated waveform relative to the carrier frequency, and the FM frequency offset can be set from the minimum DC to half the maximum current carrier bandwidth, and the default frequency offset is 100 Hz. Double-click on the “Frequency Offset” input field to open the numeric keypad to set the frequency offset. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the frequency offset. The maximum frequency offset is 12.5 MHz.

- Frequency offset \leq Carrier frequency, if the frequency offset is greater than the carrier frequency, the instrument will automatically limit the frequency offset to the maximum of the current carrier frequency.
- The sum of frequency offset and carrier frequency \leq Maximum frequency of the current carrier wave, if the frequency offset is set to an invalid value, the instrument will automatically limit the frequency offset to the maximum of the current carrier frequency.


(3) Output Arbitrary Wave

This oscilloscope has saved 200 arbitrary waves. For details, refer to Built-in Arbitrary Wave Table.

■ Enable Arbitrary Wave Function

Click on the “Continuous” to select “Arbitrary Wave” to enable this function. The instrument

will output the arbitrary wave according to the current setting, as shown in the following figure.



■ Select Arbitrary Wave

The user can select the local built-in arbitrary wave or external arbitrary wave. Once the arbitrary wave is enabled, double-click on the “Arbitrary Wave” to select the required arbitrary wave.


Load the saved waveform from Gen, which includes common waveforms, mathematical waveforms, segmented modulation, biological waveforms, medical waveforms, automotive waveforms, engineering waveforms, window functions, trigonometric functions, inverse trigonometric functions, noise, and more. The specific content of the list please refer to [Appendix B Built-in Arbitrary Wave Table](#).

(4) Amplitude Shift Keying (ASK)

In amplitude shift keying (ASK), digital signals “0” and “1” are represented by varying the amplitude of the fundamental signal. The system outputs different amplitudes based on the logic level of the modulating signal. The modulation modes of each channel are independent of one another, allowing users to configure either the same or different modulation modes for each channel.

a. Enable ASK

In G1 menu, select “Output Type” to “ASK”. Configure the parameters for the carrier wave and ASK as shown in the following figure.



b. Select Carrier Wave

Click on the “Carrier Wave” to select sine, square, ramp, or arbitrary wave.

■ Carrier Wave Setting

Once the carrier wave for ASK is selected, each parameter can be configured. For the carrier wave setting, refer to the section of [Carrier Waveform](#).

c. Modulation Wave Setting

The modulation speed should be configured.

■ Modulation Speed


Once the ASK is enabled, the modulation speed should be configured. Double-click on the “Modulation Speed” input field to open the numeric keypad to set the modulation speed. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the [Multipurpose B](#) rotary knob to move the selected cursor, and use the [Multipurpose A](#) rotary knob to adjust the modulation speed.

(5) Frequency Shift Keying (FSK)

In frequency shift keying (FSK), the function/arbitrary waveform generator can be configured to switch between two preset frequencies: the fundamental frequency and the hopping frequency. Depending on the logic state of the modulating signal, either the fundamental frequency or the hopping frequency is output. The modulation modes for each channel are independent, allowing users to configure the same or different modulation modes for each channel.

a. Enable FSK

In G1 menu, select “Output type” to “FSK”. Configure the parameters for the carrier wave and FSK as shown in the following figure.



b. Select Carrier Wave Setting

Click on the “Carrier Wave” to select sine, square, ramp, or arbitrary wave.

■ Carrier Wave

Once the carrier wave for FM is selected, each parameter can be configured. For the carrier wave setting, refer to the section of [Carrier Waveform](#).

c. Modulation Wave Setting

The hopping frequency and rate should be configured.

■ Hopping Frequency

Once FSK is enabled, the default hopping frequency 100 Hz will be displayed.

Double-click on the “Hopping Frequency” input field to open the numeric keypad to set the hopping frequency. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the [Multipurpose B](#) rotary knob to move the selected cursor, and use the [Multipurpose A](#) rotary knob to adjust the hopping frequency. The setting range for the hopping frequency is determined by the carrier wave. For the specific setting range of each carrier wave, refer to the section of [Carrier Waveform](#).

■ Rate

Once FSK is enabled, the default rate 100 Hz will be displayed. Double-click on the


“Rate” input field to open the numeric keypad to set the rate. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the rate.

(6) Sweep

When the sweep mode is selected, the output frequency of the Function/Arbitrary Waveform Generator varies linearly or logarithmically from the start frequency to the stop frequency within the specified sweep time. The generator can produce Sine, Square, Ramp, Pulse, and Arbitrary waveforms (excluding DC) as sweep outputs. The sweep modes for each channel operate independently, allowing you to configure the same or different sweep modes for each channel.

a. Enable Sweep

In G1 menu, select “Output type” to “Sweep”. Configure the parameters for the carrier wave and sweep as shown in the following figure.



b. Select Carrier Wave Setting

Click on the “Carrier Wave” to select sine, square, ramp, or arbitrary wave.

■ Carrier Wave Setting

Once the carrier wave for sweep is selected, each parameter can be configured. For the carrier wave setting, refer to the section of [Carrier Waveform](#).

c. Sweep Setting

The start frequency, stop frequency, and sweep time should be configured.

■ Sweep Type

The function/arbitrary waveform generator supports two types of sweeps: linear and logarithmic

- ① Linear Sweep: The waveform generator changes the output frequency linearly throughout the sweep.
- ② Logarithmic Sweep: The waveform generator changes the output frequency logarithmically during the sweep.

■ Start Frequency, Stop Frequency

The start frequency and stop frequency represent the lower and upper limits of the frequency scan. The function/arbitrary waveform generator always sweeps from the start frequency to the stop frequency and then returns to the start frequency.

Double-click on the “Start Frequency/ Stop Frequency” input field to open the numeric keypad to set the frequency. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the rate frequency.

- ① When the start frequency < stop frequency, the function/arbitrary waveform generator scans from low frequency to high frequency.
- ② When the start frequency > stop frequency, the function/arbitrary waveform generator scans from high frequency to low frequency.
- ③ When the start frequency = stop frequency, the function/arbitrary waveform generator outputs a fixed frequency.


By default, the start frequency is set to 1 kHz and the stop frequency to 2 kHz. However, the range of configurable starting and stopping frequencies varies for different sweep waveforms. Amplitude modulation for the frequency setting ranges of each sweep waveform, refer to the section of [Carrier Waveform](#).

■ Sweep Time

Set the time required to sweep from the start frequency to the stop frequency. The default is 1 second, with a configurable range of 1 ms to 500 s. Double-click on the “Sweep Time” input field to open the numeric keypad to set sweep time. For details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#).

Alternatively, select the parameter, use the Multipurpose B rotary knob to move the selected cursor, and use the Multipurpose A rotary knob to adjust the sweep time.

29. Toolbar

Click on the Home icon  at the top-right of the screen of the screen, click the “Edit” key at the bottom to enter the toolbar menu. The toolbar allows you to edit, delete, and adjust shortcut menu icons.



(1) Add toolbar

The toolbar contains all the function icon that can be added to the toolbar. Click to select the function to be added to the toolbar, click it again to deselect. The selected icon displays ✓ at the top-right of the screen. A maximum of 9 function icons can be added to the toolbar.

(2) Sequence

In the toolbar pop-up box, the function menu added to the toolbar can be adjusted by dragging the corresponding icons left and right, to adjust the order of the icons displayed in the toolbar.

(3) Default setting

By default, MSO5000HD toolbar displays 5 icons: Zone drawing, Cursor, Measurement, Zone Histogram, and Search.

(4) Delete

Delete all the menus from the toolbar.

30. Region Histogram





The histogram performs probability statistics on the vertical and horizontal directions of the waveform, allowing for jitter analysis and signal integrity analysis.


Jitter analysis: The histogram plays a crucial role in jitter analysis. By using histograms, we can statistically analyze the range and distribution of many data samples, thereby verifying the performance and quality of the product, as well as identifying and diagnosing intermittent issues. Histograms are especially useful for analyzing random events such as noise or jitter, as they help in the analysis and verification of jitter.

Signal integrity analysis: In signal integrity analysis, histograms are used to display the amplitude distribution of the signal. By observing the histogram, we can assess the stability and quality of the signal, promptly detect any abnormal values or fluctuations in the signal and ensure its integrity and reliability.

The histogram includes both vertical and horizontal histograms, with the window divided into multiple rows and columns. When the histogram is opened, the default measurement window size is ± 2 div (vertical/horizontal). Click on the histogram measurement window and drag it to move its position.

The region histogram can be entered using the following steps.

- Click the Home icon  at the top-right of the screen and select the region histogram icon  to enter the region histogram menu.
- If the region histogram is added to the toolbar, click the region histogram icon  to enter the region histogram menu.
- When the region histogram pop-up box is opened, click the icon  to enter the region histogram menu.



(1) Switch

Click on the “On/Off” switch to toggle the histogram function to on or off.

(2) Type

Click on the “Type” to select the histogram statistic type.

- Horizontal: Divides the limit window into multiple columns and displays the number of triggers in each column as a histogram at the bottom of the grid.
- Vertical: Splits the limit window into rows and displays the number of triggers in each row as a histogram on the left side of the grid.

(3) Source

Click on the “Source” down menu to select the source for histogram statistical analysis. The available source channels are analog channels C1 to C4.

(4) Histogram Statistics

Click the “On/Off” switch to toggle the statistics function to on or off.

- ON: The histogram statistics pop-up box is displayed.
- OFF: The histogram statistics pop-up box is not displayed.

(5) Histogram Boundary

The histogram measurement window allows you to set the left/right and upper/lower boundaries. When the histogram is opened, a default histogram area is generated. There are two methods to set the boundaries.

- In the histogram pop-up box, select the input boxes for “Left Boundary”, “Right Boundary”, “Upper Boundary”, and “Lower Boundary.” Rotate the Multipurpose A knob on the front panel to modify the boundary values. This operation is suitable for fine-tuning the boundaries to fit the screen area.


- Select the four histogram boundaries and drag them to modify the size of the measurement window. This operation is more suitable for coarse adjustments of the boundaries.

(6) Default Window

Click on the “Default Window” to set the histogram measurement window to ± 2 div vertically and ± 2 div horizontally.

(7) Reset

Click on the “Reset” key will zero out the histogram statistics and restart the counting.



The visual component of the histogram is a bar graph displayed to the left of the vertical waveform histogram or at the bottom of the horizontal waveform histogram. As waveforms are acquired and displayed, or as measurements are made, the size of the bar graph changes to reflect the peaks of the triggered quantities within the specified histogram size.

(8) Histogram Statistical Results

The results of the histogram data are displayed in the Histogram Statistics pop-up box, which can be opened to view the statistics.

- Sample: The total number of samples that fall within the histogram area.
- Peaks: The number of samples that fall within the highest bar area.
- Max: The maximum value in the sample.
- Min: The minimum value in the sample.
- Pk-Pk: The difference between the maximum and minimum values.
- Mean: The average of all statistical samples (mathematical expectation).

- Median: The value that divides the histogram into two equal parts, each containing the same number of samples.
- Mode: The most frequently occurring data value in the statistical sample.
- Bin Width: The width of each bar in the histogram, representing the width of a column.
- Sigma: The standard deviation (σ) of all statistical samples.


31. Help System

The help system provides information about the function keys (including menu keys) on the front panel.

The help system can be entered using the following steps.

- In Home menu, click on the help icon “?” to enter the help menu.
- In each function menu popup, click on the help icon “?” in the top right to open the relevant help menu.

The help screen is divided into two parts, the left side is “Help Options”, and the right side is “Help Display Area”. By selecting a help option, the user can view all related help content on the right.




32. Notification Setting

Click on the notification area at the bottom of the screen to enter the time setting and file browser setting.



32.1. Time Setting

Click on the time at the bottom of the screen to open the “Time Setting” pop-up box.



(1) Automatically Set Time

Click on the “Auto Time” to switch on/off the setting. The automatic set time can only be synchronized to Beijing time when the oscilloscope is connected to the network. If it is not connected to the network, the time will be based on the current set time.

(2) Time Zone

Click on the “Time Zone” input field, and rotate the Multipurpose A rotary knob on the front panel to change the time zone. Alternatively, double-click on the “Time Zone” input field to open the numeric keypad to enter the time zone. For the details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). The time zone can be set from -11 to 12.

(3) Month

Click on the “Month” input field, and rotate the Multipurpose A rotary knob on the front panel to change the month. Alternatively, double-click on the “Month” input field to open the numeric

keypad to enter the month. For the details on the use of the numeric keypad, refer to the section of [5.8 Parameter Setting](#). The time zone can be set from 1 to 12.

(4) Year

Click to select the “Year” input field, then rotate the Multipurpose knob on the front panel to modify the year value. Alternatively, double-click the “Year” input field to pop up the numeric keyboard to enter the year. For the details on the use of the numeric keyboard, refer to the section of [5.8 Parameter Setting](#). The year can be set from 2000 to 2050.

(5) Date

Click on the “Date” at the bottom of the screen to set the date, the selected date is displayed in blue.

(6) Time

Click on the “Time” to scroll the two dial plates to set the current time or click and scroll the hour (on the left), minute (on the right) to set the current time. Click on the blank area to complete the time setting.


32.2. File Browser

Click on the USB icon at the bottom right to directly enter the file browser. For the details on the use of the file browser, refer to the section of [File Browser](#).

33. Additional Function Key

- [Automatic Setting](#)
- [Run/Stop](#)
- [Clear Setting](#)
- [Factory Setting](#)


33.1. Automatic Setting


Automatic settings will choose an appropriate time base scale, amplitude scale and trigger parameter according to the input signal so that the waveform will automatically display on the screen. Press the  key on the front panel to enable automatic settings.

Automatic setting only applies to the following conditions.


- a. Automatic setting is only suitable for simple single frequency signals. It is impossible to achieve an effective automatic setting for complex combination waves.
- b. The measured signal frequency is not less than 10 Hz, and the amplitude is not less than 12 mVpp; the duty cycle of square wave is greater than 5%.

33.2. Run/Stop

Use the  key on the front panel to set. If the green light is on after the key is pressed, it indicates the RUN state. If the red light is on after the key is pressed, it is the STOP state.

In the running state, the oscilloscope is continuously acquiring waveform and the upper part of the screen shows "AUTO"; in the stop state, the oscilloscope stops the acquisition and the upper part of the screen shows "STOP". Press the  key to switch the waveform sampling between the run and stop states.

33.3. Clear Setting

Press the Clear icon  on the front panel to reset. This will clear all reloaded waveforms and parameter statistics.

33.4. Factory Setting

Press the **Default** key on the front panel, the oscilloscope can quickly restore to the factory setting. The factory settings of MSO5000HD series high-resolution oscilloscopes are listed in the following table.

System	Function	Factory Setting
Vertical System	CH1	200 mV/div
	Vertical offset	0 (Vertical midpoint)
	Offset	0 (Vertical midpoint)
	Coupling	DC
	Bandwidth limit	Full bandwidth
	Volts/div scale	Coarse tuning
	Probe	1×
	Inverse Phase	OFF
	Unit	V
	CH2, CH3, CH4	OFF
	MATH, FFT, REF, Digital	OFF
Horizontal System	Extension window	OFF
	Fine tuning	Coarse tuning
	Horizontal extension	Center
	Auto roll mode	Yes
	Mode	YT
	Source X-Y	C1-C2
	Horizontal time base	1 μ s/div
	Horizontal offset	0 (Horizontal midpoint)
Trigger System	Trigger type	Edge
	Trigger polarity 1	Rising edge
	Coupling mode	DC
	Level	0 V
	Trigger mode	Auto
	Trigger holdoff	80ns
	Source 1	C1
	Noise suppression	OFF
Sampling system	Acquisition mode	Normal
	Memory depth	Auto

	Interpolation	sinc
Display	Display format	Vector
	Grid display	Full display
	Transparence of pop-up window	50%
	Backlight brightness	50%
	Persistence	Auto
	Stop persistence	Not check
	Temperature color	OFF
	Grid brightness	50%
	Waveform brightness	50%
MATH	Type	Basic operation
	Source A	C1
	Operator	+
	Source B	C1
	Vertical scale	200 mV
	Vertical position	0 V
	Label state	OFF
FFT	FFT window function	Hanning
	FFT unit	dB
	FFT count	8 k
	Waterfall curve	OFF
Measurement	Parameter snapshot	OFF
	Parameter measurement	OFF
	Measurement statistical	OFF
	Voltmeter	OFF
	Counter	OFF
	Indicator	OFF
Bus Decoding	Decoding type	RS232
	Bus state	OFF
	Display format	Hexadecimal
	Event list	OFF
	Bus position	0
	RS232 source	C1

	RS232 polarity	Positive
	RS232 bitrate	100 bps
	RS232 bit width	5 bits
	RS232 bit sequence	LSB
	RS232 stop bit	1 bit
	RS232 parity bit	None
Digital	D7 - D0 display	OFF
	D15 - D8 display	OFF
	D7 - D0 threshold	TTL
	D15 - D8 threshold	TTL
	Bit sequence	LSB
	Jitter time	5 ns
Other System	Square wave output	1 kHz
	Synchronized output	Idle
	IP	DHCP
	Language	Current language
	Cursor type	OFF
	Horizontal cursor	Fixed delay
	Synchronized move	OFF
	Automatically set channel	Autoset
	Automatically set sampling	Autoset
	Automatically set trigger	Autoset
	Automatically set signal	Autoset
	Select channel	C1
	RUN/STOP	RUN

34. System Prompt and Troubleshooting

- [System Prompt](#)
- [Troubleshooting](#)

34.1. System Prompt

This chapter describes the system prompts, with detailed explanations provided in the table below.

Touch function locked.	This prompt appears when the touchscreen is locked.
Touch function unlocked.	This prompt appears when the touchscreen is unlocked.
USB flash drive is inserted.	This prompt appears when a USB flash drive is successfully inserted.
USB flash drive is removed.	This prompt appears when a USB flash drive is successfully removed.
Save path:	This prompt appears when waveform, image, setting file, decoding list, or Bode plot list (csv, pdf, html) is successfully saved.
Activation successful	This prompt appears when an option is activated again.
No activation file!	This prompt appears when a USB flash drive is inserted but contains no corresponding activation file.
Autoset is completed.	This prompt appears when Autoset is completed.
Frequency too low, please check!	This prompt appears when no signal is applied during power analysis.
Fine Tuning: On	This prompt appears when fine tuning for volts/div, time base is turned on.
Fine Tuning: Off	This prompt appears when fine tuning for volts/div, time base is turned off.
System upgrade is succussed.	This prompt appears when the system upgrade is succussed.
10 MHz synchronization successful.	This prompt appears when 10 MHz synchronization input is successful.
Automatically adjusting memory depth according to	This prompt appears when setting oscilloscope memory depth while opening FFT.

FFT Points	
Load is succussed.	This prompt appears when setting files are successfully loaded.
Creation Successful.	This prompt appears when a folder is successfully created in the file browser.
Please select a file.	This prompt appears when renaming, copying, deleting, importing REF files, loading test templates, loading Bode plot CSV data, or selecting arbitrary waveform with no content selected.
Deletion Successful.	This prompt appears when a file is successfully deleted.
Copy Successful.	This prompt appears when a file is successfully copied.
Renaming Successful.	This prompt appears when a file is successfully renamed.
Paste Successful.	This prompt appears when a file is successfully pasted.
Activated.	This prompt appears when an option is activated.
Function in trial mode; for long-term use, please purchase an activation code!	This prompt appears when using an option during the trial period.
Function not activated; please purchase an activation code!	Function not activated; please purchase an activation code!
Auto-calibration completed.	This prompt appears when auto-calibration is completed.
Auto-calibration exited.	This prompt appears when exiting during the auto-calibration process.
Digital calibration completed.	This prompt appears when digital calibration is completed.
Digital calibration exited.	This prompt appears when exiting during the digital calibration process.
Delete this file?	This prompt appears when prompting to delete a file.
File already exists; do you want to overwrite it?	This prompt appears when saving a file but a file with the same name already exists in the specified path.
Already adjusted to the limit!	This prompt appears when adjustments have reached the limit and cannot be continued. This occurs when adjusting the vertical scale factor, time

	base, horizontal position, vertical position, and trigger level to their limits.
No valid data!	This prompt appears when loading a REF file that contains errors.
This prompt appears when loading a REF file that contains errors.	This prompt appears when opening FFT and entering SCAN or ROLL modes.
AWG channel overloaded; please check the circuit!	This prompt appears when the AWG is overloaded with a power signal.
Analog channel overloaded; please check the circuit!	This prompt appears when analog channels C1 - C4 are overloaded with a power signal.
This prompt appears when analog channels C1 - C4 are overloaded with a power signal.	This prompt appears when input exceeds the maximum length in the letter or number keyboard.
10 MHz synchronization clock input not detected!	This prompt appears when the 10 MHz synchronization signal is not connected.
Digital probe not inserted!	This prompt appears when the digital probe is not connected, and the digital display is opened.
Signal source not opened; please open it and try again!	This prompt appears when the signal source is not opened during waveform saving operations.
USB drive not inserted!	This prompt appears when the USB drive is not connected for option activation or full activation operations.
This prompt appears when the USB drive is not connected for option activation or full activation operations.	This prompt appears when the USB drive is not connected for option activation or full activation operations.
The current fundamental wave does not support the selected modulation; switching to a supported fundamental wave!	This prompt appears when a non-supported modulation fundamental wave is selected in continuous wave mode.
Too many parameters; please delete measurement items first!	This prompt appears when 27 custom parameters are added in Measure, and an attempt is made to add more.
Digital probe inserted!	Digital probe inserted!
Digital probe removed!	This prompt appears when the digital probe is disconnected.
This function is not supported	This prompt appears when attempting to record

in average sampling mode!	waveforms in average sampling mode.
Input channel has no signal!	This prompt appears when there is no signal connected during the Autoset operation.
Waveform recording function is not supported in the current mode!	This prompt appears when attempting to record waveforms in ROLL/SCAN mode.
This operation is prohibited during waveform recording!	This prompt appears when attempting to modify time base settings, vertical position, open FFT, open XY, or expand windows during waveform recording.
Time base setting is not in the recommended range; bandwidth limitation may be inaccurate!	This prompt appears when adjusting time base settings for custom bandwidth.
Disk is full.	This prompt appears when there is insufficient disk space to continue saving content.
Expression error.	This prompt appears when there is an error in mathematical expressions input for advanced calculations.
Upgrade failed.	Upgrade failed.
Fundamental wave type error.	This prompt appears when an unsupported fundamental wave type is selected for amplitude modulation, frequency modulation, amplitude shift keying, frequency shift keying, or sweeping.
Loading failed.	This prompt appears when loading a template fails during testing.
Paste failed.	This prompt appears when the copied file has been deleted and a paste operation is attempted.
Directory does not exist.	This prompt appears when the corresponding file cannot be found in the import file path due to the directory being deleted.
No upgrade file.	This prompt appears when there is no upgrade file available for the upgrade operation.
Parameter error.	This prompt appears when Gen parameters are set to their limit values during channel copy operations.
Invalid address.	This prompt appears when manually setting the IP address, subnet mask, or gateway incorrectly.
File name is empty.	This prompt appears when there is no content entered in the file name input box.
Please pause before saving the	This prompt appears when attempting to save a

waveform in ROLL/SCAN mode!	waveform in ROLL/SCAN mode.
Already at the latest version!	Already at the latest version!
Incorrect upgrade package!	This prompt appears when an incorrect upgrade file is selected for the upgrade process.
Please use the navigation in Stop mode!	This prompt appears when entering the navigation function while in Run mode.

34.2. Troubleshooting

- (1) If the oscilloscope remains on a black screen without any display when pressing the power soft key.
 - a. Check if the power plug is properly connected and the power supply is normal.
 - b. Check if the power switch is turned on. If the power switch is turned on, the power soft key on the front panel should be green. When the power soft key is enabled, the power soft key should be blue, and the oscilloscope will make an active sound. There should be a normal relay rattle when the soft switch key is pressed.
 - c. If the relay has sound, it indicates that the oscilloscope is normal boot-up. Press the Default key and press the “Yes” key, if the oscilloscope returns to normal, indicating that the backlight brightness is set too low.
 - d. Restart the oscilloscope after completing the above steps.
 - e. If the product still does not work properly, contact the UNI-T Service Center for assistance.
- (2) After signal acquisition, the waveform of the signal does not appear on the screen.
 - a. Check whether probe and DUT are connected properly.
 - b. Check whether the signal output channel is open.
 - c. Check whether the signal connecting line is connected to analog channel.
 - d. Check whether the signal source has DC offset.
 - e. Plug out the connected signal, to check whether the base line is within the screen range (If not, please perform self-calibration).
 - f. If the product still does not work properly, contact the UNI-T Service Center for assistance.
- (3) The measured voltage amplitude value is 10 times larger or 10 times smaller than the actual value.

Check whether the channel's probe attenuation coefficient setting matches the attenuation rate of the connected probe.
- (4) There is a waveform display but not stable.

- a. Check the trigger settings in trigger menu whether is consistent with the actual signal input channel.
 - b. Check the trigger type: the general signals should use "Edge" trigger. The waveform can only be displayed stably if the trigger mode is set correctly.
 - c. Try to change trigger coupling to HF rejection or LF rejection, to filter out the high-frequency or low-frequency noise that interfere with the trigger.
- (5) No waveform is displayed after pressing the **Run/Stop** key.
- a. Check whether the trigger mode is set to "Normal" or "Single" and verify if the trigger level exceeds the waveform range.
 - b. If the trigger mode is normal or single and the trigger level is in the center, set the trigger mode to Auto.
 - c. Press the **Autoset** key to automatically complete the above settings.
- (6) Waveform refresh is very slow.
- a. Check whether the acquisition method is set to "Average" and if the average times are large.
 - b. Check whether the memory depth is maximum.
 - c. Check whether the trigger holdoff is large.
 - d. Check whether it is normal trigger and is slow time base.
 - e. All the above will lead to slow waveform refresh, it is recommended to restore the factory settings, then the waveform can be refreshed normally.

35. Appendix

35.1. Appendix A Maintenance and Cleaning

(1) General Maintenance

Keep the instrument away from the direct sunlight.

Caution: Keep sprays, liquids and solvents away from the instrument or probe to avoid damaging the instrument or probe.

(2) Cleaning

Check the instrument and probe frequently according to the operating condition. Follow these steps to clean the external surface of the instrument:

- a. Please use a soft cloth to wipe the dust outside the instrument.
- b. When cleaning the LCD screen, please pay attention and protect the transparent LCD screen.
- c. When cleaning the dust screen, use a screwdriver to remove the screws of the dust cover and then remove the dust screen. After cleaning, install the dust screen in sequence.
- d. Please disconnect the power supply, then wipe the instrument with a damp but not dripping soft cloth. Do not use any abrasive chemical cleaning agent on the instrument or probes.

Warning: Please confirm that the instrument is completely dry before use, to avoid electrical shorts or even personal injury caused by moisture.

35.2. Appendix B Built-in Arbitrary Wave Table

Type	Name	Description
Common function (15)	AbsSine	Absolute sine wave
	AbsSineHalf	Absolute half-sine wave
	AmpALT	Amplify sine wave
	AttALT	Attenuates sine wave
	Gaussian_monopulse	Gaussian monocycle
	GaussPulse	Gaussian pulse
	NegRamp	Falling ramp
	NPulse	N-Pulse signal
	PPulse	P-Pulse signal
	SineTra	TraSine wave signal
	SineVer	VerSine wave signal
	StairUD	Stair up and down
	StairDn	Stair down
	StairUp	Stair up
	Trapezia	Trapezoid
Engine (25)	BandLimited	Band limited signal
	BlaseiWave	Vibration of blasting “time-vibration velocity” curve
	Butterworth	Butterworth filter
	Chebyshev1	Chebyshev filter I
	Chebyshev2	Chebyshev filter II
	Combin	Combined function
	CPulse	C-Pulse signal
	CWPulse	CW pulse signal
	DampedOsc	Damped oscillation “time-offset” curve
	DualTone	Double audio signal
	Gamma	Gamma signal
	GateVibar	Gate self-oscillation signal
	LFMPulse	Linear FM pulse signal
	MCNoise	Mechanical noise
	Discharge	Ni-MH battery discharge curve
	Pahcur	Brushless DC motor current wave

	Quake	Quake wave
	Radar	Radar signal
	Ripple	Power ripple
	RoundHalf	Half round wave
	RoundsPM	RoundsPM wave
	StepResp	Step response signal
	SwingOsc	Swing oscillation - time curve
	TV	Television signal
	Voice	Voice signal
Maths (27)	Airy	Airy function
	Besselj	Besselj function I
	Besselk	Besselk function
	Bessely	Besselj function II
	Cauchy	Cauchy distribution
	Cubic	Cubic function
	Dirichlet	Dirichlet function
	Erf	Error function
	Erfc	Complementary error function
	ErfcInv	Inverse complementary error function
	ErfInv	Inverse error function
	ExpFall	Exponential falling function
	ExpRise	Exponential rising function
	Gammaln	Natural logarithm of Gamma function
	Gauss	Gaussian distribution (Normal distribution)
	HaverSine	Haversed sine
	Laguerre	Quartic Laguerre polynomial
	Laplace	Laplace distribution
	Legend	Quintic Legendre Polynomials
	Log10	Logarithm function based on 10
	LogNormal	Logarithmic normal distribution
	Lorentz	Lorentzian function
	Maxwell	Maxwell distribution
	Rayleigh	Rayleigh distribution
	Versiera	Versiera

	Weibull	Weibull distribution
	ARB_X2	Square function
SectMod (5)	AM	Sine wave amplitude modulation
	FM	Sine wave frequency modulation
	PFM	Pulse wave modulation
	PM	Sine wave phase modulation
	PWM	Pulse width modulation
Bioelect (6)	Cardiac	Electrocardio signal
	EOG	Electro-oculogram
	EEG	Electroencephalogram
	EMG	Electromyography
	Pulseilogram	Sphygmus curve of common people
	ResSpeed	Expiration rate curve of common people
Medical (4)	LFPulse	Low frequency pulse electrotherapy waveform
	Tens1	Transcutaneous electric nerve stimulation waveform 1
	Tens2	Transcutaneous electric nerve stimulation waveform 2
	Tens3	Transcutaneous electric nerve stimulation waveform 3
Automotive (17)	Ignition	Ignition waveform of automobile internal-combustion engine
	ISO16750-2 SP	Profile map of automobile starting oscillation
	ISO16750-2 Starting1	Automobile starting voltage waveform 1
	ISO16750-2 Starting2	Automobile starting voltage waveform 2
	ISO16750-2 Starting3	Automobile starting voltage waveform 3
	ISO16750-2 Starting4	Automobile starting voltage waveform 4
	ISO16750-2 VR	Operating voltage profile map of automobile under resetting
	ISO7637-2 TP1	Transient phenomena of automobile caused by power cut

	ISO7637-2 TP2A	Transient phenomena of automobile caused by inductance in wiring
	ISO7637-2 TP2B	Transient phenomena of automobile caused by turning off start-up changer
	ISO7637-2 TP3A	Transient phenomena of automobile caused by conversion
	ISO7637-2 TP3B	Transient phenomena of automobile caused by conversion
	ISO7637-2 TP4	Working profile map of automobile under start-up
	ISO7637-2 TP5A	Transient phenomena of automobile caused by power cut of battery
	ISO7637-2 TP5B	Transient phenomena of automobile caused by power cut of battery
	SCR	SCR (sintering temperature distribution)
	Surge	Surge signal
Trigonome (21)	CosH	Hyperbolic cosine
	CosInt	Cosine integral
	Cot	Cotangent function
	CotHCon	Concave hyperbolic cotangent
	CotHPro	Convex hyperbolic cotangent
	CscCon	Concave cosine
	CscPro	Convex cosine
	CotH	Hyperbolic cotangent
	CscHCon	Concave hyperbolic cosecant
	CscHPro	Convex hyperbolic cosecant
	RecipCon	Reciprocal of the depression
	RecipPro	Reciprocal of the projection
	SecCon	The secant of the depression
	SecPro	The secant of the projection
	SecH	Hyperbolic secant
	Sinc	Sinc function
	SinH	Cotangent function
	SinInt	Sine integral
	Sqrt	Square root function

	Tan	Tangent function
	TanH	Hyperbolic tangent
AntiTrigonome (16)	ACosH	Arc-cosine function
	ACotCon	Arc- hyperbolic cosine function
	ACotPro	Arc- hyperbolic cosine function
	ACotHCon	Convex arc cotangent function
	ACotHPro	Concave arc- hyperbolic cosine function
	ACscCon	Convex arc- hyperbolic cosine function
	ACscPro	Concave arc cosecant function
	ACscHCon	Convex arc cosecant function
	ACscHPro	Concave arc hyperbolic cosecant function
	ASecCon	Convex arc hyperbolic cosecant function
	ASecPro	Concave arc secant function
	ASecH	Convex arc secant function
	ASin	Arc hyperbolic secant function
	ASinH	Arcsin function
	ATan	Arc hyperbolic sine function
	ATanH	Arctan function
Noise (6)	NoiseBlue	Blue noise
	NoiseBrown	Brown noise (red noise)
	NoiseGray	Gray noise
	NoisePink	Pink noise
	NoisePurple	Purple noise
	Noisewhite	White noise
Window function (17)	Bartlett	Bartlett window
	BarthannWin	Amended Bartlett window
	Blackman	Blackman window
	BlackmanH	BlackmanH window
	BohmanWin	Bohman window
	Boxcar	Rectangle window
	ChebWin	Chebyshev window
	GaussWin	Gaussian window

	FlatTopWin	Flat-top window
	Hamming	Hamming window
	Hanning	Hanning window
	Kaiser	Kaiser window
	NuttallWin	The minimum of four Blackman Harris window
	ParzenWin	Parzen window
	TaylorWin	Taylaor window
	Triang	Quarter window (Fejer window)
	TukeyWin	Tukey window
Complex Wavelets (7)	Complex Frequency B-spline	Complex Frequency B-spline function
	Complex Gaussian	Complex Gaussian function
	Complex Morlet	Complex Morlet wavelet
	Complex Shannon	Complex Shannon function
	Mexican hat	Mexican hat wavelet
	Meyer	Meyer wavelet
	Morlet	Morlet wavelet
Other (34)	ABA_1_1	
	ABA_1_2	
	ALT_03	
	ALT_04	
	ALT_05	
	AUDIO	
	COIL_2_1	
	COIL_2_2	
	DC_04	
	ECT_1_2	
	EGR_2	
	EGR_3_2	
	EST_03_2	
	IAC_1_1	
	INJ_1_1	
	INJ_2	
	INJ_3	
	INJ_4	

	INJ_5_6	
	INJ_7	
	KS_1_1	
	MAF_1_1	
	MAF_1_2	
	MAF_5_3	
	MAP_1_1	
	MAP_1_2	
	MC_3	
	Mexican hat	Mexican hat wavelet
	O2PROPA1	
	O2PROPA2	
	O2SNAP	
	STAR02_1	
	TPS_1_1	
	TPS_1_2	

Limited Warranty and Liability

UNI-T guarantees that the Instrument product is free from any defect in material and workmanship within three years from the purchase date. This warranty does not apply to damages caused by accident, negligence, misuse, modification, contamination, or improper handling. If you need a warranty service within the warranty period, please contact your seller directly. UNI-T will not be responsible for any special, indirect, incidental, or subsequent damage or loss caused by using this device. For the probes and accessories, the warranty period is one year. Visit instrument.uni-trend.com for full warranty information.



Learn more at: www.uni-trend.com



Register your product to confirm your ownership. You will also get product notifications, update alerts, exclusive offers and all the latest information you need to know.

UNI-T is the licensed trademark of UNI-TREND TECHNOLOGY (CHINA) CO., Ltd.

UNI-T products are protected under patent laws in China and internationally, covering both granted and pending patents. Licensed software products are the properties of UNI-Trend and its subsidiaries or suppliers, all rights reserved. This manual contains information that replaces all earlier published versions. The product information in this document subject to update without notice. For more information on UNI-T Test & Measure Instrument products, applications, or service, please contact UNI-T instrument for support, the support center is available on www.uni-trend.com ->instruments.uni-trend.com

<https://instruments.uni-trend.com/ContactForm/>

Headquarter

UNI-TREND TECHNOLOGY (CHINA)
CO., Ltd.
Address: No.6, Industrial North 1st
Road, Songshan Lake Park, Dongguan
City, Guangdong Province, China
Tel: (86-769) 8572 3888

Europe

UNI-TREND TECHNOLOGY EU GmbH
Address: Affinger Str. 12
86167 Augsburg Germany
Tel: +49 (0)821 8879980

North America

UNI-TREND TECHNOLOGY US
INC.
Address: 3171 Mercer Ave STE 104,
Bellingham, WA 98225
Tel: +1-888-668-8648