

USG3000M/5000M Series RF Analog Signal Generators

Quick Guide

This document applies to the following models: USG3000M series USG5000M series

V1.0 November 2024

Limited Warranty and Liability

UNI-T guarantees that the Instrument product is free from any defect in material and workmanship within three years from the purchase date. This warranty does not apply to damages caused by accident, negligence, misuse, modification, contamination, or improper handling. If you need a warranty service within the warranty period, please contact your seller directly. UNI-T will not be responsible for any special, indirect, incidental, or subsequent damage or loss caused by using this device. For the probes and accessories, the warranty period is one year. Visit instrument.uni-trend.com for full warranty information.



Scan to Download relevant document, software, firmware and more.



Register your product to confirm your ownership. You will also get product notifications, update alerts, exclusive offers and all the latest information you need to know.

LINI-T. is the licensed trademark of UNI-TREND TECHNOLOGY (CHINA) CO., Ltd.

UNI-T products are protected under patent laws in China and internationally, covering both granted and pending patents. Licensed software products are the properties of UNI-Trend and its subsidiaries or suppliers, all rights reserved. This manual contains information that replaces all earlier published versions. The product information in this document subject to update without notice. For more information on UNI-T Test & Measure Instrument products, applications, or service, please contact UNI-T instrument for support, the support center is available on www.uni-trend.com ->instruments.uni-trend.com

https://instruments.uni-trend.com/ContactForm/

Headquarter

UNI-TREND TECHNOLOGY (CHINA) CO., Ltd. Address: No.6, Industrial North 1st Road, Songshan Lake Park, Dongguan City, Guangdong Province, China Tel: (86-769) 8572 3888

Europe

UNI-TREND TECHNOLOGY EU GmbH Address: Affinger Str. 12 86167 Augsburg Germany Tel: +49 (0)821 8879980

North America

UNI-TREND TECHNOLOGY US INC. Address: 3171 Mercer Ave STE 104, Bellingham, WA 98225 Tel: +1-888-668-8648

Copyright $\ensuremath{\mathbb{C}}$ 2024 by UNI-Trend Technology (China) Co., Ltd. All rights reserved.

Chapter 1 Instructions Manual

This manual outlines the safety requirements, installment and the operation of USG5000 series RF analog signal generator.

1.1 Inspecting Packaging and List

When you receive the instrument, please check the packaging and list by the following steps.

- Check whether the packing box and padding material have been compressed or damaged by external forces and inspect the appearance of the instrument. If you have any questions about the product or need consulting services, please contact the distributor or local office.
- Carefully take out the article and check it with the packing instructions.

1.2 Safety Instructions

This chapter contains information and warnings that must be observed. Ensure that the instrument is operated under safe conditions. In addition to the safety precautions indicated in this chapter, you must also follow accepted safety procedures.

Safety Precautions							
Warning	Please follow these guidelines to avoid possible electric shock						
vvarining	and risk to personal safety.						
	Users must adhere to standard safety precautions during the operation,						
	servicing, and maintenance of this device. UNI-T will not be liable for any						
	personal safety and property loss caused by the user's failure following						
	the safety precautions. This device is designed for professional users and						
	responsible organizations for measurement purposes.						
	Do not use this device in any manner not specified by the manufacturer.						
	This device is intended for indoor use only, unless otherwise stated in the						
	product manual.						
Safety Statements							
	"Warning" indicates the presence of a hazard. It warns users to						
	pay attention to a certain operation process, operation method						
Warning	or similar. Personal injury or death may occur if the rules in the						
•••anning	"Warning" statement are not properly executed or observed. Do						
	not proceed to the next step until you fully understand and meet						
	the conditions stated in the "Warning" statement.						
Caution	"Caution" indicates the presence of a hazard. It warns users to						

	pay attention to a certain operation process, operation method											
	or similar. Product damage or loss of important data may occur											
	if the rules in the "Caution" statement are not properly executed											
	or observed	or observed. Do not proceed to the next step until you fully										
	understand	and meet the conditions stated in the "Caution"										
	statement.											
	"Note" indi	cates important information. It reminds users to pay										
Note	attention to	procedures, methods, and conditions, etc. The										
	contents of	"Note" should be highlighted if necessary.										
Safety Signs												
A	Danger	It indicates danger of electric shock, which may cause										
		personal injury or death.										
\wedge	Warning	It indicates that there are factors you should be cautious of										
		to prevent personal injury or product damage.										
		It indicates danger, which may cause damage to this device										
A	Caution	or condition. If the "Caution" sign is present all conditions										
<u> </u>		must be met before you proceed to operation										
		It indicates potential problems, which may cause failure of										
	Note	this device if you fail to follow a certain procedure or										
\wedge		condition. If the "Note" sign is present, all conditions must										
2-3		be met before this device will function properly.										
A		Alternating current of device. Please check the region's										
	AC	voltage range.										
	DC	Direct current device. Please check the region's voltage										
	DC	range.										
<i>.</i>	Grounding	Frame and chassis grounding terminal										
	Grounding	Protective grounding terminal										
4	Grounding	Measurement grounding terminal										
0	OFF	Main power off										
	ON	Main power on										
Color Mar		Standby power supply: When the power switch is turned										
Ċ	Power	off, this device is not completely disconnected from the AC										
		power supply.										
	Secondary el	ectrical circuit connected to wall sockets through										
CATI	transformers	or similar equipment, such as electronic instruments and										
	electronic eq	uipment; electronic equipment with protective measures,										
	and any high-voltage and low-voltage circuits, such as the copier in the											

		office.					
CAT II		Primary electrical circuit of the electrical equipment connected to the indoor socket via the power cord, such as mobile tools, home appliances, etc. Household appliances, portable tools (e.g., electric drill), household sockets, sockets more than 10 meters away from CAT III circuit or sockets more than 20 meters away from CAT IV circuit.					
CAT III		Primary circuit of large equipment directly connected to the distribution board and circuit between the distribution board and the socket (three-phase distributor circuit includes a single commercial lighting circuit). Fixed equipment, such as multi-phase motor and multi-phase fuse box; lighting equipment and lines inside large buildings; machine tools and power distribution boards at industrial sites (workshops).					
с	AT IV	Three-phase public power unit and outdoor power supply line equipment. Equipment designed to "initial connection," such as power distribution system of power station, power instrument, front-end overload protection, and any outdoor transmission line.					
CE	Certificati on	CE indicates a registered trademark of EU.					
Intertek 4007682	Certificati on	Conforms to UL STD 61010-1 and 61010-2-030. Certified to CSA STD C22.2 No.61010-1 and 61010-2-030.					
X	Waste	Do not place equipment and accessories in the trash. Items must be properly disposed of in accordance with local regulations.					
4 0	EEUP	This environment-friendly use period (EFUP) mark indicates that dangerous or toxic substances will not leak or cause damage within this indicated time period. The environmentally friendly use period of this product is 40 years, during which it can be used safely. Upon expiration of this period, it should enter the recycling system					
Safety	Requiremen	ts					
W	arning						
Warning Preparation before use		Please connect this device to AC power supply with the power cable provided. The AC input voltage of the line reaches the rated value of this device. See the product manual for specific rated value. The line voltage switch of this device matches the line voltage. The line voltage of the line fuse of this device is correct. This device is not intended for measuring the main circuit.					
Check rate	all terminal d values	Please check all rated values and marking instructions on the product to avoid fire and the impact of excessive current. Please consult the product manual for detailed rated values before connection.					

	You can only use the special power cord for the instrument approved by
Use the power	the local and state standards. Please check whether the insulation layer
	of the cord is damaged, or the cord is exposed, and test whether the cord
cora property	is conductive. If the cord is damaged, please replace it before using the
	instrument.
	To avoid electric shock, the grounding conductor must be connected to
Instrument	the ground. This product is grounded through the grounding conductor
Grounding	of the power supply. Please be sure to ground this product before it is
	powered on.
	Please use the AC power supply specified for this device. Please use the
AC power supply	power cord approved by your country and confirm that the insulation
	layer is not damaged.
	This device may be damaged by static electricity, so it should be tested
	in the anti-static area if possible. Before the power cable is connected to
Electrostatic	this device, the internal and external conductors should be grounded
prevention	briefly to release static electricity. The protection grade of this device is
	4 kV for contact discharge and 8 kV for air discharge.
	Measurement accessories designated as lower-grade, which are not
Maaauramant	applicable to main power supply measurement, CAT II, CAT III, or CAT IV
measurement	circuit measurement. Probe subassemblies and accessories within the
accessories	range of IEC 61010-031 and current sensors within the range of IEC
	61010-2-032 can meet its requirements.
	Please use the input / output ports provided by this device in a proper
	manner. Do not load any input signal at the output port of this device. Do
Use the input /	not load any signal that does not reach the rated value at the input port
output port of this	of this device. The probe or other connection accessories should be
device properly	effectively grounded to avoid product damage or abnormal function.
	Please refer to the product manual for the rated value of the input /
	output port of this device.
	Please use a power fuse of exact specification. If the fuse needs to be
Power fuse	replaced, it must be replaced with another one that meets the specified
	specifications by the maintenance personnel authorized by UNI-T.
Disassombly and	There are no components available for operators inside. Do not remove
	the protective cover.
Cleaning	Qualified personnel must conduct maintenance.
Service	This device should be used indoors in a clean and dry environment with
	ambient temperature from 0 °C to +40 °C.
	Do not use this device in explosive, dusty, or high humidity conditions.
Do not operate in	Do not use this device in a humid environment to avoid the risk of internal

humid	abort airauit ar alactria abook
numia	Short circuit of electric shock.
environment	
Do not operate in	Do not use this device in a flammable and explosive environment to avoid
flammable and	product damage or personal injury.
explosive	
environment	
Caution	
	If this device may be faulty, please contact the authorized maintenance
Abnormality	personnel of UNI-T for testing. Any maintenance, adjustment or parts
	replacement must be done by the relevant personnel of UNI-T.
	Do not block the ventilation holes at the side and back of this device.
Cooling	Do not allow any external objects to enter this device via ventilation holes.
Cooling	Please ensure adequate ventilation and leave a gap of at least 15 cm on
	both sides, front and back of this device.
Safe	Please transport this device safely to prevent it from sliding, which may
transportation	damage the buttons, knobs, or interfaces on the instrument panel.
	Insufficient ventilation will cause the device temperature to rise, thus
Proper ventilation	causing damage to this device. Please keep proper ventilation during use,
	and regularly check the vents and fans.
Keen sleen and	Please take actions to avoid dust or moisture in the air affecting the
Keep clean and	performance of this device. Please keep the product surface clean and
dry	dry.
Note	
Colliburation	The recommended calibration period is one year. Calibration should only
Caupration	be conducted by qualified personnel.

1.3 Environmental Requirements

This instrument is suitable for the following environment.

- Indoor use
- Pollution degree 2
- Overvoltage category: This product should be connected to a power supply that meets
 Overvoltage Category II. This is a typical requirement for connecting devices via power cords and plugs.
- In operating: altitude lower than 3000 meters; in non-operating: altitude lower than 15000 meters.
- Unless otherwise specified, operating temperature is 10°C to +40°C; storage temperature is -20°C to + 60°C.

In operating, humidity temperature below to +35°C, ≤ 90% RH. (Relative humidity); in non-operating, humidity temperature is +35°C to +40°C, ≤ 60% RH.

There is ventilation opening on the rear panel and side panel of the instrument. So please keep the air flowing through the vents of the instrument housing. To prevent excessive dust from blocking the vents, please clean the instrument housing regularly. The housing is not waterproof, please disconnect the power supply first and then wipe the housing with a dry cloth or a slightly moistened soft cloth.

1.4 Connecting Power Supply

The specification of the AC power supply is as shown in the following table.

Voltage Range	Frequency
100 -240 V AC (Fluctuations ±10%)	50/60 Hz
100-120 V AC (Fluctuations ±10%)	400 Hz

Please use the attached power cord to connect to the power port.

Connecting to the service cable:

This instrument is a Class I safety product. The supplied power cables have reliable performance in terms of case grounding. This spectrum analyzer is equipped with a three-prong power cable that meets international safety standards. It provides good case grounding performance for the specifications of your country or region.

Please install the AC power cable as follows:

- Ensure the power cable is in good condition.
- Leave enough space to connect the power cord.
- Plug the attached three-prong power cable into a well-grounded power socket.

1.5 Electrostatic Requirements

Electrostatic discharge may cause damage to components. Components can be damaged invisibly by electrostatic discharge during transportation, storage and use.

The following measure can reduce the damage of electrostatic discharge.

- Testing in anti-static area as far as possible.
- Before connecting the power cable to the instrument, inner and outer conductors of the instrument should be briefly grounded to discharge static electricity.
- Ensure all the instruments are properly grounded to prevent the accumulation of static.

1.6 Preparation Work

- Connect the power supply wire, plug the power socket into the protective grounding socket; adjust the alignment jig according to your view.
- 2. Press the switch button 0 on the front panel to boot up the instrument.

1.7 Usage Tip

Activate the Option

If you want to activate an option, you need to input the secret key for the option. Please contact the UNI-T office to purchase it.

Refer to the following steps to activate the option you have purchased:

- 1. Save the secret key into a USB drive and insert it into the signal analyzer.
- 2. Press the Utility →System Info key to open the system menu and view basic and optional information.
- 3. In the system information window, press Add License key below the option information table, open the "Add License" dialog box, find the license file in the U disk in the dialog box, select the license file ,and check the box;
- 4. Update the status of the option in the selection information table.

Firmware update

After downloading the firmware upgrade package on the official website, please follow the following steps to upgrade:

 Unpack the upgrade package to the root of your USB drive, which contains four files: mcu_bin.md5, mcu_bin.upg, usg_xxxx.md5, and usg_xxxx.upg, as shown below:



2. Insert the U disk into the USB interface of the front panel of the device, then press the File System button at the bottom left of the screen, open File System → U disk → Upgrade package → select the mcu_bin.upg file, and click Load in the menu on the right panel of the screen to confirm the upgrade.After the first upgrade package is completed, the device will be restarted automatically;

3. After the device is restarted, open the File System → U disk → Upgrade package → select usg_xxxx.upg file, click Load in the right panel menu of the screen, and confirm the upgrade. After the second upgrade package is completed, the device will be restarted automatically again, and the upgrade is completed.

Note

Use FAT32 format U disk to copy the upgrade package. Keep the power supply state during the upgrade process, keep the U disk stable, and do not do other operations to prevent the equipment from working properly due to the failure of upgrade.

1.8 Remote Control

USG5000M series RF analog signal generator can be used to communicate with a computer via USB and LAN interfaces. Users can use SCPI (Standard Commands for Programmable Instruments) through USB or LAN, in combination with programming languages or NI-VISA, to remotely control the instrument and operate other programmable instruments that also support SCPI. For detailed information about installation, remote control modes, and programming, please refer to the *USG5000M Series RF analog signal generator Programming Manual* on the official website: http://www.uni-trend.com.

1.9 Help Information

USG5000M series RF analog signal generator has a built-in help system for each function key and menu control key. Click the Help system in of the Function Interface : open the help navigation and view the help information of the keys.

Chapter 2 Panel and Keys

2.1 Front Panel

The product front panel is shown in the following figure, it is simple, intuitive and easy to use.



8	1	USG3000M	3	4	6
Home		Fox A grant of the set	Andrég Signal Generator 9kHz-6.50 8 9 dán 5 6 Mův 2 3 Mův 0 +/- Mův 1 +/- km		LF Output
9		2	6	_	

1. Display Screen

The 5-inch capacitive touch screen clearly distinguishes function menus, control statuses, and other important information using distinct color tones. Parameter adjustments and output controls are accessible through the touch screen, and the user-friendly system interface enhances human-computer interaction, improving work efficiency.

2. Function Key

The function buttons are Home, Utility,Sweep, AM, FM/ΦM, and Pulse.

Pressing the Home button returns to the home page; the MOD ON/OFF button enables RF modulation; the Sweep button enables RF sweep; the AM button configures the AM setting for RF; the FM/ Φ M button configures the FM/ Φ M setting for RF; the Pulse button configures the pulse setting for RF; and the Utility button is used to set the auxiliary functions.

3. Numerical Keyboard

Digit keys 0 to 9 are used for entering required parameters, along with the decimal point ("."),

the symbol key ("+/-"), and unit keys. The left arrow key backspaces to delete the previous digit in the current entry.

4. Multifunction Rotary Knob / Arrow Keys

The multifunction rotary knob is used to change values (rotate clockwise to increase the number) or function as an arrow key. Press the knob to select a function or confirm a setting. When using the multifunction rotary knob and arrow key to set parameters, they can be used to switch between digit positions, clear the previous digit, or move the cursor left or right.

5. RF/LF/MOD Output Button

Press the RF button to control the RF signal output; press the LF button to control the LF signal output; press the MOD button to enable or disable each modulation mode. The key backlight turns on when the key is enabled and turns off when it is disabled.

6. LF Channel

LF output port.

7. RF Channel

RF output port.

8. USB Port

This port is used to connect an external USB storage device. Through this interface, arbitrary waveform data files saved on the USB device can be read or imported. Alternatively, the instrument's system can be upgraded using this interface to ensure that the function/arbitrary waveform generator program is updated to the latest version.

9. Power Switch button

Press the power switch button to turn on the instrument, press it again to turn it off.

Note

The LF channel output interface has overvoltage protective function, it will be generated when one of the following conditions is met.

- The amplitude of the instrument is less than or equal to 4 Vpp; the input voltage is larger than
 | ± 3 V |; the frequency is less than 10 kHz.
- When the overvoltage protective function is triggered, the channel will automatically disable the output.

2.2 Rear Panel



USG3000M



1. GPIB Port

This port is used to connect the signal generator to a PC, allowing control of the instrument through PC software with GPIB cable.

2. USB Port

This port is used to connect the signal generator to a PC, allowing control of the instrument through PC software with USB cable.

3. Local Area Network (LAN)

This port connects the instrument to a PC through ethernet or remote control.

4. Valid Output Port

Valid output provides a pulse signal. When the user modifies parameters such as frequency or amplitude, valid outputs a high pulse signal. After parameter settings are completed, valid outputs a low pulse signal.

5. External Analog Modulation Input Port

For RF AM, FM, and phase modulation, when the modulation source is set to external or internal+external, the modulation signal is input through the external analog modulation input. The corresponding modulation depth, frequency deviation, phase deviation, or duty cycle deviation is controlled by the 4Vpp high resistance signal level applied to the external analog modulation input.

6. Trigger Signal Output Port

When performing LF scanning, if the trigger output is enabled, the trigger signal (a square wave) can be output through the connector and is compatible with TTL levels. This connector can also output the synchronization signal when RF pulse modulation is used.

- External Trigger Signal Input Port
 When the sweep trigger mode is set to "external" for either RF or LF, this port receives a TTL pulse with the specified polarity as the trigger signal.
- 8. Pulse Signal Output Port

When performing pulse modulation, this port outputs the pulse signal generated by the internal generator.

9. Pulse Signal Input Port

When the pulse mode is set to external trigger, external trigger pulse pair, gating, or external pulse, this port is used to input an external pulse signal.

10. External 10MHz Input Port

Establish synchronization between multiple generators or with an external 10 MHz clock signal. If the instrument detects an external 10 MHz clock signal at the [10MHz IN] connector (input requirements: 10 MHz frequency and TTL level amplitude), it will automatically switch to this

signal as the external clock source, indicated by the first icon refer in the status bar. If the external clock source is lost, out of range, or disconnected, the instrument will automatically

revert to the internal clock, and the icon Ref will update to Ref.

11. Internal 10MHz Output Port

Establish synchronization between multiple signal generators or the output of a 10 MHz reference clock signal to an external source.

12. Main Power Supply Switch

When the power supply switch is set to "I", the instrument power is connected. When the power switch is set to "O", the instrument is disconnected (the power button on the front panel does not function).

13. AC Power Input Port

For the AC power specifications of the USG5000 series, refer to the *Connecting Power Supply* section.

14. Safety Lock

The safety lock (sold separately) is used to secure the instrument in a fixed position.

15. Ground Terminal

The ground terminal provides an electrical connection point for attaching an antistatic wrist strap to reduce electrostatic discharge (ESD) when handling or connecting the DUT.

2.3 Function Interface



- RF Frequency (Display Frequency): By selecting this parameter, users can directly set the RF frequency. This differs from the frequency output setting in the frequency menu, RF Frequency (Display Frequency) = Frequency Output + Frequency Offset.
- 2. Status Bar

RF: Displays RF output state. Gray indicates that the output is disabled, while blue indicates that the output is enabled.

ExtRef: Indicates that the signal generator is using the external 10MHz reference input. MOD: Displays modulation mode state. Gray indicates that the modulation is disabled, while blue indicates that the modulation is enabled.

AM/FM/Pul: Indicates the current modulation function in use. Gray indicates that the current modulation is disabled, while blue indicates that the current modulation is enabled.

- RF (Display Amplitude): By selecting this parameter, you can directly set the RF amplitude. This differs from the amplitude output setting in the frequency menu, RF Amplitude (Display Amplitude) = Amplitude Output + Amplitude Offset.
- 4. Parameter Setting Area

Modulation source: Controls the internal modulation source for RF, including enabling/disabling the internal modulation source, setting modulation wave, modulation frequency, modulation amplitude, and modulation phase.

Modulation input: Controls the external modulation source for RF, including enabling/disabling

the external modulation input and setting the load for the external modulation source. Analog modulation: Controls the RF modulation parameters, including enabling/disabling modulation and setting amplitude modulation (AM), frequency modulation (FM), phase modulation (Φ M), and pulse modulation (Pulse).

RF: Controls the RF carrier waves, including enabling/disabling RF output, setting frequency, amplitude, sweep, and power meter.

Function generation: Controls the LF signals, including enabling/disabling LF output, setting LF carrier waves, sweep, and modulation parameters.

- 5. Date and time: Displays day and time.
- 6. Connection type: Displays the connection device state, such as mouse, U disk, USB flash drive, and screen lock.
- 7. System log dialog box: Click on the blank area on the right side of the file storage section to access the system log, view local runtime logs, alarms, notifications, and other information.
- 8. Function setting: Screenshot, file system, setup system, and help system.
 Hom page : Click on this key to return to the home page, double-click on this key to take a screenshot and save it to the instrument.

File system 🗐: In the file system, users can save, copy, move, delete, load, and rename files, including sweep list files, pulse string files, screenshots, state files, arbitrary files, and other files. System information 🔯: View basic and optional information about the instrument. Help system 🙆: Open the help navigation.

2.4 ouch Operation

RF analog signal generator is equipped with a 5-inch capacitive touchscreen that supports several gestures:

- Tap a parameter or menu on the screen to edit the selected parameter.
- Swipe left or right to switch menus
- Swipe up or down to scroll through the menu.

Note: The menu can only be scrolled down when a scroll bar appears on the right side of the screen. If no scroll bar is visible, only the current page is displayed.

Chapter 3 Quick Start

3.1 Set Output Frequency

Default RF wave configuration: A continuous wave with 1 GHz frequency, amplitude -135 dBm.

The specific steps to change the frequency to 2.5 MHz are as follows.

Press the Freq key, use the numerical keyboard to enter 2.5, and then select GHz as the unit for the parameter.

3.2 Set Frequency Offset

Default RF wave configuration: The frequency offset is 0 Hz.

The specific steps to change the frequency offset to 100 kHz are as follows.

Press the	Home key in	the analog str	eam mapp	er on th	e screer	n, press t	the RF	→Freq÷	Freq (Offset
key, use t	he numerical	keyboard to e	enter 100, s	select k	Hz as th	e unit fo	or the p	aramete	er, and	then
click Freq	Offset key t	o enable this :	setting.							

Note: The multifunction knob and arrow keys can also be used together to set this parameter.

3.3 Set Reference Frequency

Default RF wave configuration: The reference frequency is 0 Hz. The specific steps to change the reference frequency to 200 MHz are as follows. Press the Home key in the analog stream mapper on the screen, press the $RF \rightarrow Freq \rightarrow Freq Ref$ key, use the numerical keyboard to enter 200, select MHz as the unit for the parameter, and then click Freq Ref key to enable this setting.

3.4 Set Phase Offset

Default RF wave configuration: The phase offset is 0°.

The specific steps to change the phase offset to 90° are as follows. Press the Home key in the analog stream mapper on the screen, press the $RF \rightarrow Freq \rightarrow Phase Offset$ key, use the numerical keyboard to enter 90, and then select deg as the unit for the parameter.

3.5 Set Reference Phase

Default RF wave configuration: The phase offset is 0°.

The specific steps to change the reference phase to 180° are as follows.

Press the Home key in the analog stream mapper on the screen, press the RF \rightarrow Freq \rightarrow Phase Ref

key, use the numerical keyboard to enter 180, select deg as the unit for the parameter, and then click Phase Ref key to enable this setting.

3.6 Set Internal TB Calibration

Default RF wave configuration: The internal TB calibration is 0 ppb.

The specific steps to change the internal TB calibration to 30 ppb are as follows.

Press the Home key in the analog stream mapper on the screen, press the RF \rightarrow Freq \rightarrow Inner TB calibration key, use the numerical keyboard to enter 30, and then select ppb as the unit for the parameter.

3.7 Set Reference Source

Default RF wave configuration: The reference source is Auto. The specific steps to change the reference source to internal are as follows. Press the Home key in the analog stream mapper on the screen, press the $RF \rightarrow Freq \rightarrow Ref$ Oscillator \rightarrow Internal key to complete this setting.

3.8 Set Output Amplitude

Default RF wave configuration: The amplitude is 10 dBm.

The specific steps to change the amplitude to 0 dBm are as follows. Press the Home key in the analog stream mapper on the screen, press the $RF \rightarrow Ampt \rightarrow Ampt$

use the numerical keyboard to enter 0, and then select dBm as the unit for the parameter.

3.9 Set Output Amplitude Offset

Default RF wave configuration: The amplitude offset is 0 dB.

The specific steps to change the phase offset to 10 dB are as follows.

Press the Home key in the analog stream mapper on the screen, press the $RF \rightarrow Ampt \rightarrow Ampt$

Offset key, use the numerical keyboard to enter 10, and then select Ampt Offset as the unit for the parameter.

key,

3.10 Set Reference Amplitude

Default RF wave configuration: The reference amplitude is 0 dB.

The specific steps to change the reference amplitude to 20 dB are as follows.

Press the Home key in the analog stream mapper on the screen, press the $RF \rightarrow Ampt \rightarrow Ampt Ref$

key, use the numerical keyboard to enter 20, select dBm as the unit for the parameter, and then click Ampt Ref key to enable this setting.

3.11 Set User-defined Maximum Power

Default RF wave configuration: The user-defined maximum power is 10 dBm.

The specific steps to change the customized maximum power to 20 dB are as follows.

Press the Home key in the analog stream mapper on the screen, press the RF \rightarrow Ampt \rightarrow User Power

Max key, use the numerical keyboard to enter 20, select dBm as the unit for the parameter, and

then click User Power Max key to enable this setting.

3.12 Set Attenuation

Default RF wave configuration: The attenuation is 0 dB.

The specific steps to change the attenuation to 10 dB are as follows.

Press the I	Home	key in t	he analog	ı stream	mapper	on th	ne scre	en,	pres	s the	RF	\rightarrow	Ampt	\rightarrow	Set /	Atten
key, use th	ne nur	nerical k	ceyboard	to enter	10, and	then	select	dB	as tl	he ur	nit f	or 1	the pa	arai	mete	er.

3.13 Set ALC

Default RF wave configuration: The ALC (Automatic Level Control) is enabled.

The specific steps to change the ALC state to auto are as follows.

Press the Home key in the analog stream mapper on the screen, press the $RF \rightarrow Ampt \rightarrow ALC$ State

key, and select Auto in the drop-down menu to complete the setting.

Chapter 4 Troubleshooting

Possible faults when using the USG5000 and their corresponding troubleshooting methods are listed below. Follow the steps provided for each fault. If the issue persists, please contact your distributor or local office and provide the model information (check the model info, press $Utility \rightarrow System$.)

4.1 No Display (Blank Screen)

If the signal generator screen remains blank when the power switch on the front panel is pressed:

- 1) Check that the power source is properly connected.
- 2) Ensure the power button is fully pressed.
- 3) Restart the instrument.
- If the instrument still does not respond, please contact your distributor or local office for maintenance service.

4.2 No Waveform Output

If the settings are correct but the instrument has no waveform output:

- 1) Check that the BNC cable and output terminal are properly connected.
- 2) Ensure the LF or RF key is enabled.
- If the instrument still does not work, please contact your distributor or local office for maintenance service.

Chapter 5 Service and Support

Maintenance and Cleaning

(1) General Maintenance

Keep the instrument away from the direct sunlight.

Caution

Keep sprays, liquids and solvents away from the instrument or probe to avoid damaging the instrument or probe.

(2) Cleaning

Check the instrument frequently according to the operating condition. Follow these steps to clean the external surface of the instrument:

Please use a soft cloth to wipe the dust outside the instrument.

When cleaning the LCD screen, please pay attention and protect the transparent LCD screen. When cleaning the dust screen, use a screwdriver to remove the screws of the dust cover and then remove the dust screen. After cleaning, install the dust screen in sequence.

Please disconnect the power supply, then wipe the instrument with a damp but not dripping soft cloth. Do not use any abrasive chemical cleaning agent on the instrument or probes.

Warning

Please confirm that the instrument is completely dry before use, to avoid electrical shorts or even personal injury caused by moisture.

Intellectual Property Statement

Copyright © 2024 by UNI-T Technology (China) Co., Ltd. All rights reserved.

UNI-T products are protected by patent rights in China and foreign countries, including awarded and pending patents.

UNI-T is the registered trademark of Uni-Trend Technology (China) Co., Ltd.

Licensed software products are properties of Uni-Trend and its subsidiaries or suppliers, all rights reserved. This manual contains information that replaces all earlier published versions.

PN:110401112935X