

UP07000L Series Digital Phosphor Oscilloscopes 10GSa/s | 2GHz | 1Gpts | 2,000,000wfms/s



QuickStart Guide REV.2.1 November 2024

Limited Warranty and Liability

UNI-T guarantees that the Instrument product is free from any defect in material and workmanship within three years from the purchase date. This warranty does not apply to damages caused by accident, negligence, misuse, modification, contamination, or improper handling. If you need a warranty service within the warranty period, please contact your seller directly. UNI-T will not be responsible for any special, indirect, incidental, or subsequent damage or loss caused by using this device. For the probes and accessories, the warranty period is one year. Visit instrument.uni-trend.com for full warranty information.



Scan to Download relevant document, software, firmware and more.



Register your product to confirm your ownership. You will also get product notifications, update alerts, exclusive offers and all the latest information you need to know.

LINI-T is the licensed trademark of UNI-TREND TECHNOLOGY (CHINA) CO., Ltd.

UNI-T products are protected under patent laws in China and internationally, covering both granted and pending patents. Licensed software products are the properties of UNI-Trend and its subsidiaries or suppliers, all rights reserved. This manual contains information that replaces all earlier published versions. The product information in this document subject to update without notice. For more information on UNI-T Test & Measure Instrument products, applications, or service, please contact UNI-T instrument for support, the support center is available on www.uni-trend.com ->instruments.uni-trend.com

https://instruments.uni-trend.com/ContactForm/

Headquarter

UNI-TREND TECHNOLOGY (CHINA) CO., Ltd.

Address: No.6, Industrial North 1st Road, Songshan Lake Park, Dongguan City, Guangdong Province, China

Tel: (86-769) 8572 3888

Europe

UNI-TREND	TECHNOLOGY
EU GmbH	
Address: Affin	ger Str. 12
86167 Augsbu	irg Germany
Tel: +49 (0)82	1 8879980

North America

UNI-TREND TECHNOLOGY US INC. Address: 3171 Mercer Ave STE 104, Bellingham, WA 98225 Tel: +1-888-668-8648

UP07000L Overview

UPO7000L series digital phosphor oscilloscopes feature a compact, rack-mounted structural design with a slim and lightweight body. 1U height is designed for multi-machine system integration, highdensity rack setups, and remote system operations, making it ideal for various application scenarios. The system supports multi-unit synchronous triggering and can be expanded to accommodate up to 128 oscilloscopes. Each unit integrates 4 analog channels, 1 external trigger channel, and 1 function/arbitrary waveform generator channel. With a flat body design and machine feet pads, the oscilloscopes are easy to stack and organize. leveraging the 7000 series platform, it ensures a smooth transition for users familiar with 7000X operation. Additionally, an external touch display can be connected, enabling a responsive touch experience similar to that of the 7000X series. For multi-machine integration, the series includes a rack-mounting kit for quick and straightforward installation right out of the box. Whether in system development, testing, or other demanding environments, UPO7000L excels in reliability and performance.

(0)	وي. ال	• "	@ ⁷		(0)	@ ⁷	(Q)	@1		885	**	200
2		?	@"		0	<u>.</u>	())	@"	12 (11)		33333333 3333333	
۵'	٩	<u>•</u> "	<u>@</u> '		<u>@</u>	•	<u>@</u> '	?ء	10 a			
٩	<u>e</u> "	•	œ'	• 1	<u>@</u>	•	۹,	œ'	• III			
@	۹,	•	œ'		@	@"	<u>e</u> '	<u>@</u> '	101 C			
@	•	•	<u>@</u> '		0	•	•	<u>@</u> '	101 •			
@	<u>o</u> '	•	œ'	100 M	<u>O</u>	Q '	<u>@</u>	œ'				
0'	<u>@</u> ?	•	®,	100	0	•	٩	œ'	• 1 02			
0	Q'	•	œ'		<u>@</u> ?	@ '	•	œ'	-	200000		
0	<u>e</u> r	•	œ'	100 C	<u>@</u>	٩	•	Q)	• 1 02	0000000		
******		*****	*****	*****			*****			the second		
		0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0				0 0 <td>0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0</td> <td>0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,</td> <td></td> <td></td>	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,		



UPO7000L series digital phosphor oscilloscopes include the following models.

Model	Analog Channel	Analog Bandwidth	AWG	Power Analysis	Jitter Analysis	Eye Diagram
UPO7204L	4	2GHz	0	0	0	0
UPO7104L	4	1GHz	0	0	0	0

O: Indicates option

Quick Guide

This chapter introduces basics of using the UPO7000L series oscilloscope for the first time, including the front panel, rear panels, and user interface.

General Inspection

It is recommended to inspect the instrument by following the steps below before using the UPO7000L series oscilloscope.

(1) Check for transport damage

If the packaging carton and the plastic foam cushions damage. If significant damage is found, please contact the UNI-T distributor.

(2) Check accessories

Refer to the appendix for the list of included accessories. If any accessories are missing or damaged, please contact the UNI-T distributor.

(3) Machine inspection

Examine the instrument for any visible damage, operational issues, or failures during the functionality test. If problems are detected, contact the UNI-T distributor.

If the instrument is damaged during shipping, retain the packaging materials and notify both the transportation department and the UNI-T distributor. UNI-T will arrange for maintenance or replacement as necessary.

Before Use

To perform a quick verification of the instrument's normal operations, follow the steps below.

1. Connecting Power Supply

The power supply voltage ranges from 100VAC to 240VAC, with a frequency range of 50Hz to 60Hz. Use the assembled power cable or another power cable that meets the local country standards to connect the oscilloscope. When the power switch on the rear panel is disabled, the power soft indicator in the left bottom on the rear panel lights up orange, press the soft power key to turn on the oscilloscope; when the power switch on the rear panel is enabled, the oscilloscope will automatically power on.

2. Boot-up Check

Press the soft power key to turn on the oscilloscope, the indicator of will change from orange

to blue. The oscilloscope will show a boot animation before entering the normal interface.

3. Connecting Probe

Use the assembled probe, connect BNC of probe to CH1 BNC on the oscilloscope, connect the probe tip connects to "Probe Compensation Signal Connection Sheet", and connect the ground alligator clip to the "Ground Terminal" of probe compensation signal connection sheet, as shown in the following figure. The probe compensation signal connection sheet outputs an amplitude of approximately 3Vpp and a default frequency of 1kHz.



Probe Compensation Signal Connection Sheet
 Ground Terminal

Figure 1 Probe Compensation Signal Connection Sheet and Ground Terminal

4. Function Inspection

Press the Autoset (Automatic Setting) icon, a square wave with an amplitude of approximately 3Vpp and a frequency of 1kHz will appear on the screen. Repeat step 3 to check all channels. If the displayed square wave shape does not match the one shown in the figure above, proceed to the next step "Probe Compensation."

5. Probe Compensation

When the probe is connected to any input channel for the first time, this step may need to be adjusted to match the probe and the input channel. Uncompensated probes can lead to measurement errors or inaccuracies. Please follow the steps below to calibrate probe compensation.

- (1) Set the attenuation coefficient in the probe menu to 10x and ensure the probe switch is set to 10x. Connect the probe to CH1 on the oscilloscope. If using the probe's hook head, ensure it makes stable contact with the probe.
- (2) Connect the probe tip to the "Probe Compensation Signal Connection Sheet" and the ground alligator clip to the "Ground Terminal" of the "Probe Compensation Signal Connection Sheet." Open CH1 and press the Autoset icon.

View the displayed waveform, as shown in the following figure.



UNI-T

If the displayed waveform appears as "Insufficient Compensation" or "Excessive Compensation," use a non-metallic screwdriver to adjust the probe's variable capacitance until the display matches the "Correct Compensation" waveform.

Warning: To avoid the risk of electric shock when using the probe to measure high voltage, ensure that the probe insulation is intact and avoid physical contact with any metallic parts of the probe.

Appearance and Dimensions



Front View



Side View

Front Panel



Figure 3 Front Panel

Table 1 Front Panel Connectors

No.	Description	No.	Description
			Probe compensation signal
1	Nameplate/Model series	4	connection sheet and ground
			terminal
2	External trigger SMA connector	5	Analog channel input terminal
3	USB HOST 2.0	6	Soft power switch

Table 2 Front Panel Key Indicator

Key Indicator	Red	Green	Blue	Yellow	None
				Powered on	
Power			Powered on	but not	
				enabled	
			The channel's		
			microcontroller		
			has been		
RunStop	Stop	Run	powered on, but	Abnormal	
			the software has		
			not been started		
			yet		
	Network	Network			
Lan	connection	connection			
	failed	normal			
				The	
				oscilloscope	
A = 5	Stop	Tricrocord		is currently	
Асq	acquisition	iriggered		capturing	
				pre-trigger	
				data.	

UPO7000L Digital Phosphor Oscilloscopes-QuickStart Guide

		1140	500	The channel is
				not opened

Rear Panel

UNI-T



Figure 4 Rear Panel

Table 3 Icon in User Interface

No.	Description	No.	Description
1	Safety Keyhole	8	Ground Hole
2	Gen Out	9	LAN
3	Aux Out	10	RST
4	HDMI	11	Audio port
5	10MHz Ref Out	12	USB DEVICE 2.0
6	10MHz Ref In	13	Auto Power On
7	USB Host	14	AC power supply

1. Safety Keyhole: A safety lock (purchased separately) can be used to lock the oscilloscope in a fixed position through the keyhole.

- 2. Output port of function/arbitrary waveform generator.
- 3. Aux Out: Trigger synchronous input; Pass/Fail test results; AWG trigger output.
- 4. HDMI: High-definition multimedia interface.
- 5. 10MHz Ref Out: A BNC on the rear panel that outputs the oscilloscope's 10MHz reference clock for synchronization with other external instruments.
- 6. 10MHz Ref In: Provides the reference clock for oscilloscope's acquisition system.
- 7. USB Host: Through this interface, USB-compatible storage devices can be connected to the oscilloscope. When connected, waveform files, setting files, data, and screen images can be saved or retrieved. Additionally, if updates are available, the oscilloscope's system software can be locally upgraded via the USB Host port.

- 8. Ground Hole: The device can be grounded to generate static electricity.
- 9. LAN: Use this port to connect the oscilloscope to the LAN (local area network) for remote control.
- 10. RST: Restart device.
- 11. Audio port.
- 12. USB DEVICE 2.0: Use this port to connect the oscilloscope to PC for communication.
- 13. Auto Power On: Automatic power-on setting switch, toggle the switch to AT ON, oscilloscope power on automatically after startup.
- 14. AC power supply: 100-240VAC, 50-60Hz.



User Interface

Figure 5 User Interface

No.	Description	No.	Description
1	UNI-T Logo	17	Zone triggering
2	Trigger state icon	18	Window extension
3	Single trigger	Single trigger 19 M	
4	Autoset	set 20 Trigger level cursor	
5	Horizontal scale and delay	d delay 21 Frequency meter	

Table 4 Icon in User Interface

6	Acquisition mode, storage depth and sampling rate	22	Digital voltmeter
7	Trigger information	23	Function/arbitrary waveform generator
8	Cursor measurement	24	Protocol analyzer
9	FFT	25	Reference waveform
10	UltraAcq® mode	26	Mathematical operation
11	Search Navigation	27	Channel state label
12	Save	28	Measurement menu
13	Screenshot	29	Analog channel cursor and waveform
14	Delete	30	Trigger position cursor
15	System setting		
16	Start menu		

Measurement Menu

Click the measurement label icon 🐹 at the bottom left to open the measurement menu, as shown

in Figure 6.

			?	فاشداؤها			
		1					
	💮 Cym	nomet	er				
	🗐 Quid	k Me	as				
	📮 Thre	eshold	-Screen				
	🏷 Thre	eshold	-Cursor				
	🔳 Stat	istics					
	📑 Mea	isure					
3	🔜 Clos	e All I	Measure			-3µs	
8							
C1 100	DC1M 0 mV/div FULL 1V	C2 10	DC1M 0 mV/div FULL	C3 100	DC1M mV/div FULL	C4 10	DC1M 0 mV/div FULL

Figure 6 Measurement Menu

Digital voltmeter: Click to enable the digital voltmeter measurement, which supports 4digit AC RMS, DC, and DC+AC RMS measurements.

© Cymometer Frequency meter: Click to enable 8-digit high precise frequency meter.

Parameter snapshot: Click to enable the parameter snapshot to view various parameter measurements.

Threshold-Screen Measurement threshold-screen: The measurement range covers the entire screen.
 Threshold-Cursor Measurement threshold-cursor: Select the parameter measurement range based on the cursor position.

- Statistics Measurement statistics: Click to enable the measurement statistics, including the current value, maximum, minimum, average, standard deviation, and count.
- Parameter measurement: Turn on/off the parameter measurement function.

^{© Close All Measure} Close all measurement items: Close all active measurement items with a single click.

Communication

UPO7000L series digital phosphor oscilloscopes support communication with a computer via the USB and LAN interfaces for remote control. Remote control is enabled using the SCPI (Standard Commands for Programmable Instruments) command set.

UPO7000L series supports three communication methods:

- 1. LAN: SCPI
- 2. USB: SCPI
- 3. WebServer: SCPI, remote control, export data via browser

Click the auxiliary setting icon 🧑 to open the setting menu, and select "Communication" option.

Network

Before using the LAN interface, connect the oscilloscope to the local area network using a network cable. The oscilloscope's network port is located on the rear panel. The settings menu and network connection interface (as shown in Figure 7) allow the user to view the current network settings and configure network parameters.

Figure 7 Network Configuration

USB

USB interface can display the vendor ID, product ID, serial number, and the currently used VISA address, as shown in Figure 8. This oscilloscope can communicate directly with the host computer via the USB device interface on the rear panel, without requiring additional configuration.

Figure 8 USB Communication

WebServer

Web Server displays the current network switch state. The default network port is set to 80.

PC Access

The computer and the oscilloscope must be connected to the same LAN and capable of ping each other. The user can view the oscilloscope's local IP address by clicking the setting icon it view, and then can view the oscilloscope's local IP address by IP: 80, as shown in Figure 9. Example

PC IP: 192.168.137.101 Oscilloscope IP: 192.168.137.100

Gateway: 192.168.137.1

To access the oscilloscope, enter 192.168.137.222:80 in the browser. The available features are displayed in Figure 10.

- Device information and remote control: View and control the oscilloscope remotely.
- SCPI control: Send and execute SCPI commands.
- Export data file: Export waveforms and files.

UPO7000L Digital Phosphor Oscilloscopes-QuickStart Guide

Meter SCPI control Remote Export Document About Welcome To Use UPO7204L Base Info Model UP07204L Manufacturer Uni-Trend Technology (Child) Apr/224390014 Firmware Versions Firmware Versions Null Network Info TCP IP 192.168.137.100 TCP IP 192.168.137.100 TERMON TO
Welcome To Use UPO7204L Base Info Model UP07264L Manufacturer UH-THERE Technology (China) Co., Ltd. Serial Number API/72249014 Firmware Versions NULL Network Info 192.166.137.100 TOP IP 192.166.137.100
Base Info Model UP07224L Manufacturer Uni-Trend Technology (China) Co., Ltd. Serial Number APU722450014 Firmware Versions NULL Network Info TCP IP 192.165.137.100 TCP IP
Model UP07204L Manufacturer Uni-Trend Technology (China) Co. Ltd. Serial Number APJ722490014 Firmware Versions NULL Network Info 192.165.137.100 TCP IP 192.105.137.00
Manufacturer Uni-Trend Technology (Chind) Co. Ltd. Serial Number AP17224350014 Firmware Versions NULL Network Info TCP IP 192.166.137.100 TCP IP 192.25.25.29.29.01
Serial Number AP(7224390014) Firmware Versions NULL Network Info Image: Serial Strategy of the serial series (Serial Serial Seria
Firmware Versions NULL Network Info
Network Info
TCP IP 192.168.137.100
MAC Address 00-90-27-F7-02-EA
VISA Address TCPIP0:192.168.137.100:inst0:INSTR
LXI Versions -
Current Time 10/14/2024 9:39:12 AM

	Remote Full Page Full Sareen Store	
	LAND-T men Benger Annewer H. Statuste B. A. ∏hourne Statusten, 2010/dean T. Statu ⊂ J. 2020 or	
	120 minute 12 avenue, 10 avenue, 12 avenue,	
24 - LINI-T All Pights Pergrand		anguage: 英语(美国)

Figure 10 Remote Control

Cellphone Access

The cellphone and the oscilloscope must be connected to the same LAN (usually under the same WLAN band). The user can view the oscilloscope's local IP address on the setting menu and access the oscilloscope via a web browser by entering its IP address followed by IP: 80, as shown in Figure 11 and 12.

The functionality on the cellphone is identical to that on the computer, with differences only in the layout.

Figure 11 Web Server Home Page

UPO7000L Digital Phosphor Oscilloscopes-QuickStart Guide

Figure 12 Remote Control

Troubleshooting

This section provides a list of potential faults and troubleshooting methods that may occur while using the oscilloscope. If you encounter any of these issues, please follow the corresponding steps to resolve them. If the problem persists, contact UNI-T and provide the equipment information for your device.

- (1) If the oscilloscope remains on a black screen without any display when press the soft power button.
 - Check if the power plug is properly connected and the power supply is normal.
 - Check whether the power switch of the oscilloscope is turned on. Once the switch is on, the power soft switch button on the front panel should display a red light. After pressing the start soft switch, the soft power switch button will turn blue, and the oscilloscope will emit a startup sound.
 - If a sound is heard, it indicates that the oscilloscope has booted up normally.
 - If the product still does not work properly, contact the UNI-T Service Center for assistance.
- (2) After signal acquisition, the waveform of the signal does not appear on the screen.
 - Check whether probe and DUT are connected properly.
 - Check whether the signal connecting line is connected to analog channel.
 - Check whether the analog input terminal of the signal matches the channel that is currently selected on the oscilloscope.
 - Connect the probe tip to the probe compensation signal connector on the front panel of the oscilloscope and verify whether the probe is functioning properly.
 - Check if the device under test is generating a signal. The user can connect the signalgenerating channel to the problematic channel to help diagnose the issue.
 - Click Autoset to allow the oscilloscope to automatically reacquire the signal.
- (3) The measured voltage amplitude value is 10 times larger or 10 times smaller than the actual value.
 - Check whether the probe attenuation setting on the oscilloscope matches the attenuation factor of the probe being used.
- (4) There is a waveform display, but it is unstable.
 - Check the trigger settings in the trigger menu to ensure they match the actual signal input channel.
 - Check the trigger type: general signals should typically use the "Edge" trigger. The

waveform will display stably only if the trigger mode is set correctly.

■ Try changing the trigger coupling to HF rejection or LF rejection to filter out highfrequency or low-frequency noise that may be interfering with the trigger.

(5) Waveform refresh is very slow.

Check whether the acquisition method is set to "Average" and if the average times are large.

To accelerate the refresh speed, the user can reduce the number of averaging times or select other acquisition methods.

Maintenance and Cleaning

(1) General Maintenance

Keep the probe and its accessories away from the direct sunlight.

Caution: Avoid contact with sprays, liquids, or solvents to prevent probe damage.

(2) Cleaning

Check the probe frequently according to the operating condition. Follow these steps to clean the external surface of the probe:

Use a soft cloth to remove dust from the probe.

Disconnect the power supply and clean the probe with mild detergent or water.

Do not use abrasive or chemical cleaners, as they may damage the probe.

Warning: Please confirm that the instrument is completely dry before use, to avoid electrical shorts or even personal injury caused by moisture.